## HOMCOM IT700-094BG0631

# HOMCOM Massage Recliner Chair User Manual

Model: IT700-094BG0631

### Introduction

Thank you for choosing the HOMCOM Massage Recliner Chair. This chair is designed to provide comfort and relaxation with its integrated massage and heating functions, adjustable recline, and footrest. Please read this manual thoroughly before assembly and use to ensure proper operation and safety.



Image: The HOMCOM massage recliner chair in beige faux leather, shown in an upright position.

## Safety Instructions

- Ensure all components are securely assembled before use.
- Do not allow children to play on or around the recliner without adult supervision.
- Keep hands and feet clear of the reclining mechanism when adjusting the chair.
- Only use the provided power adapter for the massage and heating functions.
- Do not use the chair if the power cord or plug is damaged.
- Avoid placing the chair near heat sources or in direct sunlight to prevent material damage.
- Maximum weight capacity for this chair is 150 kg. Do not exceed this limit.
- Individuals with limited mobility, especially the elderly, should exercise caution when operating the footrest mechanism, as it may require significant force to close.

## Package Contents

Please check that all parts are present before beginning assembly:

- Backrest
- Seat Base with Armrests
- Footrest Assembly
- Power Adapter
- Remote Control
- Assembly Hardware (screws, washers, etc.)
- Instruction Manual

## Assembly Instructions

Assembly typically involves attaching the backrest to the seat base and connecting the power components. Follow these general steps:

1. Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Attach the backrest to the seat base. Align the metal brackets on the backrest with the corresponding slots on the seat base. Push down firmly until it clicks into place.
3. Connect any internal wiring for the massage and heating functions, ensuring a secure fit.
4. Attach the power adapter to the chair's power input and then plug it into a standard wall outlet.
5. Test all functions (recline, massage, heat) to ensure proper operation.

## Operating Instructions

### Reclining Function

To recline the chair, locate the lever on the side of the chair (typically on the right). Pull the lever to release the footrest and lean back to achieve your desired reclining angle. To return to the upright position, push the footrest down with your legs until it locks into place, then lean forward. Note that closing the footrest may require some force.



Image: Close-up view of the recliner lever located on the side of the chair's armrest.

## Massage and Heating Functions

The chair features 8 massage points: 4 for the back, 2 for the thighs, and 2 for the legs. The integrated heating function is located in the backrest.

- **Power:** Press the 'POWER' button on the remote control to turn the massage and heating functions on or off.
- **Massage Modes:** Use the 'MODE' button to cycle through different massage patterns (e.g., Pulse, Press, Wave, Auto, Normal).
- **Intensity:** Adjust the massage intensity (High/Low) using the 'INTENSITY' button.
- **Targeted Massage:** Select specific massage areas (Back, Lumbar, Thigh, Leg) using the corresponding buttons.
- **Heating:** Press the 'HEAT' button to activate or deactivate the backrest heating function.
- **Timer:** Set a massage duration using the 'TIMER' button (e.g., 15, 30, 60 minutes).




Image: Diagram illustrating the 8 massage points on the chair and the functions of the remote control for massage and heating.

### Swivel and Rocking Function

The chair base allows for a 360-degree swivel motion and can also gently rock back and forth for added comfort.

## Maintenance and Care

- **Cleaning:** For the faux leather upholstery, wipe with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Do not use harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Retighten as necessary.
- **Storage:** If storing the chair, ensure it is in a dry, cool place away from direct sunlight.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Massage/Heating not working | Power cord unplugged; Remote control battery low; Internal wiring loose. | Check power connections; Replace remote batteries; Ensure internal wiring is secure. |
| Reclining mechanism stiff | Mechanism needs lubrication; Obstruction. | Apply silicone-based lubricant to moving parts (avoiding upholstery); Check for obstructions. |
| Footrest difficult to close | Designed to require force for secure closure. | Apply firm, consistent pressure with legs. This is a design feature to prevent accidental closure. |

## Specifications

- **Brand:** HOMCOM
- **Model Number:** IT700-094BG0631
- **Material:** Faux Leather (Cuir)
- **Color:** Beige
- **Overall Dimensions (Upright):** 97 cm (L) x 92 cm (W) x 104 cm (H)
- **Overall Dimensions (Reclined):** 166 cm (L) x 92 cm (W) x 84 cm (H)
- **Weight:** 45 kg
- **Maximum Weight Capacity:** 150 kg
- **Massage Points:** 8 (4 back, 2 thighs, 2 legs)
- **Heating Function:** Integrated in backrest
- **Features:** Reclining, Footrest, Massage, Heating, 360° Swivel, Rocking




Image: Diagrams showing the dimensions of the recliner chair in both upright and fully reclined positions.

## Warranty and Support

For warranty information, technical support, or replacement parts, please contact your retailer or the HOMCOM customer service department. Keep your purchase receipt as proof of purchase.