

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [IKEA](#) /
- › [IKEA BRIMNES Bookcase, White, Model 103.516.86 User Manual](#)

IKEA 103.516.86

IKEA BRIMNES Bookcase User Manual

Brand: IKEA | Model: BRIMNES (103.516.86)

1. INTRODUCTION

This manual provides essential information for the assembly, safe use, and maintenance of your IKEA BRIMNES Bookcase, Model 103.516.86. Please read these instructions carefully before beginning assembly and keep them for future reference.

The BRIMNES bookcase features adjustable shelves, allowing you to customize the storage space according to your needs. Its dimensions are 60 cm (width) x 35 cm (depth) x 190 cm (height), with a maximum load capacity of 25 kg per shelf.



Image: The IKEA BRIMNES Bookcase in white, showcasing its design and adjustable shelves.

2. SAFETY INFORMATION

WARNING: TIPPING HAZARD! Furniture that is not anchored can tip over. To prevent this, the furniture must be permanently attached to the wall with the included wall fastening device.

- Screws and wall plugs for wall mounting are **not included**. Wall materials vary, so use screws and wall plugs suitable for your specific wall type. Consult a professional if you are unsure.
- Do not overload shelves. The maximum load per shelf is 25 kg.
- Ensure the bookcase is placed on a level surface to prevent instability.

3. PACKAGE CONTENTS

Your BRIMNES Bookcase is delivered in 2 packages. Please verify that all components are present before beginning assembly. Refer to the separate assembly instructions for a detailed list of parts.

Main Materials:

- **Basic material:** Particleboard, Foil
- **Top panel:** Particleboard, Foil, ABS plastic
- **Back panel / Drawer bottom:** Fiberboard, Acrylic paint
- **Drawer front:** Fiberboard, Particleboard, Foil, ABS plastic

4. SETUP AND ASSEMBLY INSTRUCTIONS

This product requires assembly. Follow the detailed step-by-step instructions provided in the separate assembly guide included with your purchase. Ensure you have the necessary tools before starting.

1. Unpack all components and check against the parts list in the assembly guide.
2. Assemble the main frame of the bookcase according to the diagrams.
3. Insert the adjustable shelves into the desired positions.
4. **Crucial Step:** Secure the bookcase to the wall using the provided wall fastening device. Choose appropriate screws and wall plugs for your wall material (not included). This step is essential to prevent tipping and ensure safety.

5. OPERATING INSTRUCTIONS (USAGE)

The BRIMNES bookcase is designed for indoor use to store books, decorative items, and other household goods.

- **Adjusting Shelves:** The shelves are adjustable. To change their height, carefully remove the shelf, reposition the shelf supports to the desired holes, and then place the shelf back onto the supports.
- **Load Capacity:** Do not exceed the maximum load of 25 kg per shelf to maintain stability and prevent damage. Distribute weight evenly.
- **Placement:** Avoid placing the bookcase in direct sunlight or near heat sources to prevent material degradation.

6. MAINTENANCE

To keep your BRIMNES bookcase in good condition, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a cloth dampened in a mild cleaner. Then wipe dry with a clean, dry cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong solvents, or chemical polishes, as these can damage the surface finish.

- **Check Fastenings:** Periodically check all assembly fittings and wall fastenings and re-tighten them if necessary to ensure stability.

7. TROUBLESHOOTING

If you encounter issues with your BRIMNES bookcase, consider the following:

- **Instability:** Ensure the bookcase is on a level surface. Verify that all assembly screws are tightened and that the wall fastening device is securely installed.
- **Damaged or Missing Parts:** If you find any parts damaged or missing during unpacking, please contact the retailer or IKEA customer service with your product number (103.516.86) and proof of purchase.
- **Difficulty Adjusting Shelves:** Ensure shelf supports are correctly inserted into the holes. Do not force shelves into place.

8. SPECIFICATIONS

Feature	Detail
Brand	IKEA
Model Name	BRIMNES
Product Number	103.516.86
Color	White
Dimensions (W x D x H)	60 cm x 35 cm x 190 cm
Product Weight	25 kg
Max Load per Shelf	25 kg
Material	Particleboard, Foil, ABS plastic, Fiberboard, Acrylic paint
Finish Type	Painted finish
Mounting Type	Floor Mount (with wall fastening required)
Room Type	Home Office, Living Room
Shelf Type	Adjustable shelves
Designer	K Hagberg/M Hagberg

9. WARRANTY AND SUPPORT

Specific warranty information for this product is typically provided at the point of purchase or on the official IKEA website. Please retain your proof of purchase for any warranty claims.

For further assistance, missing parts, or detailed support, please contact IKEA customer service or the retailer from whom you purchased the product. Have your product number (103.516.86) ready when contacting support.

You can find more information and contact details on the official [IKEA website](#).

