Octane Seating SONIC-R4SLP-LM-BL

Octane Seating Sonic XS900 Power Recline Home Theater Seating User Manual

Model: SONIC-R4SLP-LM-BL

Sections

Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Setup and Assembly

This section provides instructions for the initial setup and assembly of your Octane Seating Sonic XS900 Home Theater Seating.

1.1 Unpacking

- Carefully remove all components from the packaging.
- Inspect all parts for any damage. Contact customer support immediately if any damage is found.
- Ensure all listed components are present before proceeding with assembly.

1.2 Assembly Instructions

The Sonic XS900 seating typically arrives in modular sections for easy assembly. Follow these general steps:

1. **Connect Seat Backs:** Align the metal brackets on the seat backs with the corresponding receivers on the seat bases. Slide the seat backs down firmly until they lock into place. You should hear an audible click.
2. **Connect Power Cables:** Locate the power cables extending from each seat base. Connect them to the corresponding power ports. Ensure all connections are secure.
3. **Connect Inter-Seat Cables (for multiple seats):** If you have multiple seats in a row, connect the inter-seat cables between adjacent seats. These cables synchronize the LED lighting and power functions.

4. **Positioning:** Place the assembled seating in your desired location. Ensure there is adequate space behind the seats for full recline operation (approximately 3-4 inches from a wall).
5. **Power Connection:** Plug the main power cord into a grounded electrical outlet.



Image: A four-seat Octane Sonic XS900 home theater seating unit in black leather, featuring blue LED lighting along the base and around the cupholders. Each seat has a removable tray table inserted into the accessory dock.

---

2. Operating Instructions

Familiarize yourself with the various functions of your Sonic XS900 seating for optimal comfort and convenience.

2.1 Power Recline

- Locate the power recline control buttons on the inner side of the armrest.
- Press and hold the **recline button** to extend the footrest and recline the backrest to your desired position.
- Press and hold the **upright button** to return the seat to its original position.
- Release the button at any point to stop the recline mechanism.

Your browser does not support the video tag.

Video: This video demonstrates the features of the Octane Seating Sonic XS900, including the power recline function, slim armrests, USB power switch, LED lighting system, and various lifestyle accessories.

2.2 USB Charging Port

- A USB charging port is integrated into the power recline control panel.
- Connect your compatible electronic devices to this port for convenient charging.

2.3 LED Ambient Lighting

- The seating features blue LED lighting around the cupholders and along the baserail.
- Locate the dedicated button on the control panel to turn the LED lighting on or off.

2.4 Accessory Dock

- Each armrest is equipped with an exclusive accessory dock.
- Insert compatible Octane Seating accessories (e.g., tray tables, wine glass holders, flex lights, popcorn bowls) into the dock. These accessories are sold separately.
- Ensure accessories are securely seated in the dock before use.

---

3. Care and Maintenance

Proper care will extend the life and appearance of your Octane Seating Sonic XS900.

3.1 Leather Care

- **Regular Cleaning:** Dust and vacuum the leather regularly to prevent dirt buildup. Use a soft, dry cloth.
- **Spot Cleaning:** For spills, immediately blot with a clean, dry cloth. Do not rub. For stubborn stains, use a mild leather cleaner specifically designed for top-grain leather. Test in an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or household detergents, as these can damage the leather.
- **Conditioning:** Apply a leather conditioner every 6-12 months to keep the leather supple and prevent drying or cracking.
- **Sunlight Exposure:** Avoid prolonged direct exposure to sunlight, which can cause fading and drying of the leather.

3.2 General Maintenance

- **Mechanism Check:** Periodically check all moving parts of the recline mechanism for smooth operation. Do not force the mechanism if it feels stiff.
- **Electrical Connections:** Ensure all power cables and connections remain secure and free from damage.
- **Weight Capacity:** Adhere to the recommended weight capacity per seat to prevent damage to the frame and recline mechanism.

---

4. Troubleshooting

This section addresses common issues you might encounter with your Sonic XS900 seating.

Problem	Possible Cause	Solution
Seat does not recline or return to upright position.	• Power cord unplugged. • Loose electrical connection. • Power outlet not functioning. • Mechanism obstruction.	• Ensure the main power cord is securely plugged into a working outlet. • Check all internal power connections between seat sections. • Test the outlet with another appliance. • Inspect beneath the seat for any objects obstructing the recline mechanism.

Problem	Possible Cause	Solution
LED lighting is not working.	• LED function turned off. • Loose connection.	• Press the LED control button to turn it on. • Check the power connections for the LED system.
USB port not charging devices.	• Power not connected to the seat. • Device incompatibility.	• Ensure the seat is powered on and connected to an electrical outlet. • Verify your device is compatible with standard USB charging.

If you continue to experience issues, please contact Octane Seating customer support.

5. Product Specifications

Below are the key specifications for the Octane Seating Sonic XS900 Home Theater Seating.

Feature	Detail
Brand	Octane Seating
Model Number	SONIC-R4SLP-LM-BL
Product Dimensions	39"D x 114"W x 43"H
Color	Black
Size	Row of 4 Seats Straight Row with Middle Loveseat
Fabric Type	100% Leather (Italian Top Grain Leather)
Form Factor	Recliner
Special Feature	Durable, Power Recline with USB, LED Lighting, Wellness Seating, Accessory Dock
Item Weight	404 pounds
Seat Height	21 Inches
UPC	841563111792

6. Warranty and Support

Octane Seating products are designed for quality and durability. For specific warranty details, please refer to the warranty card included with your product or visit the official Octane Seating website.

General Warranty Information:

- Warranty coverage typically includes manufacturing defects in materials and workmanship.
- Coverage duration may vary for different components (e.g., frame, recline mechanism, leather).

- Proof of purchase is usually required for warranty claims.

6.1 Customer Support

If you have questions, require assistance with assembly, or need to report an issue, please contact Octane Seating customer support:

- **Online Support:** Visit the Octane Seating Store on Amazon for FAQs and contact options.
- **Manufacturer Website:** Refer to the official Octane Seating website for comprehensive support resources.

When contacting support, please have your model number (SONIC-R4SLP-LM-BL) and proof of purchase readily available.

© 2023 Octane Seating. All rights reserved.