

[Manuals.plus](#) /

> [GROHE](#) /

> GROHE Minta Single-Lever Kitchen Sink Mixer with Pull-Out Spray, Chrome (Model 32321002) - User Manual

GROHE 32321002

GROHE Minta Single-Lever Kitchen Sink Mixer with Pull-Out Spray

Model: 32321002

User Manual

1. INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your GROHE Minta Single-Lever Kitchen Sink Mixer with Pull-Out Spray, Model 32321002. This kitchen mixer features a high C-shaped spout, 360° swivel range, a pull-out comfort shower head with two spray options, GROHE EasyDock system, SpeedClean silicone nozzles, and a GROHE SilkMove ceramic cartridge for precise control. The lustrous GROHE StarLight chrome finish ensures durability and easy cleaning.





Image 1.1: Front view of the GROHE Minta kitchen faucet in chrome finish.

2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Retain this manual for future reference.

- Ensure all water supply lines are turned off before beginning installation.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not use abrasive cleaners or harsh chemicals on the faucet finish, as this may damage the chrome.
- Check for leaks after installation and periodically thereafter.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation. Refer to the diagram below for identification.



DE: Änderungen vorbehalten / EN: Subject to Change / FR: Sous réserve de modifications / ES: Sujeto a cambios / IT: Soggetto a modifiche /
NL: Onder voorbehoud van eventuele wijzigingen / DK: Med forbehold for ændringer / PL: Temat do zmiany / GR: Υπόκειται σε αλλαγές /
RUS: Возможны изменения / UA: Можливі зміни / RO: Sub rezerva modificărilor ulterioare / PT: Sujeito a alterações

Image 3.1: Exploded view showing all components included in the GROHE Minta faucet package.

- Single-lever kitchen mixer body
- Pull-out spray head
- Flexible connection hoses
- Mounting hardware (washers, nuts, counterweight)
- Seals and O-rings
- Installation instructions

4. INSTALLATION INSTRUCTIONS

The GROHE Minta faucet features an Easy Installation System with flexible connection hoses for quick and hassle-free fitting. A single hole installation is required.

4.1. Preparation

1. Turn off the main water supply to your kitchen sink.
2. Remove your old faucet, if applicable. Clean the sink area thoroughly.
3. Ensure the mounting hole on your sink or countertop is compatible (minimum Ø34mm).

4.2. Faucet Mounting

1. Insert the flexible connection hoses and the threaded rod into the faucet body.
2. Place the faucet base seal onto the bottom of the faucet.
3. Insert the faucet into the mounting hole on the sink/countertop.
4. From underneath the sink, slide the rubber washer, metal washer, and mounting nut onto the threaded rod. Tighten the nut securely using the provided tool, ensuring the faucet is aligned correctly.

4.3. Water Connections

1. Connect the hot and cold flexible hoses to the corresponding water supply valves. Ensure a tight seal.
2. Attach the pull-out spray hose to the designated connection point on the faucet body.
3. Install the counterweight onto the pull-out spray hose, ensuring it allows for smooth retraction and extension of the spray head.

4.4. Final Steps

1. Slowly turn on the main water supply.
2. Check all connections for leaks.
3. Remove the spray head and flush the lines for a few minutes to clear any debris before reattaching the spray head.

- The GROHE SilkMove ceramic cartridge ensures smooth and precise control.

5.2. Pull-Out Spray Head

- Gently pull the spray head from the spout to extend it.
- The spray head offers two spray options: a powerful jet and a fine spray. Press the button on the spray head to switch between these modes.
- After use, the GROHE EasyDock system ensures the spray head retracts smoothly and effortlessly back into the spout.

5.3. Swivel Spout

- The high C-shaped spout has a 360° swivel range, allowing for flexible use across single or double sinks.



Image 5.1: The GROHE Minta faucet installed in a kitchen, demonstrating its high spout and design.

6. MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your GROHE Minta faucet.

6.1. Cleaning the Finish

- The GROHE StarLight chrome finish is designed for easy maintenance.
- Simply wipe the faucet down with a soft, dry cloth after each use to prevent water spots and maintain its luster.
- For deeper cleaning, use a mild soap solution and a soft cloth. Rinse thoroughly and dry immediately.
- **Do not use** abrasive cleaners, scouring pads, ammonia-based cleaners, or any harsh chemicals, as these can damage the chrome finish.

6.2. SpeedClean Nozzles

- The pull-out spray head features SpeedClean silicone nozzles.
- To remove limescale build-up, simply wipe the silicone nozzles with your finger or a soft cloth. This flexible material allows for easy removal of mineral deposits.

7. TROUBLESHOOTING

If you encounter issues with your faucet, refer to the following common solutions:

Problem	Possible Cause	Solution
Low water flow	Partially closed supply valves; clogged aerator/spray nozzles; debris in water lines.	Ensure supply valves are fully open. Clean spray head nozzles (SpeedClean). Flush water lines.
Leaks at connections	Loose connections; damaged seals.	Tighten connections. Inspect and replace seals if damaged.
Spray head does not retract fully	Counterweight improperly positioned; hose obstructed.	Adjust counterweight position. Check for obstructions under the sink that might impede hose movement.
Difficulty changing spray patterns	Limescale build-up in spray head.	Clean SpeedClean nozzles by wiping them.

If the problem persists after attempting these solutions, please contact GROHE customer support or a qualified plumber.

8. SPECIFICATIONS

Key technical details for the GROHE Minta Single-Lever Kitchen Sink Mixer (Model 32321002):

Feature	Detail
Brand	GROHE
Model Name	Minta
Model Number	32321002
Mounting Type	Deck Mount

Feature	Detail
Installation Type	Single Hole
Finish Type	Chrome (StarLight)
Material	Metal / Ceramic (Cartridge)
Number of Handles	1 (Single-Lever)
Special Feature	Pull Out Sprayer, 2 Spray Options, 360° Swivel Spout, EasyDock, SpeedClean
Cartridge Type	GROHE SilkMove Ceramic Cartridge (46mm)
Spout Height	185 mm
Hose Length	445 mm (Pull-out hose)
Maximum Flow Rate	9 Liters Per Minute
Product Dimensions	3.35"D x 8.27"W x 22.05"H (approx.)
Item Weight	2.2 pounds (approx.)



Image 8.1: The GROHE Minta faucet positioned between two sinks, highlighting its versatility.

9. WARRANTY AND SUPPORT

The GROHE Minta Single-Lever Kitchen Sink Mixer (Model 32321002) is backed by a **5-year manufacturer's warranty**.

For warranty claims, technical assistance, or further product information, please visit the official GROHE

website or contact their customer support directly. You can also find more information on the [GROHE Store on Amazon](#).

© 2025 GROHE. All rights reserved. Information in this manual is subject to change without notice.