

[Manuals.plus](#) /

› [KLARSTEIN](#) /

› Klarstein Barett Island Range Hood User Manual

KLARSTEIN TK15-Barett-WHd

Klarstein Barett Island Range Hood User Manual

Model: TK15-Barett-WHd

[Safety Instructions](#)

[Setup & Installation](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. SAFETY INSTRUCTIONS

Read all instructions carefully before installation and operation. Keep this manual for future reference.

- Ensure the power supply matches the rating label on the appliance.
- Installation must be performed by a qualified technician in accordance with local regulations.
- Do not operate the appliance if the power cord is damaged. Contact customer service for replacement.
- Always disconnect the appliance from the power supply before cleaning or maintenance.
- This appliance is for household use only. Do not use it for commercial purposes.
- Ensure adequate ventilation in the room when the range hood is used simultaneously with gas or other fuel-burning appliances.
- Do not flambé under the range hood.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. SETUP & INSTALLATION

The Klarstein Barett Island Range Hood is designed for ceiling mounting above freestanding cooking areas. Proper installation is crucial for optimal performance and safety.

2.1 Unpacking and Component Check

Carefully unpack all components and verify against the packing list. Ensure no parts are missing or damaged.

Your browser does not support the video tag.

Video: Empava 36 Inch Island Range Vent Hood 36RH10 Unboxing. This video demonstrates the unboxing process and shows the various components included with a similar island range hood. It provides a visual guide to help identify parts before installation.

Your browser does not support the video tag.

Video: Island Range Hood 36 Inch Ceiling Mount Installation. This video illustrates the installation steps for a ceiling-mounted island range hood, including marking, drilling, assembling the hanging rack, connecting the pipe, and fixing the duct covers. While the model may differ, the general installation principles are applicable.

2.2 Mounting the Ceiling Plate

1. Use the provided drill template to mark the drilling points on the ceiling.
2. Drill holes and insert expansion rubber plugs.
3. Attach the ceiling plate using the provided mounting material (screws and dowels). Ensure it is securely fastened.

2.3 Assembling the Support Frame

1. Assemble the hanging rack base to the ceiling cover using M4 screws.
2. Attach the P1 expansion hangers to the ceiling cover and P2 expansion hangers to the blower unit using M4 screws.

2.4 Ducting and Electrical Connection

1. Connect the aluminum pipe to the exhaust outlet of the range hood.
2. For ducted operation, ensure the pipe leads to an external vent. For recirculating operation, ensure activated carbon filters are installed.
3. Connect the power cord to the ceiling cable. This appliance requires a 220-240V ~ 50Hz power supply. No plug is available on the device; direct wiring is required.

2.5 Installing Duct Covers

1. Assemble the outer duct cover to the blower unit using M4 screws.
2. Embed and fix the inner duct cover using M4 screws.
3. Adjust the hanging height of the hood, maximum 140 cm, ensuring it is level and stable.



THE FOCAL POINT

Island hood for ceiling mounting
on freestanding hobs

Image: Installed Klarstein Barett Island Range Hood. This image shows the range hood fully installed above a cooking island, highlighting its modern design and how it integrates into a kitchen space.

3. OPERATING INSTRUCTIONS

The Klarstein Barett Island Range Hood features intuitive button controls and a digital display for easy operation.

3.1 Control Panel Overview



ALLES IM BLICK

Zuschaltbare LED-Kochflächenbeleuchtung (2 x 1 Watt) mit Lichteffizienzklasse A

Image: Control Panel. A close-up view of the touch control panel with a digital display, showing buttons for power, light, and fan speed adjustment.

- **On/Off Button:** Located on the front of the hood, press to power the unit on or off.
- **Fan Speed Control:** Three adjustable recirculation speeds (Low, Medium, High) to suit different cooking needs. The digital display indicates the selected speed.
- **Light Button:** Activates the integrated LED illumination for the cooking surface.

3.2 Fan Operation

- Press the On/Off button to start the fan at the lowest speed.
- Press the fan speed button repeatedly to cycle through the three available speeds (Low, Medium, High).
- The fan provides a maximum air circulation power of 560 m³/h, effectively removing steam and odors.

3.3 Lighting Operation

- Press the Light button to turn on the LED lights.

- The integrated LED hobs provide bright, white light over the stove, enhancing visibility during cooking.

4. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your Klarstein Barett Island Range Hood.

4.1 Cleaning the Aluminum Grease Filter



Image: Grease and Carbon Filters. This image displays the washable aluminum grease filter and the activated carbon filters, showing their placement and design for effective air purification.

- The aluminum grease filter is removable and washable.
- Clean the filter regularly (approximately every 2-4 weeks, depending on usage) to prevent grease buildup and maintain optimal suction.

- The filter can be washed by hand with warm soapy water or in a dishwasher. Ensure it is completely dry before re-installing.

4.2 Replacing Activated Carbon Filters

- For recirculating operation, the activated carbon filters (item reference 10030983) need to be replaced periodically.
- The frequency of replacement depends on usage, typically every 3-6 months.
- Refer to the specific instructions for replacing the activated carbon filters provided with the replacement filters.

4.3 Exterior Cleaning

- Clean the stainless steel exterior with a soft cloth and a non-abrasive cleaner designed for stainless steel.
- Avoid using harsh chemicals or abrasive materials that could scratch the surface.

5. TROUBLESHOOTING

If you encounter issues with your range hood, refer to the following troubleshooting guide before contacting customer service.

Problem	Possible Cause	Solution
Fan not operating	No power supply	Check power connection and circuit breaker.
Fan not operating	Control panel malfunction	Contact customer service.
Poor suction performance	Clogged grease filters	Clean or replace grease filters.
Poor suction performance	Saturated activated carbon filters (recirculating mode)	Replace activated carbon filters.
Poor suction performance	Improper installation or ducting issues	Verify installation according to instructions. Consult a technician if necessary.
Lights not working	Faulty LED lights	Contact customer service for replacement.

6. SPECIFICATIONS

Detailed technical specifications for the Klarstein Barett Island Range Hood.

- **Model:** TK15-Barett-WHd
- **Brand:** KLARSTEIN
- **Material:** Stainless Steel
- **Mounting Type:** Island Mount
- **Air Flow Capacity:** Max. 560 m³/h
- **Motor Power:** 190 W
- **Number of Speeds:** 3
- **Controls Type:** Touch
- **Light Source Type:** LED (2 x 1 Watt)

- **Energy Efficiency Class:** B
- **Filter Type:** Mesh Activated Carbon (Removable and washable aluminum grease filter, includes activated carbon filters)
- **Ventilation Type:** Ductless/Recirculating
- **Voltage:** 220-240V ~ 50Hz
- **Item Weight:** 16.9 Kilograms (approx. 37.2 pounds)
- **Product Dimensions:** Approx. 35 x 38 cm (ØxH) for hood body; Ceiling plate: approx. 35 x 2.5 cm (ØxH)
- **Adjustable Hanging Height:** Maximum 140 cm
- **Cable Length:** 180 cm

7. WARRANTY & SUPPORT

For warranty information, technical support, or to purchase replacement parts (e.g., activated carbon filters, item reference 10030983), please contact Klarstein customer service.

Note: This device comes with an EU licensed to the UK Converter plug attached. This is preinstalled for convenience before shipping.

Visit the official KLARSTEIN Store for additional product information and support:[KLARSTEIN Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07JYHVDRP>

More documents and user manuals: <https://manuals.plus/>