

Chicco 00079135720070

Chicco BravoFor2 Double Stroller Instruction Manual

Model: 00079135720070 (Iron)

INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Chicco BravoFor2 Standing/Sitting Double Stroller. Please read all instructions carefully before using the product and retain this manual for future reference. The Chicco BravoFor2 is designed to accommodate two children, featuring a traditional padded stroller seat for younger children and a bonus back seat and standing platform for older siblings.

SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always secure children in the harness system.
- Never leave children unattended in the stroller.
- Avoid serious injury from falling or sliding out. Always use the restraint system.
- Do not carry more than two children in the stroller.
- Ensure the stroller is fully unfolded and locked before placing children inside.
- Do not overload the storage basket or parent/child trays. Refer to specifications for weight limits.
- Engage brakes when parking the stroller.
- Keep hands clear of moving parts when folding or unfolding the stroller.

PACKAGE CONTENTS

Verify that all components are present before assembly:

- Stroller Frame with Forward Facing Seat
- 2 Removable Cup Holders
- Stroller Cover/Canopy

SETUP AND ASSEMBLY

Follow these steps to assemble your Chicco BravoFor2 Stroller:

1. **Unfolding the Stroller:** Grasp the integrated handle and lift the stroller until it clicks into the fully open position. Ensure all locking mechanisms are engaged.
2. **Attaching Wheels:** Insert the wheels into their designated slots until they click securely.
3. **Installing Canopy:** Attach the canopy to the stroller frame.
4. **Installing Child Tray:** Secure the child tray to the front seat.
5. **Installing Parent Tray:** Attach the parent tray to the handlebar.



Image: Chicco BravoFor2 Stroller partially assembled, illustrating the main seat and standing platform configuration.

Video: Official demonstration of the BravoFor2 Standing/Sitting Double Stroller, including assembly and feature overview.

OPERATING INSTRUCTIONS

Front Seat Operation

The front seat is designed for younger children. It features a padded seat, a five-point harness for security,

a large adjustable canopy for sun protection, and a removable child tray with two cup holders.

- **Harness Adjustment:** Adjust the five-point harness to fit your child snugly.
- **Canopy Adjustment:** The canopy can be adjusted to multiple positions or removed entirely.
- **Child Tray:** The child tray can be detached for easy child access or cleaning.



Image: The Chicco BravoFor2 Stroller configured with an infant car seat in the front and an older child seated on the rear platform.



Image: Close-up view of the child tray, highlighting its cup holders and snack space.

Rear Seat and Standing Platform

The rear of the stroller features a bonus seat and a standing platform for older children. The seat includes a three-point harness for safety and can be folded away when not in use to allow for standing. Easy-grip handles provide stability for standing children, and a backrest offers additional support.

- **Sitting:** Ensure the rear seat is unfolded and the child is secured with the three-point harness.
- **Standing:** Fold the rear seat away to create space for a child to stand on the platform, holding onto the easy-grip handles.



Image: The Chicco BravoFor2 Stroller in use, showing a younger child in the front seat and an older child standing on the rear platform.



Image: An older child comfortably seated in the rear seat of the Chicco BravoFor2 Stroller, secured by the harness.

Video: An overview of the BravoFor2 Stroller, demonstrating its features including the rear seat and standing platform.

Infant Car Seat Compatibility

The front stroller seat folds forward to securely accept any Chicco infant car seat with an easy click-in attachment. (Infant car seat sold separately).



Image: An infant car seat being securely attached to the front seat of the Chicco BravoFor2 Stroller.

Folding the Stroller

The BravoFor2 features a one-hand, ultra-compact quick fold for convenient maneuvering and storage. An integrated handle activates the fold and simultaneously rotates the front wheels inward, allowing the folded unit to stand independently. The fold handle also serves as a carry handle.



Image: Demonstration of the one-hand folding process for the Chicco BravoFor2 Stroller.



Image: The Chicco BravoFor2 Stroller shown in its compact, folded, and freestanding configuration.

Video: Official demonstration of the BravoFor2 Standing/Sitting Double Stroller, including the one-hand quick fold feature.

Parent Tray

The padded push-handle includes a parent tray with two cup holders, providing convenient storage for beverages and small personal items.



Image: Close-up view of the parent tray, featuring two cup holders and a zippered storage pouch for personal items.

Wheels and Brakes

The stroller is equipped with treaded rubber tires, full suspension, and front swivels to ensure a smooth ride. One-touch brakes keep the stroller securely in place when parked.

- **Brakes:** Press the brake pedal down to engage the brakes. Lift the pedal to release.
- **Front Swivel Wheels:** The front wheels can swivel for maneuverability or be locked for stability on uneven terrain.

MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your stroller.

- **Cleaning Fabric:** All fabric components are 100% Polyester. Hand wash only with mild soap and cold water. Do not use bleach. Air dry thoroughly.
- **Cleaning Frame:** Wipe the metal and plastic frame parts with a damp cloth and mild soap. Dry thoroughly.
- **Wheel Maintenance:** Regularly check wheels for debris and ensure they rotate freely. Lubricate axles if necessary.

- **Harness System:** Inspect the harness straps and buckles regularly for wear or damage.

TROUBLESHOOTING

If you encounter issues with your Chicco BravoFor2 Stroller, refer to the following common solutions:

Problem	Possible Cause	Solution
Stroller does not fold or unfold smoothly.	Locking mechanisms are not disengaged/engaged; debris in hinges.	Ensure all locks are released/engaged. Check for and remove any obstructions.
Wheels squeak or do not turn freely.	Dirt or debris in wheel axles; lack of lubrication.	Clean wheels and axles. Apply a silicone-based lubricant if needed.
Harness is difficult to buckle or unbuckle.	Buckle mechanism is dirty or misaligned.	Clean the buckle with a damp cloth. Ensure straps are not twisted.
Stroller pulls to one side.	Uneven weight distribution; locked swivel wheel; bent wheel.	Distribute weight evenly. Ensure front swivel wheels are unlocked. Check wheels for damage.

SPECIFICATIONS

- **Model Number:** 00079135720070
- **Item Weight:** 26.6 Pounds
- **Item Dimensions (L x W x H):** 45.7" x 23.3" x 42.8"
- **Folded Size:** 45.7" x 23.3" x 42.8" (Note: This appears to be the unfolded size, please refer to product for actual folded dimensions)
- **Maximum Weight Recommendation:** 40 Pounds (per seat/platform)
- **Seating Capacity:** 2
- **Front Harness Type:** 5-point
- **Rear Harness Type:** 3-point
- **Number of Cup Holders:** 2 (parent tray) + 2 (child tray)
- **Basket Weight Capacity Maximum:** 5 Pounds
- **Material Type:** Plastic, Metal, Polyester, Flat-Free Rubber, EVA
- **Fabric Type:** 100% Polyester
- **Color:** Iron
- **Manufacturer:** Artsana USA, Inc.



Image: A diagram illustrating the key dimensions of the Chicco BravoFor2 Stroller.

WARRANTY AND SUPPORT

Your Chicco BravoFor2 Stroller comes with a **1-year limited warranty** from the date of purchase. For warranty claims, product support, or to access the full user guide, please visit the official Chicco website or contact customer service.

You can also download the complete User Guide in PDF format [here](#).