

[Manuals.plus](#) /

› [3rd Avenue](#) /

› 3rd Avenue XF 3/4 Size Electric Guitar Starter Pack - Red Instruction Manual

3rd Avenue XF203CRDPK

3rd Avenue XF 3/4 Size Electric Guitar Starter Pack - Red

Instruction Manual

INTRODUCTION

Thank you for choosing the 3rd Avenue XF 3/4 Size Electric Guitar Starter Pack. This comprehensive kit is designed for aspiring musicians, offering a comfortable and accessible entry into playing the electric guitar. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new instrument and accessories.

PACKAGE CONTENTS

Your 3rd Avenue XF 3/4 Size Electric Guitar Starter Pack includes the following items:

- 3/4 Size Electric Guitar (Red)
- 10W Practice Amplifier with UK/EU compatible plug
- Instrument Cable
- Guitar Stand
- Carry Case (Gig Bag) for transport and storage
- Shoulder Strap
- Extra Set of Steel Strings
- 2 Guitar Picks
- Capo
- Tremolo Arm

Elgitarr i storlek 3/4

ST-design med sex stålsträngar




Figure 1: Complete Package Contents

This image illustrates all the components included in your starter pack, ensuring you have everything needed to begin playing.

GUITAR FEATURES AND DIMENSIONS

The 3rd Avenue XF electric guitar features an iconic ST-design, a C-shaped maple neck, and a polished redwood fretboard for comfortable playability. It is equipped with two single-coil pickups for versatile sound.

PAKETETS INNEHÅLL:



Figure 2: Guitar Dimensions and Features

This image provides a visual guide to the guitar's physical dimensions and highlights its 6-string configuration, suitable for ages 8-12.



Figure 3: Guitar Controls and Components

This close-up view details the guitar's controls, including the volume and tone knobs, 3-way pickup selector, fixed bridge, and strap buttons.

SETUP

1. Guitar Assembly

1. Attach the shoulder strap to the strap buttons located on the guitar body.
2. If desired, insert the tremolo arm into its designated slot on the bridge.

2. Amplifier Connection

1. Ensure the amplifier's power switch is in the 'OFF' position and the volume knob is set to minimum.
2. Connect one end of the instrument cable to the guitar's output jack.
3. Connect the other end of the instrument cable to the amplifier's input jack.

4. Plug the amplifier's power cord into a suitable UK/EU compatible electrical outlet.

3. Tuning the Guitar

Before playing, ensure your guitar is in tune. You can use a digital tuner (not included) or an online/app-based tuner. The standard tuning for a 6-string guitar from thickest to thinnest string is E-A-D-G-B-e.

- Turn the tuning pegs on the headstock to adjust the pitch of each string.
- The durable alloy tuning pegs with worm gear provide accurate tuning.

OPERATING INSTRUCTIONS

1. Playing the Guitar

- Hold the guitar comfortably, either seated or standing with the strap.
- Use the included picks to strum or pluck the strings.
- Press down on the strings against the frets with your fretting hand to produce different notes.

2. Amplifier Operation

1. Turn on the amplifier's power switch.
2. Slowly increase the amplifier's volume to your desired level.
3. Use the **Volume** knob on the guitar to control the guitar's output level.
4. Adjust the **Tone** knob on the guitar to modify the brightness of the sound.
5. Utilize the **3-way pickup selector** switch to choose between the neck pickup (warmer tone), bridge pickup (brighter tone), or both.
6. The amplifier features controls for **Volume**, **Treble**, and **Bass** to shape your sound.
7. Engage the **Overdrive** function on the amplifier for a distorted rock sound.
8. For silent practice, connect headphones to the amplifier's **Headphone Jack**.

MAINTENANCE

1. Cleaning

- Wipe down the guitar body and neck with a soft, dry cloth after each use to remove sweat and fingerprints.
- Periodically clean the fretboard with a specialized fretboard cleaner and conditioner.

2. String Replacement

Guitar strings wear out over time, affecting tone and playability. Replace strings when they become dull, corroded, or break.

1. Loosen the old strings using the tuning pegs.
2. Carefully remove the old strings from the bridge and tuning pegs.
3. Thread new strings through the bridge and wind them onto the tuning pegs.
4. Tune the new strings to the correct pitch. New strings will stretch, so re-tune frequently during the first few playing sessions.

3. Storage

When not in use, store your guitar in its included carry case to protect it from dust, humidity, and physical damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from amplifier	Amplifier not powered on; volume too low; cable not connected; guitar volume off.	Ensure amplifier is on and plugged in. Increase amplifier and guitar volume. Check all cable connections.
Guitar sounds out of tune	Strings are out of tune; new strings stretching.	Re-tune the guitar using a tuner. New strings require frequent re-tuning.
Buzzing sound when playing	Fingers not pressing strings firmly; string height too low; worn frets.	Ensure firm finger pressure. If buzzing persists, consult a guitar technician for string height adjustment or fret inspection.
Distorted sound (when not using overdrive)	Amplifier volume too high; faulty cable.	Reduce amplifier volume. Try a different instrument cable.

SPECIFICATIONS

Feature	Specification
Product Dimensions	91 x 30 x 4 cm
Item Weight	3 kg
Model Number	XF203CRDPK
Back Material	Poplar
Body Material	Alder
Color Name	Red
Connector Type	6.35 mm Jack
Fretboard Material	Redwood
Guitar Pickup Configuration	S (Single-coil)
Scale Length	60 centimeters
String Gauge	Light
String Material	Alloy Steel
Top Material	Poplar Wood
Number of Strings	6
Guitar Bridge System	Hardtail
Material Type	Laminated Poplar, Wood
Size	3/4 Size
Skill Level	Beginner

Feature	Specification
Neck Material Type	Maple
Hand Orientation	Right-handed

OFFICIAL PRODUCT VIDEO

Watch this video for a visual overview of the 3rd Avenue Junior electric guitar set for beginners, showcasing the guitar, amplifier, and other accessories.

Video 1: 3rd Avenue Junior Electric Guitar Set for Beginners

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official 3rd Avenue website. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question