



Manuals.plus /

› Shark /

› Shark NV70 Navigator Professional Upright Vacuum User Manual

Shark NV70

Shark NV70 Navigator Professional Upright Vacuum User Manual

Model: NV70

[Box](#) [Assembly](#) [Operation](#) [Safety Instructions](#) [What's in the](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be observed, including the following:

- Read all instructions before using this vacuum cleaner.
- Always unplug the vacuum cleaner from the electrical outlet before cleaning or servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If the vacuum cleaner is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run vacuum cleaner over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.

- Use extra care when cleaning on stairs.

WHAT'S IN THE BOX

Your Shark NV70 Navigator Professional Upright Vacuum includes the following components:

- Main Vacuum Unit
- Handle Assembly
- Hose
- Crevice Tool
- Dusting Brush
- Pet Upholstery Tool
- HEPA Filter (pre-installed)

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Shark NV70 Navigator Professional Upright Vacuum:

1. **Attach the Handle:** Insert the handle assembly into the top of the vacuum pod until it clicks securely into place.
2. **Connect the Hose:** Connect the flexible hose to the vacuum pod's hose connector. Ensure a tight fit.
3. **Attach Accessories:** Store the crevice tool, dusting brush, and pet upholstery tool on the onboard accessory posts for easy access.



Image: The main unit of the Shark NV70 Navigator Professional Upright Vacuum, showing its assembled form.

OPERATING INSTRUCTIONS

Powering On and Off

- Plug the power cord into a suitable electrical outlet.

- Press the Power button located on the vacuum pod to turn the unit ON or OFF.

Floor Type Selection

The NV70 features a versatile floor selector to optimize cleaning for different surfaces:

- **Hard Floor Setting:** For bare floors and delicate rugs. The brush roll will not spin in this mode.
- **Carpet Setting:** For deep cleaning carpets. The brush roll will activate to agitate carpet fibers.



Image: The Shark NV70 vacuum in use on a carpeted floor, demonstrating its cleaning capability.

Swivel Steering

The advanced swivel steering allows for easy maneuverability around furniture and obstacles. Gently turn the handle to steer the vacuum in the desired direction.



Image: The Shark NV70 vacuum pivoting smoothly on a rug, highlighting its swivel steering feature.

Using Attachments

The NV70 comes with several tools for specialized cleaning:

- **Crevice Tool:** Ideal for cleaning in tight spaces, corners, and along edges.
- **Dusting Brush:** Use for dusting delicate surfaces, blinds, and upholstery.
- **Pet Upholstery Tool:** Designed to remove pet hair and debris from upholstery and stairs.



Image: A close-up of the crevice tool attachment, useful for narrow spaces.



Image: A close-up of the dusting brush attachment, suitable for delicate surfaces.





Image: A close-up of the pet upholstery tool, designed for effective pet hair removal.



Image: A person using the pet upholstery tool to clean pet hair from a car's interior.



Image: A person extending the vacuum hose to clean high-reach areas like crown molding or ceilings.

Product Video

Your browser does not support the video tag.

Video: A demonstration of the Shark Navigator Professional Upright Vacuum's features, including its lightweight design, maneuverability, and extended reach for various cleaning tasks.

MAINTENANCE

Emptying the Dust Cup

Empty the dust cup after each use or when debris reaches the MAX FILL line.

1. Press the dust cup release latch and lift the dust cup off the vacuum pod.
2. Hold the dust cup over a trash bin and press the bottom release latch to open the bottom flap.
3. Close the flap and reattach the dust cup to the vacuum.

Cleaning Filters

Regularly clean the pre-motor and post-motor (HEPA) filters to maintain optimal suction power.

- **Pre-Motor Filters (Foam & Felt):** Rinse with water every 3 months or as needed. Allow to air dry completely before reinstalling.
- **Post-Motor HEPA Filter:** Rinse with water once a year or as needed. Allow to air dry completely before reinstalling.

Important: Do not operate the vacuum without all filters properly installed and completely dry.

Brush Roll Maintenance

Check the brush roll regularly for any hair, string, or debris that may be wrapped around it. Use scissors to carefully cut away any obstructions.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on.	Power cord not securely plugged in. No power at outlet.	Check plug. Check circuit breaker or try another outlet.
Vacuum does not pick up dirt.	Dust cup full. Filters need cleaning. Hose or nozzle blocked.	Empty dust cup. Clean filters. Check hose and nozzle for blockages.
Brush roll does not spin.	Brush roll is off (hard floor setting). Obstruction in brush roll.	Ensure carpet setting is selected. Remove any obstructions from brush roll.
Vacuum tips over easily when using hose.	Vacuum is top-heavy and base is narrow.	Exercise caution and keep the vacuum base stable when extending the hose for cleaning.

SPECIFICATIONS

Model: NV70

Brand: Shark

Power Source: Corded Electric

Voltage: 120 Volts

Wattage: 1200 watts

Capacity: 2.9 Quarts (Dust Cup)

Filter Type: Foam, Felt, HEPA

Item Weight: 15.2 Pounds

Special Features: Bagless, Swivel Steering, Anti-Allergen Complete Seal Technology, HEPA Filter

WARRANTY AND SUPPORT

This Shark NV70 Navigator Professional Upright Vacuum (Renewed) typically comes with a limited warranty. Please refer to your purchase documentation for specific warranty terms and duration.

For product support, troubleshooting assistance, or to inquire about replacement parts, please contact Shark customer service or the retailer from whom you purchased the renewed product.

Manufacturer Warranty Description: 90 days limited warranty (as per product data).



