Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KIIROO 54001470000

KIIROO Titan Interactive Vibrating Stroker User Manual

Model: 54001470000

1. Introduction

Welcome to the KIIROO Titan User Manual. This guide provides essential information for the safe and effective use, maintenance, and troubleshooting of your KIIROO Titan interactive vibrating stroker. Please read this manual thoroughly before first use and retain it for future reference.
The KIIROO Titan is an interactive vibrating stroker designed for male use. It features touch-sensitive vibration technology, a real-feel sleeve, and nine internal bullet vibrators for a dynamic experience. It can be used independently or connected to compatible interactive platforms for synchronized experiences.

2. Product Overview

The KIIROO Titan is engineered to provide an immersive experience with its advanced features:

- **Interactive Technology:** Connects to over 4,000 interactive videos across various content platforms, allowing you to feel every movement.
- **Real-Feel Sleeve:** Designed for realistic sensations.
- **Nine Bullet Vibrators:** Provides touch-sensitive vibration technology for varied intensity and patterns.
- **Standalone Use:** Offers multiple modes and speeds for individual enjoyment.
- **Partner Connectivity:** Capable of connecting to partners' devices for shared experiences from any location.



Figure 1: KIIROO Titan device and packaging.



Figure 2: Front view of the KIIROO Titan, showing the power button and control pads.

Your browser does not support the video tag.

Video 1: KIIROO Titan Intro Explainer. This video provides a brief overview of the KIIROO Titan's features and interactive

capabilities.

3. Setup

3.1. Charging the Device

Before first use, fully charge your KIIROO Titan. The device includes one Lithium Ion battery.

1. Locate the charging port on your KIIROO Titan.
2. Connect the provided USB charging cable to the device and a compatible USB power source (e.g., computer, wall adapter).
3. The indicator light will illuminate to show charging status. Refer to the device's specific light indicators for full charge notification (e.g., solid light, light changing color).
4. A full charge typically takes approximately 2-3 hours.

3.2. Initial Connection (Optional for Interactive Features)

To utilize the interactive features, you will need to connect your KIIROO Titan to a compatible device or platform.

1. Download the KIIROO app or visit a compatible interactive platform website.
2. Ensure your KIIROO Titan is charged and powered on.
3. Follow the on-screen instructions within the app or platform to pair your device via Bluetooth.
4. Once paired, the device is ready for interactive use.

4. Operating Instructions

4.1. Powering On/Off

- To power on: Press and hold the power button (usually indicated by a universal power symbol) for 2-3 seconds until the indicator light illuminates.
- To power off: Press and hold the power button for 2-3 seconds until the indicator light turns off.

4.2. Standalone Use

The KIIROO Titan offers various vibration modes and intensities for standalone use.

1. Power on the device.
2. Press the mode button (if available, or short press the power button) to cycle through different vibration patterns.
3. Use the intensity buttons (if available, or long press the mode/power button) to adjust the vibration strength.
4. Experiment with the different settings to find your preferred experience.

4.3. Interactive Use

For an enhanced experience, connect your KIIROO Titan to interactive content.

1. Ensure the device is paired with your chosen interactive platform (refer to Section 3.2).
2. Select interactive content (videos, live streams, partner connections) from the platform.
3. The KIIROO Titan will automatically synchronize with the content, providing haptic feedback.
4. Adjust intensity or patterns via the platform's interface if available.



Figure 3: The KIIROO Titan held in hand, demonstrating its ergonomic design for use.

5. Maintenance

5.1. Cleaning

Proper cleaning ensures hygiene and extends the lifespan of your KIIROO Titan.

- Always clean the device before and after each use.
- Use warm water and a mild, toy-safe soap or a specialized toy cleaner.

- Avoid using harsh chemicals, alcohol-based cleaners, or petroleum-based lubricants, as these can damage the material.
- Rinse thoroughly with clean water.
- Pat dry with a lint-free cloth or allow to air dry completely before storage.

5.2. Storage

Store your KIIROO Titan properly to maintain its condition.

- Store in a clean, dry, and dust-free environment.
- Keep away from direct sunlight and extreme temperatures.
- Store separately from other toys made of different materials to prevent material degradation or reactions.

6. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully (refer to Section 3.1).
Device does not turn on.	Power button not pressed correctly.	Press and hold the power button for 2-3 seconds.
Vibrations are weak or inconsistent.	Low battery.	Recharge the device.
Vibrations are weak or inconsistent.	Incorrect mode/intensity setting.	Adjust the mode and intensity settings (refer to Section 4.2).
Cannot connect to interactive platform.	Bluetooth not enabled or device not paired.	Ensure Bluetooth is on and re-pair the device (refer to Section 3.2). Check platform's connectivity guide.
Cannot connect to interactive platform.	Device is out of range.	Move the device closer to the connected computer or smartphone.

If you experience issues not covered here, please contact KIIROO customer support.

7. Specifications

Model Name	KIIROO Titan
Item Model Number	54001470000
Brand	KIIROO
Product Dimensions	4 x 4.5 x 11 inches
Item Weight	2.09 Pounds
Color	Black
Material	Acryl

Batteries	1 Lithium Ion battery (included)
Manufacturer	Kiiroo B.V
Style	Interactive

8. Warranty and Support

8.1. Warranty Information

KIIROO B.V. warrants this product against defects in materials and workmanship for a period of one (1) year from the date of original purchase. This warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear. Proof of purchase is required for all warranty claims.

8.2. Customer Support

For technical assistance, warranty claims, or general inquiries, please contact KIIROO customer support:

- **Website:** Visit the official KIIROO website for FAQs and support resources.
- **Email:** Refer to your product packaging or the official website for the most current support email address.
- **Online Store:** Visit the KIIROO Store on Amazon

Please have your model number (54001470000) and proof of purchase ready when contacting support.

© 2026 KIIROO B.V. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07K3G59G2

More documents and user manuals: **https://manuals.plus/**