

[manuals.plus](#) /› [Arzum](#) /› [Arzum AR683 Steampro 2002 Ceramic Soleplate Iron User Manual](#)

## Arzum AR683 Steampro 2002

# Arzum AR683 Steampro 2002 Ceramic Soleplate Iron User Manual

Model: AR683 Steampro 2002

## 1. INTRODUCTION AND IMPORTANT SAFETY INSTRUCTIONS

Thank you for choosing the Arzum AR683 Steampro 2002 Ceramic Soleplate Iron. To ensure safe and efficient operation, please read this manual carefully before first use and keep it for future reference.

### Safety Precautions:

- Always ensure the voltage indicated on the rating label corresponds to your mains voltage.
- Do not immerse the iron, power cord, or plug in water or any other liquid.
- Keep the iron out of reach of children and individuals with reduced physical, sensory, or mental capabilities.
- Unplug the iron from the power outlet before filling or emptying the water tank, and when not in use.
- Never leave a hot iron unattended.
- Use the iron on a stable, heat-resistant surface.
- Do not operate the iron if it has a damaged cord or plug, or if it has been dropped or damaged. Contact authorized service for repair.
- The soleplate can become extremely hot. Avoid direct contact with skin.

## 2. PRODUCT OVERVIEW

Familiarize yourself with the components of your Arzum AR683 Steampro 2002 iron:



*Image: The Arzum AR683 Steampro 2002 iron, featuring a red and black design. Key components visible include the ergonomic handle, the ceramic soleplate, the water tank cap, steam and spray buttons, and the temperature control dial.*

1. Water Inlet / Water Tank Cap
2. Spray Nozzle
3. Steam Button
4. Spray Button
5. Temperature Control Dial
6. Handle
7. Power Cord
8. Ceramic Soleplate
9. Water Level Indicator

### **3. SETUP AND FIRST USE**

#### **Before First Use:**

- Remove any labels or protective film from the soleplate.
- It is normal for a slight odor or smoke to occur during the first few minutes of use. This will dissipate quickly.
- To clean the soleplate, iron an old, damp cloth for a few minutes.

## Filling the Water Tank:

1. Ensure the iron is unplugged from the power outlet.
2. Set the steam control to the "dry ironing" position (no steam).
3. Open the water inlet cap.
4. Fill the water tank with clean tap water up to the "MAX" level indicator. Do not overfill.
5. Close the water inlet cap securely.

**Note:** For areas with hard water, it is recommended to use a mixture of 50% tap water and 50% distilled water to prevent limescale buildup.

## 4. OPERATING INSTRUCTIONS

---

### Temperature Setting:

- Refer to the garment's care label for recommended ironing temperature.
- Turn the temperature control dial to the desired setting.
- The indicator light will illuminate, indicating the iron is heating. It will turn off when the set temperature is reached.

### Dry Ironing:

1. Ensure the water tank is empty or the steam control is set to "dry ironing".
2. Plug in the iron and set the desired temperature.
3. Wait for the indicator light to turn off before beginning to iron.

### Steam Ironing:

1. Fill the water tank as described in the "Setup" section.
2. Plug in the iron and set the temperature control dial to a steam-appropriate setting (usually between "••" and "•••" or MAX).
3. Wait for the indicator light to turn off, indicating the iron has reached the correct temperature.
4. Adjust the steam button to the desired steam level.
5. Begin ironing.

### Spray Function:

Press the spray button to release a fine mist of water, which helps to dampen stubborn creases.

### Automatic Shut-Off (3-Way Safety):

For safety and energy saving, your iron is equipped with a 3-way automatic shut-off system:

- **Horizontal Position:** The iron will automatically turn off after approximately 25-30 seconds if left motionless on its soleplate.
- **Vertical Position:** The iron will automatically turn off after approximately 8-10 minutes if left motionless in its upright position.
- **Unused:** The iron will automatically turn off after 1 hour of inactivity.

When the iron automatically shuts off, an audible and visual warning will be provided. To restart the iron, simply move it slightly.

### Anti-Drip System:

The anti-drip system prevents water from dripping onto your garments when the iron's temperature is too low for steam production. This helps to avoid water stains.

## 5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your iron.

### Cleaning the Soleplate:

- Always ensure the iron is unplugged and completely cool before cleaning.
- Wipe the soleplate with a damp cloth and a non-abrasive cleaner.
- Do not use harsh scouring pads or abrasive cleaners, as these can damage the ceramic coating.

### Cleaning the Exterior:

Wipe the exterior of the iron with a soft, damp cloth. Dry thoroughly.

### Descaling (Anti-Calc):

To maintain optimal steam performance, descale your iron regularly, especially in hard water areas. Refer to the specific descaling instructions in your full product manual if available, or use a commercially available iron descaling solution following its instructions. Always ensure the iron is unplugged and cool before descaling.

### Storage:

- Unplug the iron and allow it to cool completely.
- Empty any remaining water from the tank.
- Store the iron in an upright position to protect the soleplate.
- Wrap the power cord neatly around the cord wrap area if available, or secure it with a tie.

## 6. TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Iron not heating up.	Not plugged in; power outlet fault; automatic shut-off activated.	Check power connection; test outlet with another appliance; move the iron to reactivate.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam control set to "dry"; limescale buildup.	Fill water tank; set temperature higher; adjust steam control; descale the iron.
Water dripping from soleplate.	Temperature too low for steam (anti-drip system working); water tank overfilled.	Increase temperature; do not overfill water tank.
White flakes coming from soleplate.	Limescale buildup.	Descale the iron. Use distilled water or a mix in hard water areas.

## 7. TECHNICAL SPECIFICATIONS

- **Model:** AR683 Steampro 2002
- **Power:** 2400 Watt
- **Voltage:** 220-240V~ (2.3E+2 Volt)
- **Soleplate:** Ceramic
- **Features:** Anti-Drip System, 3-Way Automatic Shut-Off
- **Cable Length:** 2 meters
- **Dimensions (approx.):** 41 x 33 x 34 cm
- **Weight (approx.):** 1.17 Kilogram

## 8. WARRANTY AND CUSTOMER SUPPORT

Your Arzum AR683 Steampro 2002 Ceramic Soleplate Iron is covered by a manufacturer's warranty.

Please refer to the warranty card included with your product for specific terms and conditions.

For technical assistance, spare parts, or service, please contact Arzum customer support or an authorized service center. Do not attempt to repair the appliance yourself.

### Related Documents - AR683 Steampro 2002

 A black Arzum SteamLux steam iron with a digital display and various buttons. The Arzum logo is on the left, and the model name is on the right. Technical specifications: 3000W, 2 years warranty.	<p><a href="#">Arzum SteamLux Steam Iron AR6052-16 User Manual</a></p> <p>Comprehensive user manual for the Arzum SteamLux Steam Iron, model AR6052-16. Includes instructions on usage, safety precautions, maintenance, and technical specifications.</p>
 A white Arzum GASTROART stand mixer with a large bowl and various attachments. The Arzum logo is on the left, and the model name is on the right. Technical specifications: 1500W, 2 years warranty.	<p><a href="#">Arzum GASTROART AR1190 Stand Mikser Kullanım Kılavuzu</a></p> <p>Bu kullanım kılavuzu, Arzum GASTROART AR1190 stand mikser (model AR1190-33, AR1190-54) için kapsamlı bilgiler sunar. Güvenlik talimatları, çalışma yönergeleri, bakım ipuçları ve teknik özellikler hakkında detaylı bilgi içerir.</p>
 A white Arzum Hestia Pro multi-blender set with various attachments. The Arzum logo is on the left, and the model name is on the right. Technical specifications: 2000W, 5 years warranty.	<p><a href="#">Arzum Hestia Pro AR1198 Multi Blender Set - User Manual &amp; Instructions</a></p> <p>Comprehensive user manual for the Arzum Hestia Pro AR1198 Multi Blender Set. Learn about its features, operation, safety precautions, cleaning, and warranty.</p>

 <p><b>arzum</b> VANESSA 43 W 3 YEAR WARRANTY LED Turkey</p>	<p><a href="#">Arzum VANESSA AR 5021 Hair Straightener User Manual and Safety Guide</a></p> <p>Comprehensive user manual for the Arzum VANESSA AR 5021 Hair Straightener. Learn about its features, how to use it safely, styling tips, cleaning instructions, technical specifications, and warranty information.</p>
 <p><b>arzum</b> OKKA RICH PRO PLUS <small>İLK KAHVE İÇİLEMEK İÇİN 10 DAKİKA BAKIN</small></p>	<p><a href="#">Arzum OKKA Rich Pro Plus Kullanım Kılavuzu - Türk Kahvesi Makinesi</a></p> <p>Arzum OKKA Rich Pro Plus Türk Kahvesi Makinesi kullanım kılavuzu. Cihazın güvenli kullanımı, özellikleri, modları, bakımı ve temizliği hakkında detaylı bilgiler içerir. Türkçe, İngilizce, Almanca, Fransızca, Rusça ve Arapça dillerinde sunulmaktadır.</p>
 <p><b>arzum</b> CRUST MIX JOY <small>1500 WATT 3 LİTRE 6 HIZLI</small></p>	<p><a href="#">Arzum Crust Mix Joy AR1188-02 Stand Mixer User Manual</a></p> <p>User manual for the Arzum Crust Mix Joy AR1188-02 stand mixer. Learn about its 1500W power, 6-speed settings, 5L stainless steel bowl, included accessories, safe operation, cleaning, and maintenance. Enhance your kitchen tasks with Arzum.</p>