Ikea ikea-koppla6

IKEA KOPPLA 6 Outlet Power Strip with Switch User Manual

Model: ikea-koppla6

Introduction

The IKEA KOPPLA 6 Outlet Power Strip with Switch is designed to provide convenient electrical access for multiple devices while allowing for easy power management. This power strip features six grounded outlets and an integrated switch to turn off all connected devices, helping to conserve energy. It is constructed from durable ABS plastic and polycarbonate plastic.


Safety Information

Please read and understand all safety instructions before using the power strip. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- For indoor use only. Do not expose to moisture or water.
- Do not exceed the maximum electrical rating of 250 Volts.
- Do not plug one power strip into another.
- Do not use with extension cords that are not properly grounded.
- Keep out of reach of children.
- Do not disassemble or modify the power strip. There are no user-serviceable parts inside.
- Ensure plugs are fully inserted into the outlets.

Product Overview

The IKEA KOPPLA power strip provides six grounded outlets for connecting your electronic devices. It features a prominent on/off switch that controls power to all connected outlets.



This image shows a close-up of the IKEA KOPPLA power strip, highlighting the red illuminated on/off switch and the design of the grounded outlets. The switch allows for convenient control over all connected devices.

The power strip is designed to be compact, measuring approximately 19 ¾ inches in length, making it suitable for various spaces.

Setup

Follow these steps to set up your IKEA KOPPLA power strip:

1. **Unpack:** Carefully remove the power strip from its packaging. Inspect for any signs of damage.
2. **Placement:** Choose a dry, indoor location away from water sources, heat, and direct sunlight. Ensure the power strip is placed on a stable surface.
3. **Connect to Wall Outlet:** Plug the power strip's cord into a standard, grounded wall outlet.
4. **Connect Devices:** Plug your electronic devices into the six available outlets on the power strip.



This image displays a single IKEA KOPPLA 6 outlet power strip, illustrating its compact design and the coiled power cord, ready for connection to a wall outlet.

Operating Instructions

Using the IKEA KOPPLA power strip is straightforward:

- **Power On:** Press the red switch to the 'ON' position. The switch will illuminate when power is supplied to the outlets.
- **Power Off:** Press the red switch to the 'OFF' position. This will cut power to all connected devices, allowing you to save energy when devices are not in use.
- **Connecting Devices:** Insert the power plugs of your electronic devices firmly into any of the six outlets.

Maintenance

To ensure the longevity and proper functioning of your IKEA KOPPLA power strip, follow these simple maintenance guidelines:

- **Cleaning:** Wipe clean with a dry cloth. Do not use liquid cleaners or abrasive materials. Ensure the power strip is unplugged from the wall outlet before cleaning.
- **Inspection:** Periodically inspect the power strip, cord, and plugs for any signs of damage, fraying, or loose connections. If any damage is observed, discontinue use immediately.
- **Storage:** When not in use, store the power strip in a dry, cool place, away from direct sunlight and moisture.



This image displays two IKEA KOPPLA 6 outlet power strips, providing a clear view of their white plastic casing and overall design, which facilitates easy cleaning and maintenance.

Troubleshooting

If you encounter issues with your IKEA KOPPLA power strip, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power to devices	Power strip switch is off Power strip not plugged in Wall outlet has no power Overload	Press the switch to the 'ON' position. Ensure the power strip is securely plugged into a working wall outlet. Check the wall outlet with another device or test the circuit breaker. Unplug some devices to reduce the load.

Problem	Possible Cause	Solution
Switch does not illuminate	No power to the power strip Faulty unit	Verify the power strip is plugged into a live wall outlet. If still no illumination, the unit may be faulty and should be replaced.
Devices intermittently lose power	Loose connection Overheating	Ensure all plugs are firmly seated in the outlets. Reduce the number of connected devices or move the power strip to a cooler location.

Specifications

Feature	Detail
Model Number	ikea-koppla6
Number of Outlets	6
Voltage	250 Volts
Special Feature	On And Off Switch
Material Type	ABS plastic, Polycarbonate plastic
Color	Grounded White
Size	19 ¾ inches (approx.)
Batteries Required	No
Manufacturer	IKEA

Warranty and Support

For information regarding warranty coverage or technical support for your IKEA KOPPLA power strip, please refer to the documentation provided at the time of purchase or visit the official IKEA website. Keep your proof of purchase for warranty claims.
If you have further questions or require assistance, please contact IKEA customer service.

© 2023 IKEA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question