

[manuals.plus](#) /

› [Best Choice Products](#) /

› [Best Choice Products 7.5ft Pre-Lit Snow Flocked Artificial Christmas Tree Instruction Manual \(Model SKY5090\)](#)

Best Choice Products SKY5090

Best Choice Products 7.5ft Pre-Lit Snow Flocked Artificial Christmas Tree

INSTRUCTION MANUAL - MODEL: SKY5090

1. Safety Instructions

- **Indoor Use Only:** This artificial Christmas tree is designed for indoor use. Do not use outdoors.
- **Electrical Safety:** Ensure all light connections are secure. Do not overload electrical outlets. Unplug the tree when not in use or before performing any maintenance.
- **Flocking Material:** The snow flocking may shed during initial setup and handling. It is recommended to assemble the tree in an area that can be easily cleaned. Avoid inhaling dust.
- **Stability:** Always ensure the tree is placed on a flat, stable surface and the metal stand is fully extended and locked to prevent tipping.
- **Children and Pets:** Keep small children and pets away from the tree during assembly and disassembly. Small parts or shedding flocking could pose a hazard.
- **Heat Sources:** Keep the tree away from direct heat sources, open flames, or heaters to prevent fire hazards.

2. Package Contents

Verify that all components are present before beginning assembly:

- Christmas Tree Sections (typically 3 sections for 7.5ft tree)
- Foldable Metal Stand
- Pre-attached Warm White Incandescent Lights

3. Setup Instructions

Follow these steps for easy assembly:

1. **Prepare the Area:** Choose a clear, flat space for your tree. Lay down a sheet or tarp to catch any shedding flocking during assembly.
2. **Assemble the Stand:** Open the foldable metal stand and ensure it is fully extended and stable.

Tighten any screws if necessary.

3. **Insert Bottom Section:** Carefully insert the largest tree section (bottom section) into the stand. Ensure it is firmly seated.
4. **Insert Middle Section:** Place the middle tree section onto the bottom section, aligning the poles.
5. **Insert Top Section:** Place the top tree section onto the middle section.
6. **Connect Lights:** Connect the light cords between each section. Ensure all connections are secure.
7. **Fluff the Branches:** Starting from the bottom, gently pull apart and shape each branch tip to create a full, natural appearance. This process may take 30-60 minutes for optimal results.
8. **Plug In:** Once fully assembled and fluffed, plug the tree into a standard electrical outlet.

7.5ft



52in

Image: The 7.5ft Pre-Lit Snow Flocked Artificial Christmas Tree with its dimensions (7.5ft height, 52 inches diameter).

4. Operating Instructions (Lights)

Your tree comes pre-lit with warm white incandescent lights. A foot pedal switch controls the light functions:

- **Steady On:** Provides a constant, warm white glow.
- **Twinkle:** Lights will gently twinkle, creating a dynamic effect.
- **Slow Glow:** Lights will slowly fade in and out.

Press the foot pedal repeatedly to cycle through these three light functions.



Image: Close-up view of the tree's branches with warm white twinkling lights.

3 Light Functions

LED lights switch between 3 different modes to provide variety for your tree's beautiful glow



Image: The foot pedal switch used to select between three distinct light functions.

5. Maintenance

- **Cleaning:** To clean the tree, gently dust the branches with a soft cloth or use a vacuum cleaner with a brush attachment on a low setting. Avoid using liquid cleaners, which can damage the flocking or electrical components.
- **Light Replacement:** The incandescent lights are replaceable. If a section of lights goes out, check for loose bulbs or fuses. Refer to the light string's specific instructions for bulb and fuse replacement.
- **Flocking Care:** While durable, excessive handling can cause flocking to shed. Handle branches gently during decoration and disassembly.

6. Storage

Proper storage ensures the longevity of your Christmas tree:

1. **Unplug and Disconnect:** Unplug the tree from the power outlet and disconnect all light connections between sections.
2. **Remove Decorations:** Carefully remove all ornaments and decorations.
3. **Compress Branches:** Gently compress the branches of each section back towards the center pole.

- Disassemble:** Separate the tree sections and remove the bottom section from the stand. Fold the stand for storage.
- Store in Original Box:** Store the tree sections and stand in the original packaging or a dedicated Christmas tree storage bag in a cool, dry place.

7. Troubleshooting

- Lights Not Working:**
 - Check if the tree is properly plugged into a working outlet.
 - Ensure all light connections between tree sections are securely fastened.
 - Inspect individual bulbs for looseness or breakage. Replace any faulty bulbs.
 - Check the fuses in the light string plug. Replace if blown (refer to light string instructions).
- Excessive Flocking Shedding:**
 - Some shedding is normal, especially during initial setup and handling.
 - Minimize excessive handling of flocked branches.
 - Clean up shed flocking with a vacuum cleaner.
- Tree Not Stable:**
 - Ensure the metal stand is fully opened and all legs are on a flat surface.
 - Verify that the tree sections are securely inserted into each other and the stand.

8. Specifications

Feature	Detail
Brand	Best Choice Products
Model Number	SKY5090
Height	7.5 feet (90 inches)
Diameter	52 inches
Material	Polyvinyl Chloride (PVC)
Color	Green (Snow Flocked)
Light Type	Pre-Lit Warm White Incandescent
Number of Lights	550
Number of Tips	1346
Assembly	Easy 3-section assembly
Base Type	Metal Stand
Item Weight	30.5 Pounds

9. Warranty and Support



For warranty information, product support, or to purchase replacement parts, please contact Best Choice


Products customer service directly. Refer to the contact information provided with your purchase or visit the official Best Choice Products website.

You can visit the Best Choice Products store online:[Best Choice Products Store](#)

© 2023 Best Choice Products. All rights reserved.

Related Documents - SKY5090


	<p>Best Choice Products Christmas Tree Instruction Manual - Version 9</p> <p>Comprehensive guide for assembling, fluffing, and maintaining Best Choice Products artificial Christmas trees. Includes safety warnings, parts identification, assembly steps for Type A and Type B trees, light replacement, cleaning, storage, and warranty information.</p>
	<p>Best Choice Products Christmas Tree Instruction Manual - Assembly and Care Guide</p> <p>Comprehensive instruction manual for Best Choice Products artificial Christmas trees. Covers assembly for Type A and Type B models, fluffing techniques, light repair, cleaning, storage, and important safety warnings. Includes details on product warranty and customer support.</p>
	<p>Best Choice Products Artificial Christmas Tree Instruction Manual</p> <p>Detailed instruction manual for assembling, fluffing, and maintaining Best Choice Products' snow flocked artificial pine Christmas trees. Includes safety guidelines, parts list, assembly steps for different types and sizes, light troubleshooting, and warranty information.</p>
	<p>Best Choice Products Artificial Christmas Tree Instruction Manual</p> <p>Comprehensive instruction manual for assembling, fluffing, and maintaining Best Choice Products artificial Christmas trees. Includes guidance on different tree sizes, types (Type A/B), light troubleshooting, cleaning, storage, and warranty information.</p>
	<p>Best Choice Products Christmas Wreath Instruction Manual - Assembly & Care Guide</p> <p>Comprehensive instruction manual for Best Choice Products Christmas Wreaths (24in to 60in). Learn how to assemble, fluff, clean, store, and care for your holiday wreath. Includes warranty and support information.</p>



[Best Choice Products Artificial Christmas Tree Instruction Manual](#)

Comprehensive instruction manual for Best Choice Products artificial Christmas trees, detailing assembly for Type A and Type B models, fluffing techniques, cleaning, storage, and warranty information. Covers various tree sizes from 4.5ft to 12ft.

Documents - Best Choice Products – SKY5090




[\[pdf\] Instructions Catalog](#)

SKY2818 Variations Instruction v7 INSTRUCTION MANUAL94be082f 51db 59f1 b714

4c0255573b13images thdstatic catalog Images 94 94be082f 4c0255573b13 |||


INSTRUCTION MANUAL Pre-Lit Artificial Hinged Ver. 7 Christmas Tree THIS
INSTRUCTION IS FOR THE FOLLOWING ITEMS: SKY2818 SKY2888 SKY3504
SKY3706 SKY4212 SKY4213 SKY4983 SKY4985 SKY4988 SKY4991 SKY4994
SKY5088 **SKY5090** SKY5092 SKY5094 SKY5095 SKY5096 SKY5456 SKY...
lang:en score:34 filesize: 2.83 M page_count: 8 document date: 2020-08-10



[\[pdf\] User Manual Instructions](#)

SKY2818 Variations Instruction v7 uzt6ysq4fbbsn2s5t5g images salsify image upload s ZQOpzcJP |||

INSTRUCTION MANUAL Pre-Lit Artificial Hinged Ver. 7 Christmas Tree THIS
INSTRUCTION IS FOR THE FOLLOWING ITEMS: SKY2818 SKY2888 SKY3504
SKY3706 SKY4212 SKY4213 SKY4983 SKY4985 SKY4988 SKY4991 SKY4994
SKY5088 **SKY5090** SKY5092 SKY5094 SKY5095 SKY5096 SKY5456 SKY...
lang:en score:32 filesize: 2.83 M page_count: 8 document date: 2020-08-10



[\[pdf\] User Manual Instructions Catalog](#)

SKY2818 2888 3706 4213 4983 4985 4988 4991 5088 5090 5094 5095 5096 5456 5459 5460 Instruction

v5 xd0rvftvxsgdixuby1r5 images salsify image upload s CFhxwcd |||

INSTRUCTION MANUAL Pre-Lit Artificial Hinged Christmas Tree Ver. 5 SKY2818
SKY2888 SKY3706 SKY4213 SKY4983 SKY4985 SKY4988 SKY4991 SKY5088
SKY5090 SKY5094 SKY5095 SKY5096 SKY5456 SKY5459 SKY5460 As shoppers,
we're always trying to find the perfect balance between qual...
lang:en score:29 filesize: 1.7 M page_count: 8 document date: 2019-05-06

