Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 201811050015-C

YING RAY Replacement Remote Control Instruction Manual

Model: 201811050015-C

1. Product Overview

This manual provides instructions for the YING RAY replacement remote control, designed for use with Fujitsu air conditioner models ASY14USACW and ASY13PSBCW. This remote control displays temperature in Celsius only.



Figure 1: YING RAY Replacement Remote Control. Note the "Display in Celsius" label at the bottom.

2. Setup

2.1 Battery Installation

The remote control requires two AAA 1.5V ordinary batteries (not included). Follow these steps to install them:

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Close the battery compartment cover securely.

Important: Ensure correct battery polarity. Do not mix old and new batteries, or different types of batteries.

3. Operating Instructions

This section describes the functions of the buttons on your remote control.



Figure 2: Overview of remote control buttons.

- **START/STOP:** Powers the air conditioner ON or OFF.
- **MASTER CONTROL:** Selects the operating mode (e.g., Cool, Heat, Dry, Fan, Auto). Press repeatedly to cycle through modes.
- **SET TEMP (+/-):** Adjusts the desired temperature setting. The display shows temperature in Celsius.

- **FAN CONTROL:** Adjusts the fan speed (e.g., Auto, Low, Medium, High). Press repeatedly to cycle through speeds.
- **SLEEP:** Activates or deactivates the Sleep mode, which adjusts temperature for comfortable sleep and energy saving.
- **TIMER:** Sets the ON/OFF timer for the air conditioner.
- **SET TIME:** Used in conjunction with the TIMER button to set specific ON/OFF times.
- **SET SWING (Left/Right Arrows):** Controls the horizontal airflow direction (swing).
- **SET SWING (Up/Down Arrows):** Controls the vertical airflow direction (swing).
- **TIME ADJUST:** Used for fine-tuning timer settings or setting the current time (if applicable to the specific AC unit).
- **ACL (All Clear):** Resets the remote control to factory default settings. Use a thin, pointed object (like a paperclip) to press this recessed button.

Note: The functionality of some buttons may vary slightly depending on the specific Fujitsu air conditioner model. Refer to your air conditioner's manual for detailed operation of advanced features.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's display becomes dim or unresponsive. Follow the battery installation steps in Section 2.1. Always replace both batteries simultaneously.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote.

5. Troubleshooting

- **Remote not responding:**
  - Check if batteries are installed correctly with proper polarity.
  - Replace old batteries with new AAA 1.5V batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner.
- **Display is dim or blank:**
  - Batteries may be low. Replace them.
- **Air conditioner not responding to specific commands:**
  - Some advanced functions may require specific settings on the air conditioner unit itself. Refer to your air conditioner's original manual.
  - Press the ACL button (using a thin object) to reset the remote control, then try again.

6. Specifications

Feature	Detail
Brand	YING RAY
Model Number	201811050015-C
Compatible Devices	Fujitsu Air Conditioners (ASY14USACW, ASY13PSBCW, 9307979033)

Connectivity Technology	Infrared
Controller Type	Button Control
Battery Type	2 x AAA 1.5V (not included)
Temperature Display	Celsius Only
Special Features	Ergonomic Design

7. Warranty and Support

Specific warranty information and direct customer support contact details for this replacement remote control are not provided in the product data. Please refer to the retailer or your purchase documentation for any applicable warranty or support inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07K6L3FR7

More documents and user manuals: **https://manuals.plus/**