Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 201811050004-C

YING RAY Replacement Remote Control for Fujitsu Air Conditioner (Model 201811050004-C) - Instruction Manual

Model: 201811050004-C

Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your YING RAY replacement remote control for Fujitsu Air Conditioners. This remote control is designed to replace original Fujitsu remote models such as ABY18FBBJ, ABY18UBBJ, ABY24FBBJ, ABY24UBBJ, ASY24UBBN, ASY30FBBJ, ABY30UBBJ, and AR-JW1. Please note that this remote displays temperature in Celsius only.

Product Overview

The YING RAY replacement remote control features an ergonomic design and button-based control for various air conditioner functions. It operates using AAA 1.5V ordinary batteries.



Figure 1: Front view of the YING RAY replacement remote control. Key buttons include SLEEP, TIMER, MASTER CONTROL, SET TEMP, SET TIME, FAN CONTROL, SET SWING, START/STOP, and a display area indicating "Display in Celsius".

Setup

1. Battery Installation

The remote control requires two (2) AAA 1.5V ordinary batteries (not included). Ensure correct polarity when inserting batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.

3. Insert two AAA batteries, matching the (+) and (-) terminals as indicated inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

Important: Remove batteries if the remote control will not be used for an extended period to prevent leakage.

Operating Instructions

This remote control is pre-programmed for compatible Fujitsu Air Conditioner models. No additional programming is typically required after battery installation.

Basic Functions:

- **START/STOP Button:** Press this orange button to turn the air conditioner ON or OFF.
- **MASTER CONTROL Button:** Cycles through various operating modes (e.g., Cool, Heat, Dry, Fan, Auto).
- **SET TEMP Buttons (+/-):** Adjusts the desired temperature. The display shows temperature in Celsius.
- **FAN CONTROL Button:** Adjusts the fan speed (e.g., Auto, Low, Medium, High).
- **SLEEP Button:** Activates or deactivates the sleep mode, which typically adjusts temperature and fan speed for comfortable sleep.
- **TIMER Button:** Used to set ON/OFF timers for the air conditioner.
- **SET SWING Buttons:** Controls the horizontal and vertical swing of the air conditioner's louvers.

Setting the Time:

Use the "SET TIME" button in conjunction with the temperature adjustment buttons (+/-) to set the current time. Refer to the air conditioner's main unit manual for specific timer programming details if needed.



Figure 2: Detail of the top section of the remote control, showing the SLEEP and TIMER buttons, the main display area, and the orange START/STOP button at the bottom.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote control's range decreases or the display becomes dim. Always replace both batteries simultaneously with new ones of the same type.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not responding.	Dead or incorrectly inserted batteries. Obstruction between remote and AC unit.	Check battery polarity and replace batteries. Ensure clear line of sight to AC unit's receiver.
Display is dim or blank.	Low battery power.	Replace batteries.
Air conditioner not responding to commands.	Remote control out of range. AC unit power off. Incompatibility.	Move closer to the AC unit. Check if the AC unit is powered on. Verify remote compatibility with your specific AC model.

Specifications

- **Model Number:** 201811050004-C
- **Compatible AC Models:** Fujitsu ABY18FBBJ, ABY18UBBJ, ABY24FBBJ, ABY24UBBJ, ASY24UBBN, ASY30FBBJ, ABY30UBBJ, AR-JW1
- **Display Unit:** Celsius Only
- **Power Source:** 2 x AAA 1.5V Batteries (not included)
- **Control Type:** Button Control
- **Special Feature:** Ergonomic Design
- **Manufacturer:** ZHUHAI YINGRAY TRADING CO., LTD.

Warranty Information

Specific warranty details for this YING RAY product are typically provided at the point of purchase or within the product packaging. Please retain your proof of purchase for any warranty claims. For general return policy, Amazon's standard 30-day return policy applies for refund/replacement.

Support

For further assistance or inquiries regarding your YING RAY replacement remote control, please contact the seller directly through the platform where the purchase was made. You may also refer to the original air conditioner's manual for detailed operational instructions specific to your Fujitsu unit.
Seller: YING RAY (via Amazon)

© 2024 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07K6L4LN4

More documents and user manuals: **https://manuals.plus/**