



[Manuals.plus](#) /

› [Audio Pro](#) /

› Audio Pro A10 MKII Wireless Multiroom Speaker User Manual

Audio Pro A10 MKII

Audio Pro A10 MKII Wireless Multiroom Speaker User Manual

Model: A10 MKII

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Audio Pro A10 MKII Wireless Multiroom Speaker. Please read this manual thoroughly before using your speaker to ensure optimal performance and longevity.

PRODUCT OVERVIEW

The Audio Pro A10 MKII is a compact, high-fidelity wireless multiroom speaker designed to deliver exceptional sound quality with deep bass and detailed highs. It supports various connectivity options including Bluetooth, WiFi, AirPlay 2, and a 3.5 mm audio cable input.



Figure 1: Audio Pro A10 MKII Wireless Multiroom Speaker.

Your browser does not support the video tag.

Video 1: A brief overview of the Audio Pro A10 MKII HiFi Portable Wifi Bluetooth Wireless Speaker.

Controls and Indicators




Figure 2: Top panel controls including LED indicator, source selection, volume, play/pause, Bluetooth pairing, and WiFi presets.

- **LED Indicator:** Displays status and connectivity.
- **Select Source:** Cycles through available input sources (WiFi, Bluetooth, AUX).
- **Volume Control:** Adjusts the speaker's output volume.
- **Play/Pause:** Controls media playback.
- **Pair Bluetooth:** Initiates Bluetooth pairing mode.
- **WiFi Presets (1-4):** Customizable buttons for quick access to favorite music or radio stations.

SETUP

To begin using your Audio Pro A10 MKII speaker, follow these steps for initial setup.

1. Download the Audio Pro Control App

The Audio Pro Control app is essential for setting up and managing your speaker, especially for WiFi and multiroom functionalities. It is available for both iOS and Android devices.

Control Audio Pro units with the *Audio Pro Control* app for iOS and Android.



Figure 3: Control your Audio Pro units with the Audio Pro Control app for iOS and Android.

Download the app here: [iOS App Store](#) | [Google Play Store](#)

2. Initial Power On and Network Connection

1. Connect the speaker to a power outlet using the provided power cable.
2. Open the Audio Pro Control app on your smartphone or tablet.
3. Follow the on-screen instructions within the app to connect your A10 MKII to your home WiFi network. The speaker supports both 2.4GHz and 5GHz bands.
4. Once connected, the speaker's LED indicator will confirm the network status.

OPERATING INSTRUCTIONS

Connectivity Options

- **WiFi:** For multiroom audio, AirPlay 2, Google Cast, and Spotify Connect. Offers higher fidelity and range than Bluetooth.

- **Bluetooth:** For direct connection from any Bluetooth-enabled device.
- **AUX (3.5 mm Audio Cable Input):** For wired connection to external audio sources.

Using AirPlay for Audio

AirPlay allows you to stream audio from your Apple devices to the A10 MKII speaker.

Your browser does not support the video tag.

Video 2: Instructions on how to use AirPlay to stream audio from Apple devices to your Audio Pro speaker.

Using Google Cast for Audio

Google Cast enables streaming audio from Android devices, Chromebooks, and Google Chrome on PC/Mac to your A10 MKII speaker.

Your browser does not support the video tag.

Video 3: Guide on how to use Google Cast to stream audio to your Audio Pro speaker.

Using Spotify Connect

Spotify Connect allows you to control music playback on your A10 MKII directly from the Spotify app on your device.

Your browser does not support the video tag.

Video 4: Instructions on how to use Spotify Connect with your Audio Pro speaker.

Additional features with Spotify Connect:

Your browser does not support the video tag.

Video 5: Explore three additional functionalities when using Spotify Connect with your Audio Pro speaker.

WiFi vs. Bluetooth

Understand the differences and advantages of WiFi and Bluetooth connectivity for your speaker.

Your browser does not support the video tag.

Video 6: A comparison between WiFi and Bluetooth connectivity for Audio Pro speakers, highlighting features and benefits.

Saving and Playing Presets

Presets allow you to quickly access your favorite music or radio stations. You can save presets directly on the speaker or through the Audio Pro app.

Your browser does not support the video tag.

Video 7: Learn how to save your favorite audio content as presets directly on your Audio Pro speaker.

Multiroom Functionality

The A10 MKII supports multiroom audio, allowing you to play music across multiple Audio Pro speakers simultaneously or individually. This feature is managed through the Audio Pro Control app.



Figure 4: Audio Pro A10 MKII speakers can be wall-mounted for multiroom audio setups.

Connecting a Turntable

You can connect a turntable to your Audio Pro speaker for vinyl playback. Ensure your turntable has a built-in or external RIAA amplifier if connecting via cables.

Your browser does not support the video tag.

Video 8: Instructions on how to connect a turntable to your Audio Pro speaker, either wired or wirelessly via Bluetooth.

MAINTENANCE

To keep your Audio Pro A10 MKII speaker in optimal condition, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surfaces. Avoid abrasive cleaners or solvents.
- **Placement:** Place the speaker on a stable surface, away from direct sunlight, heat sources, and moisture.
- **Ventilation:** Ensure adequate airflow around the speaker to prevent overheating.
- **Power:** Disconnect the power cable during electrical storms or when unused for extended periods.

Troubleshooting

If you encounter issues with your Audio Pro A10 MKII, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
No power	Power cable disconnected; power outlet not working.	Check power cable connection; try a different outlet.
No sound	Incorrect source selected; volume too low; device not connected.	Select correct input source; increase volume; re-establish connection (Bluetooth/WiFi).
Cannot connect to WiFi	Incorrect WiFi password; speaker too far from router; network interference.	Verify WiFi password; move speaker closer to router; restart router and speaker.
Bluetooth pairing fails	Speaker not in pairing mode; device already paired; interference.	Press and hold Bluetooth button to enter pairing mode; forget device on your phone and re-pair; ensure no other devices are connected.
Multiroom audio issues	Network congestion; app synchronization issues.	Ensure all speakers are on the same network; restart the Audio Pro app; check network stability.

For further assistance, please contact Audio Pro customer support.

Specifications

Feature	Detail
Model Name	Audio Pro A10 MKII Wireless Multiroom Speaker
Speaker Type	Multi Room
Special Feature	Bluetooth, WiFi, AirPlay2, Spotify Compatible
Recommended Uses	Indoor
Color	MKII Black
Product Dimensions	7.5"D x 5.5"W x 5.5"H
Item Weight	5.32 pounds (2.42 Kilograms)
Manufacturer	Audio Pro
Speaker Maximum Output Power	52 Watts
Connectivity Technology	Auxiliary, Bluetooth, WiFi
Mounting Type	Tabletop Mount (Wall mountable with separate bracket)
Material	Fabric, Plastic

Warranty and Support

Your Audio Pro A10 MKII speaker comes with a standard manufacturer's warranty. For specific details regarding warranty

coverage, duration, and terms, please refer to the warranty card included with your product or visit the official Audio Pro website. For technical support, troubleshooting assistance beyond this manual, or service inquiries, please contact Audio Pro customer support through their official channels. Contact information can typically be found on the Audio Pro website or within the product packaging.