

Ikea 902.990.91

Ikea VIDGA Ceiling Bracket (4-Pack) Instruction Manual

Model: 902.990.91

1. PRODUCT OVERVIEW

The Ikea VIDGA Ceiling Bracket is designed for mounting VIDGA curtain rails directly to the ceiling, providing a clean and seamless appearance without visible screws. This package includes four white ceiling brackets, each with a height of 7 mm.

These brackets are suitable for supporting single or triple curtain rails and can also be used to create room dividers with curtains or fabric. The installation process is straightforward, requiring only one screw per bracket for secure attachment.

2. SAFETY INFORMATION

- Always ensure that the ceiling material is suitable for drilling and can support the weight of the curtain rail and curtains.
- Use appropriate fasteners (screws, wall plugs) for your specific ceiling type. Fasteners are sold separately and are not included with the brackets.
- Exercise caution when using power tools for drilling. Wear appropriate safety gear, such as eye protection.
- Keep small parts away from children to prevent choking hazards.
- If unsure about installation, consult a qualified professional.

3. PACKAGE CONTENTS

The package contains the following items:

- 4 x VIDGA Ceiling Brackets (White)

Note: Mounting hardware (screws, wall plugs) is not included and must be purchased separately based on your ceiling material.

4. SETUP AND INSTALLATION

Follow these steps to install your Ikea VIDGA Ceiling Brackets:

- 1. Plan Placement:** Determine the desired location for your curtain rail. For a 140 cm long rail, two ceiling or wall brackets are typically needed. For longer rail systems, add one additional bracket for every 140 cm of rail length.
- 2. Mark Drill Points:** Hold the bracket against the ceiling at the planned installation point. Use a pencil to mark the single drill hole. Ensure the marks are aligned for multiple brackets.
- 3. Drill Holes:** Using an appropriate drill bit for your ceiling material, drill a hole at each marked point. If necessary, insert suitable wall plugs into the drilled holes.
- 4. Attach Bracket:** Place the bracket over the drilled hole(s) and secure it with a screw. Tighten the screw firmly but do not overtighten. The bracket is designed for easy mounting with just one screw.
- 5. Install Curtain Rail:** Once all brackets are securely installed, attach your VIDGA curtain rail to the brackets. The design allows for the rail to be fitted without visible screws, ensuring a clean finish.



Image 1: The Ikea VIDGA Ceiling Bracket in white, illustrating its compact design and the single attachment point for ceiling installation.

5. OPERATING

The VIDGA Ceiling Brackets serve as fixed support points for your VIDGA curtain rail system. Once installed, they provide a stable base for hanging curtains or fabric panels. There are no operational controls for the brackets themselves; their function is purely structural.

6. MAINTENANCE

To maintain the appearance and functionality of your ceiling brackets:

- **Cleaning:** Wipe the brackets with a damp cloth. A mild detergent can be used if necessary. Dry thoroughly with a clean cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the finish.
- **Regular Inspection:** Periodically check the screws for tightness to ensure the brackets remain securely fastened to the ceiling.

7. TROUBLESHOOTING

- **Bracket feels loose:**
 - Ensure the screw is tightened properly.
 - Verify that the correct type and size of wall plug (if used) were selected for your ceiling material.
 - Check for damage to the ceiling material around the drill hole. If damaged, consider relocating the bracket or using a larger wall plug.
- **Curtain rail sags:**
 - Ensure enough brackets are used for the length of the curtain rail. Add an additional bracket for every 140 cm of rail length.
 - Check that the curtain rail is correctly seated in all brackets.

8. SPECIFICATIONS

Brand	Ikea
Model Number	902.990.91
Color	White
Quantity per Pack	4 pieces
Height	7 mm
Material (Metal Part)	Aluminum, epoxy/polyester powder coating
Material (Plastic Fastening)	Reinforced polyamide plastic
Special Features	No visible screws after installation
Package Dimensions	15 x 5 x 3 cm
Package Weight	20 g

9. WARRANTY AND SUPPORT

For information regarding warranty, returns, or product support, please refer to the official Ikea website or contact Ikea customer service directly. Keep your purchase receipt as proof of purchase.

You can find more information and contact details on the official Ikea website: www.ikea.com

© 2026 Ikea. All rights reserved.