

[Manuals.plus](#) /

› [Dell](#) /

› Dell Precision 5810 Mid-tower Workstation User Manual

Dell Precision 5810

Dell Precision 5810 Mid-tower Workstation User Manual

Model: Precision 5810 with Intel Xeon E5-1620 v3 Processor

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Dell Precision 5810 Mid-tower Workstation. Please read these instructions carefully before using your workstation to ensure optimal performance and longevity.

The Dell Precision 5810 is a powerful mid-tower workstation designed for demanding professional applications. This particular model is equipped with an Intel Xeon E5-1620 v3 Quad-core processor and runs on Windows 7 Professional.

1. SETUP

1.1 Unpacking

Carefully remove the workstation and all accessories from the packaging. Ensure the following items are present:

- Dell Precision 5810 Mid-tower Workstation
- Power Cable
- Keyboard
- Documentation (this manual)

Retain the packaging for future transport or service needs.

1.2 Connecting Peripherals

Before powering on, connect your essential peripherals:

1. **Monitor:** Connect your monitor to one of the available video output ports (HDMI or DisplayPort) on the graphics card.
2. **Keyboard:** Connect the included keyboard to an available USB port.
3. **Mouse:** Connect your mouse to an available USB port.
4. **Network:** For internet access, connect an Ethernet cable to the network port or ensure Wi-Fi is configured after

initial setup.

5. **Power:** Connect the power cable to the workstation's power supply and then to a grounded electrical outlet.




Figure 1: Front view of the Dell Precision 5810 Workstation, showing various ports and the optical drive.

The image above displays the front of the Dell Precision 5810 Mid-tower Workstation. It highlights the accessible ports and the optical drive bay, which are crucial for connecting external devices and media during the setup process.

1.3 Initial Power-On

Once all peripherals are connected:

- Press the power button located on the front of the workstation.
- The system will boot into Windows 7 Professional. Follow any on-screen prompts for initial operating system setup, if applicable.

2. OPERATION

2.1 Power On/Off

- **To Power On:** Press the power button.
- **To Shut Down:** Click the "Start" button in Windows, then select "Shut Down."
- **To Restart:** Click the "Start" button, then select "Restart."
- **To Sleep:** Click the "Start" button, then select "Sleep."

2.2 Operating System

Your workstation comes pre-installed with **Windows 7 Professional**. Familiarize yourself with the Windows interface for managing files, installing software, and configuring system settings.

2.3 Connectivity

The Dell Precision 5810 offers various connectivity options:

- **USB Ports:** Multiple USB ports are available for connecting external devices such as storage drives, printers, and other peripherals.
- **Video Outputs:** HDMI and DisplayPort are available for connecting to monitors or projectors.
- **Ethernet:** A dedicated Ethernet port provides wired network connectivity.
- **Bluetooth:** Integrated Bluetooth allows for wireless connection to compatible devices.
- **Wi-Fi:** Wireless network connectivity is supported.

3. MAINTENANCE

3.1 Cleaning

- **Exterior:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to clean the exterior surfaces. Avoid harsh chemicals.
- **Ventilation:** Periodically check and clean the ventilation grilles to ensure proper airflow. The system uses air cooling, and blocked vents can lead to overheating. Use compressed air to gently clear dust from vents.

3.2 Software Updates

Regularly update your operating system and drivers to ensure system stability, security, and optimal performance. Windows Update can manage OS updates, and Dell's support website provides driver updates for your specific model.

3.3 Data Backup

It is highly recommended to regularly back up your important data to an external drive or cloud storage to prevent data loss in case of hardware failure or other unforeseen issues.

4. TROUBLESHOOTING

This section addresses common issues you might encounter. For more complex problems, refer to Dell's official support resources.

4.1 No Power

- Ensure the power cable is securely connected to both the workstation and the electrical outlet.
- Verify the electrical outlet is functional by plugging in another device.
- Check the power supply unit (PSU) status indicator, if available.

4.2 No Display

- Confirm the monitor is powered on and connected correctly to the workstation's video output port.
- Ensure the correct input source is selected on your monitor.
- If using multiple monitors, try connecting only one.

4.3 Slow Performance

- Close unnecessary applications running in the background.
- Check for sufficient free space on your hard drive.
- Run a virus scan to check for malware.
- Ensure your operating system and drivers are up to date.
- Consider adding more RAM if performance issues persist during demanding tasks.

5. SPECIFICATIONS

Key technical specifications for the Dell Precision 5810 Mid-tower Workstation:

Feature	Detail
Brand	Dell
Model Name	Precision 5810 Workstation
Processor	Intel Xeon E5-1620 v3 (Quad-core, 3.5 GHz)
RAM	8 GB DDR4 SDRAM
Storage	HDD (Hard Disk Drive)
Graphics Card	Nvidia Quadro K620 (Dedicated, GDDR5)
Operating System	Windows 7 Professional
Optical Drive	DVD
Connectivity	Ethernet, HDMI, USB (6 total), Bluetooth, Wi-Fi
Video Output	HDMI, DisplayPort
Dimensions (H x W x D)	16.3 x 6.8 x 18.5 inches (approx.)
Weight	37.15 Pounds (approx.)

6. WARRANTY & SUPPORT

6.1 Warranty Information

This Dell Precision 5810 Workstation comes with a**90-day limited warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms and conditions, please refer to the warranty documentation provided with your purchase or contact your reseller.

As a Certified Refurbished product, it is tested and certified to look and work like new. The refurbishing process includes functionality testing, basic cleaning, inspection, and repackaging.

6.2 Technical Support

For technical assistance, driver downloads, or further troubleshooting, please visit the official Dell Support website or contact Dell customer service. Have your service tag or express service code ready when contacting support.

Dell Support Website: www.dell.com/support

© 2024 Dell Inc. All rights reserved. Dell and the Dell logo are trademarks of Dell Inc.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07K6V264T>

More documents and user manuals: <https://manuals.plus/>