

Simple Houseware B07K6VC617

Simple Houseware Under Shelf Basket (White, 1 Pack)

Model: B07K6VC617 | Brand: Simple Houseware

INTRODUCTION

Thank you for choosing the Simple Houseware Under Shelf Basket. This product is designed to help you maximize unused vertical space in your cabinets, pantries, and other shelving units, providing convenient extra storage. Its durable steel construction ensures reliable, long-lasting use. Please read this manual carefully to ensure proper installation and optimal use of your new under-shelf basket.

SAFETY INFORMATION

- Do not overload the basket. Exceeding the recommended weight capacity may cause damage to the basket or the shelf it is attached to.
- Ensure the basket is securely attached to the shelf before placing items inside.
- Keep out of reach of small children to prevent accidental injury.
- Avoid placing sharp or pointed objects that could damage the wire frame or stored items.

PACKAGE CONTENTS

- 1 x Simple Houseware Under Shelf Basket (White)

SPECIFICATIONS

Feature	Detail
Color	White
Material	Metal

Product Dimensions (L x W x H)	11.25" x 12.5" x 5.5"
Sliding Arms Dimensions (D x H)	6.75" x 1"
Item Weight	0.62 Kilograms
Finish Type	Powder Coated
Compatibility	Designed to fit most standard shelves

SETUP AND INSTALLATION

The Simple Houseware Under Shelf Basket offers quick and easy setup with no tools required. Follow these steps for installation:

- 1. Measure Your Shelf:** Before installation, ensure your cabinet shelf meets the minimum required space for the basket. The sliding arms are 6.75"D x 1"H, designed to fit most standard shelves.
- 2. Slide On:** Simply slide the basket's arms onto the underside of your desired shelf. Ensure the arms are fully extended and securely gripping the shelf for stability.
- 3. Verify Stability:** Gently tug on the basket to confirm it is firmly in place and does not wobble.




Figure 1: Product Dimensions and Shelf Compatibility. Measure your cabinet shelf before purchase.



Figure 2: Simple slide-on installation process.

USAGE INSTRUCTIONS

The Simple Houseware Under Shelf Basket is a versatile organizer designed to maximize space in various areas of your home or office. Here are some common uses:

- **Kitchen Pantry:** Store food wraps, napkins, small kitchenware, snacks, or spices.
- **Cabinets:** Organize cleaning supplies, small appliances, or extra dishes.
- **Bathroom:** Hold hand towels, toiletries, or other bathroom accessories.
- **Closet:** Store folded clothing items like t-shirts, socks, or accessories.
- **Office/Desk:** Keep office supplies, notebooks, or small electronics tidy.

By utilizing the space beneath existing shelves, you can instantly create additional storage without the need for permanent fixtures or complex installations.



Figure 3: Example of pantry organization with under shelf baskets.



Figure 4: Example of office desk organization with an under shelf basket.

CARE AND MAINTENANCE

To keep your Simple Houseware Under Shelf Basket in optimal condition:

- Wipe clean with a damp cloth and mild soap.
- Dry thoroughly after cleaning to prevent rust.
- Avoid using abrasive cleaners or scouring pads, as these may damage the powder-coated finish.

TROUBLESHOOTING

- **Basket feels unstable:** Ensure the sliding arms are fully pushed onto the shelf and the shelf thickness is within the compatible range (maximum 1 inch).
- **Items falling out:** Do not overload the basket. Distribute weight evenly and ensure items are not taller than the basket's sides.
- **Difficulty sliding onto shelf:** Check if the shelf thickness exceeds 1 inch. The basket is designed for standard shelf thicknesses up to 1 inch.

WARRANTY AND SUPPORT

Simple Houseware products are designed for durability and satisfaction. For any questions, concerns, or warranty information, please contact Simple Houseware customer support through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.