

[Manuals.plus](#) /

> [MYMAHDI](#) /

> Mymahdi MP3/MP4 Portable Player User Manual

MYMAHDI M230-Silver-New

Mymahdi MP3/MP4 Portable Player User Manual

Model: M230-Silver-New

1. INTRODUCTION

The Mymahdi MP3/MP4 Portable Player is a versatile and compact device designed for entertainment and learning on the go. It supports various functions including music playback, photo viewing, e-book reading, voice recording, and FM radio. Its slim design and long battery life make it an ideal companion for travel, exercise, or daily commutes.

This player is designed to be user-friendly and supports expandable storage up to 64GB via a TF/Micro SD card (not included).



Figure 1: Mymahdi MP3/MP4 Portable Player showcasing multiple color options.

2. SETUP

2.1 Package Contents

Before you begin, please ensure all items are present in the package:

- 1x Mymahdi Music Player
- 1x USB Cable
- 1x Earphones
- 1x User's Manual (this document)
- 1x After-sale Card
- 1x High Valued Gift Box



Figure 2: Included accessories: player, USB cable, earphones, manual, and gift box.

2.2 Charging the Device

Connect the player to a USB power source (e.g., computer USB port or a USB wall adapter) using the provided USB cable. The device charges in approximately 3 hours when powered on. A full charge provides up to 40 hours of usage.

2.3 Inserting a TF/Micro SD Card

The player requires a TF/Micro SD card for storing music, videos, photos, and e-books. Locate the card slot on the device and gently insert the card until it clicks into place. The player supports cards up to 64GB.

The most intimate gift for the elderly and children

Small and exquisite MP3 can be carried at any time, the old man listens to FM radio, for children learn language, listen to music or watch movies, it 's a greatl gift for the elderly and children



Figure 3: Illustrates the insertion of a TF/Micro SD card into the player.

2.4 Transferring Files

To transfer music, videos, photos, or e-books, connect the player to your computer using the USB cable. The device will appear as a removable disk. Simply copy and paste your desired files directly onto the TF/Micro SD card within the player's storage. For video files, AMV and AVI formats are supported, but AVI may require a conversion tool (resolution 128x160).

3. OPERATING INSTRUCTIONS

3.1 Basic Navigation

The player features a central navigation pad with "MENU", "VOL", and directional buttons (left, right, up, down, play/pause). The "MENU" button typically returns to the previous screen or main menu. The "VOL" button, when held down, allows volume adjustment; otherwise, it may function as a back button.

3.2 Music Playback

From the main menu, select the "Music" icon. Navigate through your folders and select a song to play. Supported audio formats include MP3 (MP1, MP2, MP3), WMA, OGG, WAV, APE, FLAC, AAC-LC, ACELP. For APE and FLAC, requirements are 8KHz-48KHz, 1000Kbps.

One key high-definition recording

Innovative design concept, a portable one-touch switch, fast recording



Figure 4: The player is suitable for listening to music during physical activities.

3.3 Photo Viewer

Select the "Photo" icon from the main menu to browse images stored on your TF card.

3.4 E-book Reader

Access the "E-book" function to read text files. You can watch the books you would like at anytime and anywhere.

Listening to music while exercising

Portable sports MP3, listening to music while exercising, to meet the requirements of your life



Figure 5: The player can be used as an e-book reader.

3.5 Voice Recorder

The player includes a voice recording feature. Select the "Voice Recorder" icon to start recording audio. It offers one-key high-definition recording.

The most intimate gift for the elderly and children

Small and exquisite MP3 can be carried at any time, the old man listens to FM radio, for children learn language, listen to music or watch movies, it 's a greatl gift for the elderly and children



Figure 6: The player's interface for voice recording.

3.6 FM Radio

Tune into your favorite FM radio stations. The player supports preset stations, manual tuning, and auto tuning across various radio frequency bands.



FM radio function

Preset stations, manual tuning, auto tuning, radio frequency bands, etc. With it, your life is no longer lonely.

Figure 7: Visual representation of the FM radio function with frequency indicators.

3.7 Video Playback

The player supports AMV and AVI video formats. For AVI files, a conversion tool may be required to ensure compatibility and optimal playback at a resolution of 128x160.

3.8 Language Settings

The device supports multiple languages including English, German, French, Italian, Dutch, Portuguese, Spanish, Russian, Hebrew, and more. Navigate to the settings menu to change the display language.

Your browser does not support the video tag.

Video 1: An official product video demonstrating various features and functions of the Mymahdi MP3/MP4 player, including its multi-lingual selection and portability.

4. MAINTENANCE

4.1 Cleaning

Wipe the device with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as they may damage the screen or casing.

4.2 Storage

Store the player in a cool, dry place away from direct sunlight and extreme temperatures. When not in use for extended periods, ensure the battery is partially charged (around 50%) to prolong its lifespan.

4.3 Battery Care

To maintain optimal battery performance, avoid fully discharging the battery frequently. Charge the device regularly, even if not in constant use.

5. TROUBLESHOOTING

If you encounter issues with your Mymahdi MP3/MP4 Player, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or device is off.	Charge the device for at least 3 hours. Ensure the power switch (if present) is in the ON position.
Cannot transfer files to the device.	No TF/Micro SD card inserted or card not recognized.	Ensure a TF/Micro SD card is properly inserted. Try re-inserting the card or using a different card. Ensure the device is connected correctly to the computer.
Poor sound quality or no audio.	Faulty earphones or incorrect audio settings.	Try using a different pair of earphones. Check the volume level on the device. Ensure audio files are not corrupted.
Buttons are unresponsive or behave unexpectedly.	Software glitch or unfamiliarity with controls.	Restart the device. Familiarize yourself with the button functions; for example, the "VOL" button may also serve as a "back" button if not held down for volume control.
Video files do not play.	Unsupported video format or resolution.	Ensure video files are in AMV or AVI format. If AVI, confirm they are converted to 128x160 resolution using a compatible tool.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	3.54 x 1.57 x 0.39 inches
Item Weight	3.52 ounces
Screen Size	1.8 Inches LCD
Memory Storage Capacity	Max 64 GB (via TF/Micro SD card)
Battery Type	1 Lithium Ion battery (included)
Battery Life	Up to 40 hours after full charge

Feature	Detail
Charging Time	Approximately 3 hours
Connectivity Technology	USB
Supported Audio Formats	MP3 (MP1, MP2, MP3), WMA, OGG, WAV, APE, FLAC, AAC-LC, ACELP
Supported Video Formats	AMV, AVI (128x160, may require conversion)
Media Type	Micro SD, Micro SDHC
Special Features	FM Radio, Voice Recorder, E-book Reader, Photo Viewer
Supported Languages	English, German, French, Italian, Dutch, Portuguese, Spanish, Russian, Hebrew, etc.

7. WARRANTY AND SUPPORT

The Mymahdi MP3/MP4 Player comes with a 12-month warranty. For any product inquiries, technical support, or warranty claims, please refer to the contact information provided on the included After-sale Card or visit the official MYMAHDI store on Amazon: [MYMAHDI Store](#).

We pride ourselves on friendly and prompt customer service.

