**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**YING RAY 2018110625-F**

# YING RAY Replacement Fujitsu Air Conditioner Remote Control User Manual

Model: 2018110625-F

## Introduction

This manual provides detailed instructions for the proper use and maintenance of your YING RAY Replacement Remote Control for Fujitsu Air Conditioners. Please read this manual thoroughly before operating the remote control to ensure correct usage and to maximize its lifespan. This remote control is designed to operate specific Fujitsu air conditioner models and displays temperature exclusively in Fahrenheit.

## Product Overview

The YING RAY Replacement Remote Control is a direct replacement for various Fujitsu Air Conditioner models, offering essential functions for controlling your unit. It features a clear LCD display and intuitive buttons for easy operation.






Image: Front view of the YING RAY Replacement Fujitsu Air Conditioner Remote Control, showing all buttons and the LCD screen.





Image: Close-up of the remote control's LCD screen, clearly showing the temperature displayed in Fahrenheit (e.g., 88°F).

**Note:** This remote control displays temperature readings exclusively in Fahrenheit (°F).

## Setup

### Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two (2) AAA 1.5V ordinary batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

**Important: Batteries are not included with this remote control. Use only AAA 1.5V ordinary batteries.**

## Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the unit.

### Basic Functions

- **START/STOP Button:** Press to turn the air conditioner ON or OFF.
- **MODE Button:** Press to cycle through operating modes (e.g., Auto, Cool, Dry, Fan, Heat). The current mode will be displayed on the LCD.
- **Temperature Adjustment Buttons (+/-):** Use these buttons to increase or decrease the desired temperature setting. The temperature is displayed in Fahrenheit.
- **FAN CONTROL Button:** Adjusts the fan speed (e.g., Auto, Low, Medium, High).
- **SWING Button:** Activates or deactivates the automatic louver swing function.

### Timer Functions

- **TIMER Button:** Initiates the timer setting process. Follow the on-screen prompts to set ON or OFF timers.
- **SET TIME Button:** Used in conjunction with the TIMER button to adjust the desired time for the timer function.

### Other Functions

- **CLOCK Button:** Press to set the current time. Use the temperature adjustment buttons to set the hour and minute, then press CLOCK again to confirm.
- **SLEEP Button:** Activates the sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.
- **MASTER CONTROL Button:** This button may cycle through primary operating modes or settings depending on the specific Fujitsu unit. Refer to your air conditioner's manual for details.
- **ACL (All Clear) Button:** A small recessed button, typically used to reset the remote control to factory default settings. Use a thin, pointed object (like a paperclip) to press it.

## Maintenance

### Cleaning the Remote Control

- Wipe the remote control with a soft, dry cloth.
- Do not use liquid cleaners, abrasive cleaners, or chemical sprays, as these can damage the remote's surface or internal components.

### Battery Replacement

- Replace batteries when the remote control's display becomes dim or its operating range decreases.
- Always replace both batteries at the same time with new AAA 1.5V ordinary batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.
- Dispose of used batteries according to local regulations.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote control does not operate the air conditioner. | • Batteries are dead or incorrectly inserted.<br>• Remote control is not pointed at the air conditioner's receiver.<br>• Obstruction between remote and air conditioner.<br>• Air conditioner unit is not powered on. | • Replace batteries with new AAA 1.5V batteries, ensuring correct polarity.<br>• Point the remote directly at the air conditioner.<br>• Remove any objects blocking the signal path.<br>• Ensure the air conditioner is plugged in and powered on. |
| Display is dim or blank. | • Low battery power. | • Replace batteries with new AAA 1.5V batteries. |
| Remote control functions are erratic. | • Interference from other electronic devices.<br>• Low battery power.<br>• Internal error. | • Move away from other electronic devices.<br>• Replace batteries.<br>• Press the ACL (All Clear) button with a thin object to reset the remote. |

## Specifications

- **Model:** 2018110625-F
- **Compatible with:** Various Fujitsu Air Conditioner models (e.g., ASY14FSBCW, ABT14RB, ABT18RB, ABT24AB, ABT24RB, ASU9R2, AST7RSB-W)
- **Power Supply:** 2 x AAA 1.5V Ordinary Batteries (not included)
- **Display Unit:** Fahrenheit (°F) only
- **Manufacturer:** ZHUHAI YINGRAY TRADING CO., LTD.

## Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the seller's policy at the time of purchase. For technical support or inquiries regarding compatibility, please contact the seller directly through the platform where the purchase was made.
Keep this manual for future reference.

© 2024 YING RAY. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07K7GSGPF**

More documents and user manuals: **https://manuals.plus/**