Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 2018110613-F

YING RAY Replacement Remote Control Instruction Manual

For Fujitsu Air Conditioner Models ASY14FSBCW, ASY14USBCW, 9313693022, 9371190174

1. Introduction

This manual provides comprehensive instructions for the proper use and maintenance of your YING RAY replacement remote control. This remote is designed to be compatible with various Fujitsu air conditioner models, including ASY14FSBCW, ASY14USBCW, 9313693022, and 9371190174. Please read this manual thoroughly before operating the remote control to ensure optimal performance and longevity.
Note: This remote control displays temperature exclusively in Fahrenheit.

2. Product Overview

Familiarize yourself with the remote control's layout and display features.




Image 2.1: Front view of the remote control, illustrating button placement and LCD screen.




Image 2.2: Detail of the remote control's LCD display, emphasizing the Fahrenheit temperature reading.

2.1. Button Functions

- **START/STOP:** Powers the air conditioner ON or OFF.
- **SLEEP:** Activates or deactivates the sleep mode for comfortable nighttime operation.
- **TIMER:** Sets or cancels the ON/OFF timer function.
- **CLOCK:** Adjusts the current time displayed on the remote.
- **MASTER CONTROL:** Cycles through operating modes (e.g., Auto, Cool, Dry, Heat, Fan).
- **SET TEMP (+/-):** Increases or decreases the desired temperature setting.
- **SET TIME:** Used in conjunction with the TIMER button to set specific times.
- **FAN CONTROL:** Adjusts the fan speed (e.g., Auto, Low, Medium, High).
- **SET SWING:** Activates or deactivates the vertical louver swing function.
- **SWING:** Adjusts the horizontal louver swing function (if applicable to your AC unit).
- **TIME ADJUST:** Fine-tunes timer settings.
- **ACL (Reset):** Resets the remote control to factory default settings. Use a thin, pointed object to press this button.

3. Battery Installation

The remote control requires two "AAA" 1.5V ordinary batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new "AAA" batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Important: *Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Remove batteries if the remote control will not be used for an extended period.*

4. Setup

This YING RAY replacement remote control is designed for direct use with compatible Fujitsu air conditioner models. No programming or pairing is typically required. Once batteries are installed, the remote should function immediately with your air conditioner.
Point the remote control directly at the air conditioner's receiver when operating.

5. Operating Instructions

5.1. Basic Operation

1. **Power ON/OFF:** Press the **START/STOP** button to turn the air conditioner on or off.
2. **Select Mode:** Press the **MASTER CONTROL** button repeatedly to cycle through available operating modes (e.g., AUTO, COOL, DRY, HEAT, FAN). The selected mode will be displayed on the remote's LCD screen.
3. **Adjust Temperature:** Use the **SET TEMP (+)** or **SET TEMP (-)** buttons to set your desired temperature. The temperature will be displayed in Fahrenheit.
4. **Adjust Fan Speed:** Press the **FAN CONTROL** button to select the desired fan speed (e.g., AUTO, LOW, MED, HIGH).

5.2. Advanced Functions

- **Sleep Mode:** Press the **SLEEP** button to activate sleep mode, which adjusts temperature gradually for comfort during sleep and saves energy. Press again to deactivate.
- **Timer Function:**
    a. Press the **TIMER** button.
    b. Use the **SET TIME** buttons (often combined with TEMP +/-) to set the desired ON or OFF time.
    c. Press **TIMER** again to confirm.
- **Louver Swing:** Press the **SET SWING** button to enable or disable the automatic vertical louver movement. Press the **SWING** button to adjust horizontal louvers (if supported by your AC unit).
- **Clock Setting:** Press the **CLOCK** button, then use the **SET TIME** buttons to adjust the current time. Press **CLOCK** again to confirm.

6. Maintenance

6.1. Battery Replacement

Replace batteries when the remote control's display becomes dim or its operating range decreases. Follow the steps outlined in Section 3. Battery Installation.

6.2. Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly installed batteries.	Replace batteries with new "AAA" batteries, ensuring correct polarity.
Remote control range is poor.	Weak batteries; Obstruction between remote and AC unit.	Replace batteries. Ensure a clear line of sight to the air conditioner's receiver.
Air conditioner not responding.	Remote not compatible; AC unit power issue.	Verify compatibility with your specific Fujitsu model. Check if the AC unit is powered on and functioning independently.
Display is dim or blank.	Low battery power.	Replace batteries.

If problems persist after attempting these solutions, please contact customer support.

8. Specifications

- **Model Number:** 2018110613-F
- **Compatible Brands:** Fujitsu
- **Compatible AC Models:** ASY14FSBCW, ASY14USBCW, 9313693022, 9371190174
- **Power Source:** 2 x "AAA" 1.5V Batteries (not included)
- **Display:** Fahrenheit Only
- **Control Type:** Button Control
- **Special Feature:** Ergonomic design

9. Warranty and Support

For warranty information or technical support, please refer to the seller's policies on the platform where the product was purchased. Keep your purchase receipt as proof of purchase.
For general inquiries or further assistance, you may contact YING RAY customer service through the retailer's messaging system.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07K7JCJZK

More documents and user manuals: **https://manuals.plus/**