

Cecotec Power Moca Spume 5000

Cecotec Power Moca Spume 5000 Milk Frother Instruction Manual

Model: Power Moca Spume 5000 (01518)

1. INTRODUCTION

Thank you for choosing the Cecotec Power Moca Spume 5000 Milk Frother. This appliance is designed to effortlessly prepare perfect frothed milk for your coffee, lattes, cappuccinos, and even hot chocolate. Please read this instruction manual carefully before first use to ensure proper operation, maintenance, and safety.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not immerse the power base, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance out of reach of children.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only manufacturer-recommended attachments.
- Do not use the appliance outdoors.
- Avoid contact with moving parts.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to 'off', then remove the plug from the wall outlet.
- This appliance is for household use only.
- The jug is cordless for ease of use, but the power base must remain connected to a power source during operation.

3. PRODUCT OVERVIEW

The Cecotec Power Moca Spume 5000 is an automatic milk frother designed for convenience and versatility. It features a sleek stainless steel design with a 360-degree anti-slip base.

Components:

- **Froth Cup (Stainless Steel Jug):** The main container for milk, with a non-stick interior and capacity indicators.
- **Power Base:** The electrical base that heats and froths the milk.
- **Lid:** Covers the froth cup during operation.
- **Cleaning Brush:** For easy cleaning of the jug and accessories.
- **Frothing/Heating Whisk:** Removable accessory for frothing and heating.
- **Hot Chocolate Accessory:** Specific attachment for preparing melted chocolate.



Image 1: The Cecotec Power Moca Spume 5000 Milk Frother. This image shows the complete unit, including the stainless steel jug with its black ribbed exterior and the silver power base with the control button.



Image 2: Close-up of the control panel. The central power button is illuminated, with icons indicating functions for cold frothing, warm frothing, and heating/hot chocolate around it.

4. SETUP AND FIRST USE

1. Unpack all components and remove any packaging materials.
2. Clean the stainless steel jug, lid, and all removable accessories (frothing whisk, hot chocolate accessory) with warm soapy water. Rinse thoroughly and dry. The jug is dishwasher safe.
3. Place the power base on a stable, flat, heat-resistant surface.
4. Ensure the power base is plugged into a suitable electrical outlet.
5. Insert the desired whisk (frothing or hot chocolate) into the bottom of the jug.

5. OPERATING INSTRUCTIONS

The Power Moca Spume 5000 offers four operating modes. The jug has embossed indicators for maximum and minimum capacities: 200 ml for frothing and 400 ml for heating.

General Operation:

1. Place the desired whisk into the jug.
2. Pour milk (or other liquid for hot chocolate) into the jug, ensuring it is between the minimum and maximum fill lines. The frother supports normal, evaporated, cold, and lactose-free milk.
3. Place the lid on the jug.
4. Place the jug onto the power base.
5. Press and hold the central power button for a few seconds to cycle through the operating modes. The indicator light around the button will change to reflect the selected mode.
6. Once the desired mode is selected, release the button. The appliance will start automatically.
7. The appliance will automatically switch off once the function is complete.
8. Carefully remove the jug from the base and pour the contents.

Operating Modes Explained:

- **Warm Frothing:** Heats and froths milk for cappuccinos and lattes. Use the frothing whisk. Max capacity: 200 ml.
- **Cold Frothing:** Froths milk without heating, ideal for iced coffees or cold beverages. Use the frothing whisk. Max capacity: 200 ml.
- **Heating:** Heats milk without frothing. Use the frothing whisk (without the spring) or the hot chocolate accessory. Max capacity: 400 ml.
- **Hot Chocolate:** Heats and mixes ingredients to create hot chocolate. Use the specific hot chocolate accessory. Max capacity: 400 ml.



Image 3: A spoon scooping thick, creamy frothed milk from the stainless steel jug of the frother, demonstrating the quality of the foam produced.



Image 4: Frothed milk being poured from the frother jug into a glass of coffee, creating a layered latte or cappuccino.



Image 5: Thick, melted chocolate being poured from the frother jug into a glass, illustrating the hot chocolate function.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your appliance.

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. The stainless steel jug is dishwasher safe. Alternatively, wash it with warm soapy water using the provided cleaning brush. Rinse thoroughly and dry.
3. The lid and all removable accessories (whisks) can be washed with warm soapy water and rinsed.
4. Wipe the exterior of the power base with a damp cloth. Do not immerse the power base in water or any other liquid.
5. Ensure all parts are completely dry before storing or next use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; jug not correctly placed on base.	Check power connection; ensure jug is securely seated on the power base.
Milk is not frothing or heating properly.	Incorrect whisk used; milk level too high/low; type of milk; whisk not properly inserted.	Ensure correct whisk is used for the desired function; check milk levels are between min/max indicators; ensure whisk is securely attached; try a different type of milk.
Milk overflows.	Too much milk added.	Do not exceed the maximum fill line for frothing (200 ml) or heating (400 ml).
Burnt smell or residue at the bottom of the jug.	Jug not cleaned thoroughly; milk residue.	Clean the jug thoroughly after each use, especially the bottom heating plate.

8. SPECIFICATIONS

- **Model Name:** Power Moca Spume 5000
- **Model Number:** 01518
- **Power:** 650 W
- **Frothing Capacity:** 200 ml
- **Heating Capacity:** 400 ml
- **Dimensions:** 15 x 15 x 24 cm (Length x Width x Height)
- **Item Weight:** 1.52 kg
- **Material:** Stainless Steel
- **Color:** Stainless Steel
- **Special Features:** 4 operating modes, cordless jug, dishwasher-safe jug, BPA-free, 360-degree base, automatic shut-off.
- **Included Components:** Froth Cup, Power Base, Lid, Cleaning Brush.

9. WARRANTY AND SUPPORT

Your Cecotec Power Moca Spume 5000 Milk Frother comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included with your product or visit the official Cecotec website.

For technical support, spare parts, or any questions regarding your appliance, please contact Cecotec customer service through their official channels. Please have your model number (01518) and purchase date ready when contacting support.

Related Documents - Power Moca Spume 5000

	<p><u>Cecotec Ready Warm 7000 Quartz Bath: User Manual & Technical Specifications</u></p> <p>Comprehensive user manual and technical specifications for the Cecotec Ready Warm 7000 Quartz Bath, a 1200W quartz heater. Includes safety instructions, operation guide, cleaning, maintenance, warranty information, and detailed technical data.</p>
	<p><u>Cecotec READY WARM 9890 FORCE ROTATE Fan Heater User Manual</u></p> <p>Comprehensive user manual for the Cecotec READY WARM 9890 FORCE ROTATE fan heater, covering safety instructions, operation, cleaning, maintenance, technical specifications, and warranty information.</p>
	<p><u>Cecotec Ready Warm 9650 Horizon Force - User Manual and Specifications</u></p> <p>Instruction manual and technical specifications for the Cecotec Ready Warm 9650 Horizon Force fan heater. Includes safety instructions, operation guide, cleaning, maintenance, and warranty information.</p>
	<p><u>Manual de Usuario Cecotec ReadyWarm 2070 Max Force Black Termoventilador Instrucciones y Especificaciones</u></p> <p>Manual completo del termoventilador Cecotec ReadyWarm 2070 Max Force Black (modelo 08254). Incluye instrucciones de seguridad, funcionamiento, limpieza, mantenimiento y especificaciones técnicas para un uso óptimo y seguro.</p>
	<p><u>Cecotec ReadyWarm 9750 Rotate Force Upright Fan Heater - User Manual</u></p> <p>Explore the Cecotec ReadyWarm 9750 Rotate Force upright fan heater. This manual provides essential operating instructions, safety guidelines, and technical details for efficient heating in well-insulated spaces.</p>
	<p><u>Cecotec Ready Warm 9820 Force Dual Fan Heater: User Manual and Specifications</u></p> <p>Comprehensive guide for the Cecotec Ready Warm 9820 Force Dual fan heater, covering safety instructions, operation, cleaning, maintenance, technical specifications, disposal, and warranty information.</p>

