



[Manuals.plus](#) /

› [Satisfyer](#) /

› Satisfyer Master Vibrator S4049369016440 Instruction Manual

## Satisfyer S4049369016440

# Satisfyer Master Vibrator S4049369016440 Instruction Manual

Model: S4049369016440

## 1. PRODUCT OVERVIEW

---

The Satisfyer Master Vibrator is designed for G-spot and clitoral stimulation. It features a flexible, skin-friendly silicone shaft and offers multiple vibration programs for varied experiences. This manual provides essential information for safe and effective use of your device.



Image 1: The Satisfyer Master Vibrator, showcasing its overall design.

## 2. KEY FEATURES

---

- **Material:** Skin-friendly silicone for gentle contact.
- **Design:** Impressive XXL size with a lifelike shape and stylized head for targeted stimulation.
- **Vibration Programs:** 12 distinct vibration programs for diverse sensations.
- **Dual Motors:** Targets both G-spot and clitoris simultaneously.
- **Handle:** Ring-shaped handle design for secure grip and adjustable angle.
- **Waterproof:** IPX7 waterproof rating for easy cleaning and use in water.
- **Rechargeable:** Includes a magnetic USB charging cable.

# PRODUCT FEATURES




Image 2: Diagram illustrating key features such as realistic design, silicone shaft, 12 vibration settings, ring handle, and magnetic charging.

## 3. SETUP AND CHARGING

---

### 3.1 Initial Charge

Before first use, fully charge the device. Connect the magnetic USB charging cable to the charging points on the device's base and plug the USB end into a compatible power source (e.g., computer USB port, USB wall adapter). The indicator light will show charging status.



Image 3: The magnetic USB charging cable for the Satisfyer Master Vibrator.

### **3.2 Cleaning Before First Use**

Clean the device thoroughly with warm water and a mild, toy-safe cleaner before its initial use. Rinse well and allow to air dry completely.

## **4. OPERATING INSTRUCTIONS**

---

### **4.1 Power On/Off**

To turn on the device, press and hold the power button (usually the central button on the control panel) for 2-3 seconds. To turn off, press and hold the power button again for 2-3 seconds.

### **4.2 Changing Vibration Programs**

Once powered on, short press the program button (often indicated by a wave icon or +/- buttons) to cycle through the 12 available vibration programs. Experiment to find your preferred setting.

### **4.3 Usage Tips**

- Apply a generous amount of water-based lubricant to the device and desired areas for comfortable use.

- The flexible shaft adapts to body contours, allowing for various angles and positions.
- The ring-shaped handle provides a secure grip during use.

## 5. MAINTENANCE AND CARE

---

### 5.1 Cleaning After Use

After each use, clean the device with warm water and a toy-safe cleaner. Ensure all residue is removed. Rinse thoroughly and pat dry with a lint-free cloth or allow to air dry completely.

### 5.2 Storage

Store the device in a clean, dry place, away from direct sunlight and extreme temperatures. Avoid storing with other toys made of different materials to prevent material degradation.

### 5.3 Charging

Recharge the device when the battery indicator shows low power. Do not overcharge. Disconnect the charger once fully charged.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided USB cable.
Device does not charge.	Improper connection or faulty cable/power source.	Ensure the magnetic charging cable is securely connected. Try a different USB port or power adapter.
Vibrations are weak.	Low battery.	Recharge the device.

## 7. SPECIFICATIONS

---

- **Model Number:** S4049369016440
- **Material:** Silicone
- **Dimensions:** 9.06 x 1.93 x 1.93 inches
- **Weight:** 14.11 ounces
- **Battery:** 1 Lithium Ion battery (included)
- **Water Resistance:** Waterproof (IPX7)
- **Vibration Programs:** 12

## 8. WARRANTY AND SUPPORT

---

The Satisfyer Master Vibrator comes with a 15-year guarantee, ensuring long-lasting satisfaction. For warranty claims, technical support, or further assistance, please refer to the official Satisfyer website or contact their customer service directly. Keep your proof of purchase for warranty validation.

Video 1: Official product video demonstrating the Satisfyer Master Vibrator's features and design. This video is provided by the seller, EIS-Inc.

## **9. SAFETY INFORMATION**

---

- This product is intended for adult use only.
- Do not use if the device appears damaged or defective.
- Discontinue use immediately if you experience any discomfort or pain.
- Consult a healthcare professional if you have any medical conditions or concerns before use.
- Keep out of reach of children.
- Use only water-based lubricants with silicone products to prevent material damage.