

Aiworth E36

Aiworth E36 Digital Voice Recorder User Manual

Model: E36 | Brand: Aiworth

INTRODUCTION

Thank you for choosing the Aiworth E36 Digital Voice Recorder. This device is designed to provide high-quality audio recording for various purposes, including lectures, meetings, interviews, and personal notes. With its advanced features and user-friendly interface, you can capture clear sound and manage your recordings efficiently.



The Aiworth E36 Digital Voice Recorder and included 128GB Micro SD card.

PRODUCT FEATURES

- **High-Quality Recording:** Equipped with dual sensitive microphones and a professional recording IC, supporting up to 1536Kbps PCM recording for clear audio.

- **Large Storage Capacity:** Built-in 8GB flash memory, expandable with a pre-plugged 128GB TF card, offering up to 9860 hours of recording.
- **Long Battery Life:** 800mAh rechargeable battery provides up to 45 hours of continuous recording.
- **Voice Activated Recording (VOR):** Automatically starts recording when sound (over 60db) is detected and pauses when silent.
- **Password Protection:** Secure your device and recordings with a 3-digit power-on password.
- **Variable Play Speed:** Adjust playback speed with 16 levels for faster review or detailed listening.
- **A-B Repeat Function:** Loop playback between two selected points for focused review.
- **Line-in Recording:** Directly record from external audio devices.
- **User-Friendly Design:** All operation buttons are conveniently located on the front for intuitive control.

1536Kbps PCM recording

Dual sensitive microphones



30Ft

60Ft

10Ft

30Ft

60Ft

STOP

REC

Easy management
Recorded files named as

YYYY-MM-DD-HH-MM-SS

 2018-06-14-11-50-30

 2018-06-14-11-52-31

 2018-06-14-11-55-45

The Aiworth E36 features 1536Kbps PCM recording and dual sensitive microphones for superior audio capture.



**Built-in
8GB memory &
800mAh battery**

**128GB TF card
has been plugged in
the recorder**



**Save 9860 hours recordings &
45 hours continuous recording**

The device boasts 136GB of memory and an 800mAh battery, providing up to 45 hours of continuous recording.

PACKAGE CONTENTS

Upon opening your package, you should find the following items:

- E36 Voice Recorder
- Line-in cable
- USB cable
- After-sales Service Card

SAFETY INFORMATION

For optimal performance and longevity of your device, please observe the following safety guidelines:

- It is recommended to charge the device for a while before its first use.
- Keep the device away from water and moisture.
- Avoid extreme temperatures.
- Do not attempt to disassemble or repair the device yourself.

SETUP

1. Initial Charging

Before first use, connect the device to a USB power source (computer USB port or a 5V/1A USB adapter) using the provided USB cable. The battery indicator on the screen will show charging status. A full charge typically takes a few hours.

2. Inserting/Removing TF Card (Micro SD Card)

Your E36 recorder comes with a 128GB TF card pre-plugged. If you need to remove or insert a different card:

1. Locate the TF card slot on the side of the device.
2. To remove, gently push the card inward until it clicks, then release. The card will spring out.
3. To insert, align the card correctly (gold contacts facing down, usually) and push it into the slot until it clicks into place.

3. Setting Date and Time

Accurate date and time settings are crucial for organizing your recordings. Refer to the on-screen menu for 'System Settings' to adjust the date and time. Use the navigation buttons to select and confirm values.

4. Setting Password Protection

To protect your recordings, you can set a 3-digit power-on password:

1. Navigate to the 'System Settings' menu.
2. Select 'Password Protection' or similar option.
3. Follow the on-screen prompts to set your 3-digit password. Remember your password, as there is no recovery option.
4. After three incorrect attempts, the device will automatically turn off for security.

Power-on password protection

No one could turn on the device without correct password
Keep your recording files in a safe place



The device features power-on password protection to keep your recordings secure.

OPERATING INSTRUCTIONS

1. Basic Recording

- To start recording, slide the **REC** button upwards. The recording indicator will light up.
- To stop and save the recording, slide the **STOP** button downwards. Recordings are automatically saved with a timestamp (YYYY-MM-DD-HH-MM-SS) for easy management.

2. Voice Activated Recording (VOR)

The VOR function allows the recorder to start recording only when sound is detected, saving memory and battery life.

- Enable VOR mode through the device's menu settings.
- The recorder will automatically begin recording when sound levels exceed approximately 60dB and pause when silent.

Voice activated recording

There is sound(Over 60db),auto start recording
It's silent around,just auto SAVE it!



The voice-activated recording feature automatically starts and stops recording based on sound detection.

3. Playback Functions

- **Variable Play Speed:** Use the menu to adjust playback speed across 16 levels. This allows you to quickly review long recordings or slow down to catch every detail.
- **A-B Repeat:** During playback, set a start point (A) and an end point (B) to continuously loop a specific section of the recording.

Helpful functions in this recorder



Explore helpful functions such as variable speed playback and A-B repeat for enhanced listening.

4. Line-in Recording

Connect the recorder to other audio devices (e.g., computer, radio, player) using the provided line-in cable to record audio directly from them.

5. Connecting to a Personal Computer

To transfer files, connect the E36 to your computer using the USB cable. The device will appear as a removable disk, allowing you to drag and drop files to and from the recorder.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid using liquid cleaners or solvents.
- **Storage:** Store the recorder in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

TROUBLESHOOTING

Device will not turn on:

Ensure the battery is charged. Connect to a power source and try again. If the issue persists, perform a reset by inserting a thin pin into the reset hole (if available, refer to device diagram).

Poor recording quality:

Check microphone placement. Ensure the recording environment is not excessively noisy. Adjust recording settings (e.g., sensitivity level) in the menu. Ensure the device is not covered or obstructed during recording.

Display is difficult to read:

Adjust screen brightness in the settings. Ensure any protective film has been removed from the screen. If the display remains unclear, contact customer support.

Cannot transfer files to computer:

Ensure the USB cable is securely connected to both the recorder and the computer. Try a different USB port or cable. Ensure the device is in data transfer mode (if prompted).

SPECIFICATIONS

Feature	Specification
Product Dimensions	3.81 x 1.25 x 0.49 inches
Item Weight	2.4 ounces
Item Model Number	E36
Batteries	1 Lithium Polymer battery required
Memory Storage Capacity	8GB (built-in) + 128GB (TF card)
Recording Format	MP3 Audio, WMA, WAV
Microphone Form Factor	Built-In
Hardware Interface	3.5mm Audio, USB 2.0
Headphones Jack	3.5 millimeters

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the 'After-sales Service Card' included in your package.

For additional support, video tutorials, or any inquiries not covered in this manual, please contact the manufacturer or seller directly.

You can also find a digital version of the user manual [here](#) and a user guide [here](#).

[\[pdf\]](#) User Manual Warranty

L36 20190314 cdr Administrator 48GB Digital Voice Recorder Activated for Lectures Meetings aiworth 3480 Hours Sound Audio Dictaphone Recording Device with Playback MP3 Player Password Variable Speed E36 User Manual Aiworth B1WNnx0iMVS m media amazon images I |||

E36 User Manual V2 Product Sketch Built-in Mic Line in jack Vol / Up Stop/ USB port Return/Save Play / Pause / ON/OFF Rewind / Previous VOL-/Down TF card socket Screen Headphone jack Record Fast Forward Lock / Next Button Reset Speaker Menu Delete /A-B Lanyard hole 6 To Ensure Product Warr...

lang:en **score:34** filesize: 3.69 M page_count: 1 document date: 2020-06-11

Digital voice recorder



User Manual

[\[pdf\]](#) User Manual Quick Start Guide Instructions

pc E36 instruction Aiworth Professional voice recorder manufacturer aiworthtec 91 |||

Digital voice recorder User Manual 0 Digital voice recorder Thank you for purchasing this product. This is the Quick Start Guide, which provides you with instructions on the basic operations of the recorder. Please read it carefully before using this product.

1.Precautions Charging Do not use the R...

lang:en **score:28** filesize: 750.4 K page_count: 20 document date: 2018-04-13

[Aiworth E36 Digital Voice Recorder User Manual](#)

Comprehensive user manual for the Aiworth E36 Digital Voice Recorder, covering setup, operation, features, and troubleshooting.

lang:en **score:15** filesize: 4.51 M page_count: 1 document date: 2019-03-27