Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Jkea /
- Ikea Tross Ceiling Track 3 LED Spotlights (Model 802.626.63) Instruction Manual

Ikea 802.626.63

Ikea Tross Ceiling Track 3 LED Spotlights (Model 802.626.63) Instruction Manual

Your guide to safe and efficient use.

NTRODUCTION

This manual provides essential information for the safe installation, operation, and maintenance of your Ikea Tross Ceiling Track with 3 LED Spotlights, Model 802.626.63. Please read these instructions carefully before installation and retain them for future reference.

SAFETY INFORMATION

- Always disconnect power at the main fuse or circuit breaker before installation, maintenance, or bulb replacement.
- Installation should be performed by a qualified electrician if you are unsure.
- Ensure the ceiling structure can support the weight of the fixture.
- Do not exceed the maximum wattage specified for the bulbs.
- · Keep packaging materials out of reach of children.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x Ikea Tross Ceiling Track fixture
- 3 x LED Spotlights (integrated or included, depending on model variant)
- Mounting hardware (screws, wall plugs)
- · Instruction manual



Figure 1: Overview of the Ikea Tross Ceiling Track with three LED spotlights. The fixture is white and designed for ceiling mounting.

SETUP AND INSTALLATION

- 1. **Preparation:** Turn off the main power supply at the circuit breaker before starting any electrical work.
- 2. **Mounting Location:** Choose a suitable location on the ceiling, ensuring it is structurally sound and free from obstructions.
- 3. Marking: Hold the fixture base against the ceiling and mark the drilling points for the mounting screws.
- 4. **Drilling:** Drill holes at the marked points. Insert appropriate wall plugs if necessary.
- 5. **Wiring:** Connect the household electrical wires to the terminal block inside the fixture base. Ensure correct polarity (Live to Live, Neutral to Neutral, Earth to Earth). Refer to local electrical codes.
- 6. Securing the Fixture: Attach the fixture base to the ceiling using the provided screws.
- 7. Attaching Spotlights: Ensure the spotlights are securely attached to the track.
- 8. Bulb Installation (if applicable): If bulbs are not pre-installed, insert B22D base LED bulbs into the spotlight

holders. Do not overtighten.

- 9. Final Check: Double-check all connections and ensure the fixture is securely mounted.
- 10. Restore Power: Turn the main power supply back on.



Figure 2: A close-up view of one of the spotlights, detailing the bulb base and connection point. This image helps in understanding bulb replacement or installation.

OPERATING INSTRUCTIONS

Once installed and power is restored, the Ikea Tross Ceiling Track is ready for use.

- Turning On/Off: Operate the light fixture using your standard wall switch connected to the circuit.
- Adjusting Spotlights: Each spotlight head can be individually adjusted to direct light to your desired area. Gently pivot and rotate the spotlight heads to achieve the optimal lighting angle.

MAINTENANCE

• **Cleaning:** Disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.

• Bulb Replacement:

- a. Turn off power at the circuit breaker.
- b. Allow the old bulb to cool completely before touching.
- c. Gently twist and pull out the old B22D bulb.
- d. Insert a new B22D LED bulb of the correct wattage (refer to specifications).
- e. Restore power.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power supply. Loose wiring. Faulty bulb.	Check circuit breaker. Ensure all wires are securely connected (power off first). Replace bulb.
Light flickers.	Loose bulb. Incompatible dimmer switch (if applicable). Faulty wiring.	Tighten bulb. Ensure dimmer is compatible with LED bulbs. Consult a qualified electrician.
Spotlight head is loose.	Mounting screw needs tightening.	Gently tighten the screw securing the spotlight head to the track. Do not overtighten.

SPECIFICATIONS

Feature	Detail
Brand	Ikea
Model Number	802.626.63
Light Type	LED
Special Feature	Corded
Wattage	50 Watts (Max per fixture, check individual bulb rating)
Bulb Base	B22D
Light Colour	Cool White (with possible selectable colors)
Colour Temperature	6500 Kelvin
Number of Items	1 (fixture with 3 spotlights)
Country of Origin	Sweden

WARRANTY INFORMATION

Ikea products are designed with quality and durability in mind. For specific warranty terms and conditions applicable to

your region and product, please refer to the purchase documentation or visit the official Ikea website. Keep your proof of purchase for warranty claims.

SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact lkea customer service. You can find contact information on the official lkea website or on your purchase receipt. For more information, visit: www.ikea.com

© 2023 Ikea. All rights reserved.

Related Documents - 802.626.63

HEKTAR	
	HEKTAR Ceiling Track Installation Guide Step-by-step assembly instructions for the IKEA HEKTAR ceiling track with 3 spotlights. Includes safety precautions and installation steps.
BAROMETER	BAROMETER Ceiling Track Light Installation Guide IKEA
0000	Official installation guide for the IKEA BAROMETER ceiling track light. Learn how to safely install and change bulbs for your IKEA BAROMETER lighting fixture.
TD 066	
TROSS	TROSS Spot Lamp Installation Guide IKEA Step-by-step installation instructions and safety information for the IKEA TROSS spot lamp. Learn how to safely mount and wire your new lighting fixture.
SKENINGE	
THE TRANSPORT	SKENINGE Track Lighting System Installation Guide This guide provides installation instructions for the IKEA SKENINGE track lighting system. Learn how to safely connect the wiring and mount the track, with a maximum load capacity of 1800W.

IKEA BÄVE LED Ceiling Track 5 Spots Installation Guide Official installation and safety instructions for the IKEA BÄVE LED ceiling track with 5 spots. Learn how to safely mount and use your lighting fixture. KRUSNATE KRUSNATE Ceiling Light with 4 Spotlights Assembly Instructions Step-by-step assembly and installation guide for the IKEA KRUSNATE ceiling light with 4 spotlights. Includes safety precautions and bulb replacement instructions.