

Nickelodeon 6037474

Nickelodeon Paw Patrol 2-Pack Magnetic Jigsaw Puzzles Instruction Manual

Model: 6037474

PRODUCT OVERVIEW

The Nickelodeon Paw Patrol 2-Pack Magnetic Jigsaw Puzzles provide an engaging activity for children aged 36 months to 6 years. This set includes two distinct puzzles featuring colorful graphics of popular Paw Patrol characters. The magnetic design ensures pieces remain securely in place, making it suitable for travel and various play environments.

Each puzzle is designed to be easy to assemble, promoting fine motor skills and problem-solving abilities. Additionally, the manual includes a 'search and find' activity for each puzzle scene, adding an extra layer of interactive play.

PACKAGE CONTENTS

- 1 x Nickelodeon Paw Patrol 2-Pack Magnetic Jigsaw Puzzles book
- 2 x Magnetic Jigsaw Puzzles (one on each side of the book)
- Puzzle pieces for two distinct Paw Patrol scenes

SETUP

1. **Unpack the Puzzles:** Carefully remove the puzzle book from its packaging.
2. **Select a Puzzle Scene:** Open the book to reveal the two magnetic puzzle boards. Choose which puzzle scene to assemble first.
3. **Separate Pieces:** Gently remove all puzzle pieces from the chosen magnetic board. If both puzzles are mixed, refer to the back of the pieces for sorting (e.g., one puzzle might have circles, the other triangles, if applicable, or simply by image content).
4. **Prepare Play Area:** Ensure a clean, flat surface for assembly. The magnetic boards allow for assembly directly within the book or on a separate surface.

OPERATING INSTRUCTIONS

1. **Assemble the Puzzle:** Begin by identifying edge pieces to form the border of the puzzle. Then, fill in the center by matching colors, patterns, and character images. The magnetic backing will hold pieces in place as you work.
2. **Utilize Magnetic Feature:** The magnetic nature of the pieces and board allows for easy assembly and prevents accidental displacement, even when moving the book.
3. **Engage in Search and Find:** After completing a puzzle, refer to the bottom of the puzzle scene for a 'search and find' activity. Locate the specified items and count their occurrences within the completed image.
4. **Switch Puzzles:** Once one puzzle is complete, you can either store the pieces on its magnetic board or flip the book to the other side to begin assembling the second puzzle.



Figure 1: The Nickelodeon Paw Patrol 2-Pack Magnetic Jigsaw Puzzles, featuring two vibrant scenes for assembly.

MAINTENANCE

- **Cleaning:** Wipe the puzzle pieces and magnetic boards with a dry or slightly damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the puzzle book in a dry place away from direct sunlight and extreme temperatures to prevent warping or damage to the magnetic properties and graphics.
- **Handling:** Handle pieces gently to avoid bending or tearing.

TROUBLESHOOTING

- **Missing Pieces:** If a piece is missing, carefully check the play area and packaging. If still missing, contact customer support.
- **Pieces Not Sticking:** Ensure the magnetic board and pieces are clean and free of debris. If the magnetic properties seem weakened, ensure proper storage conditions have been maintained.
- **Difficulty Assembling:** For younger children, provide assistance by sorting pieces by color or character, or by starting the border for them.

SPECIFICATIONS

Feature	Detail
Product Name	Nickelodeon Paw Patrol 2-Pack Magnetic Jigsaw Puzzles

Feature	Detail
Brand	Nickelodeon
Model Number	6037474
ASIN	B07KFQZKPR
Product Dimensions	14.5 x 12 x 14.5 inches
Item Weight	9 pounds
Recommended Age	36 months - 6 years
Number of Puzzles	2
Magnetic Feature	Yes
Manufacturer	UPD
Release Date	December 6, 2018

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt for any warranty claims.
Manufacturer: UPD