

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GYMAX](#) /

› [GYMAX Mini Basketball Hoop - Model GO-GM0185 Instruction Manual](#)

GYMAX GO-GM0185

GYMAX Mini Basketball Hoop - Model GO-GM0185 Instruction Manual

Your guide to setting up, operating, and maintaining your GYMAX Mini Basketball Hoop.

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup & Assembly](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the GYMAX Mini Basketball Hoop, Model GO-GM0185. This wall-mounted basketball hoop is designed for both indoor and outdoor use, providing a fun and engaging way for kids, teens, and adults to enjoy basketball. Its shatterproof backboard and durable construction ensure long-lasting play. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.

2. SAFETY INFORMATION

- **Adult Supervision:** Always ensure adult supervision when children are using the basketball hoop.
- **Secure Mounting:** Ensure the hoop is securely mounted to a stable wall or door frame according to the instructions to prevent it from falling.
- **Avoid Hanging:** Do not hang on the rim or backboard, as this can cause damage to the product or lead to injury.
- **Check for Damage:** Regularly inspect the hoop, net, and mounting hardware for any signs of wear or damage. Discontinue use if any damage is found and replace parts as necessary.
- **Appropriate Use:** Use only mini basketballs with this hoop. Using larger or heavier balls may cause damage.
- **Age Recommendation:** Suitable for children aged 8 and above.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- 1 x Backboard
- 2 x Net (one for replacement)
- Mounting Hardware (screws, anchors, etc.)



Image: All components of the GYMAX Mini Basketball Hoop, including the backboard, rim, and two nets.

4. SETUP & ASSEMBLY

The GYMAX Mini Basketball Hoop is designed for easy assembly. Follow these steps for a secure installation:

- 1. Prepare the Backboard:** The backboard is constructed from high-density shatterproof polypropylene, ensuring durability.
- 2. Attach the Rim:** Securely attach the classic steel-made basketball rim to the backboard using the provided hardware. Ensure all screws are tightened to prevent wobbling.
- 3. Install the Net:** Loop the all-weather nylon net around the rim. The package includes an extra net for replacement.
- 4. Choose Mounting Location:** This hoop can be wall-mounted or hung over a door. Choose a stable

surface, such as a brick or cement wall, or a sturdy door.

5. **Mount the Hoop:** Use the provided screws and anchors for wall mounting. For over-the-door installation, utilize the appropriate hooks (if included or purchased separately) to hang the backboard securely. Ensure the hoop is level and firmly attached to prevent movement during play.





Image: The GYMAX Mini Basketball Hoop securely mounted on a brick wall, demonstrating a typical installation scenario.



**Active and positive childhood with
GYMAX**

**Unite to fight, Enjoy the victory, Strive to
sprint, Start the competition**




Image: Examples of the GYMAX Mini Basketball Hoop being used in various settings, including over a door and on a wall, highlighting its versatility for indoor and outdoor play.

5. OPERATING INSTRUCTIONS

Once assembled and securely mounted, your GYMAX Mini Basketball Hoop is ready for use. This hoop is suitable for various skill levels and ages, from kids to adults.

- **Playing:** Use a mini basketball to shoot hoops. The 16.5-inch rim is designed for engaging play.
- **Indoor/Outdoor Use:** The all-weather design allows for play in various environments, including dorms, bedrooms, sunrooms, basements, offices, or outdoor patios.
- **Adjustable Height:** The wall-mounted design allows for installation at any desired height, making it adaptable for different users and spaces.



Image: An adult preparing to shoot a mini basketball into the wall-mounted hoop, demonstrating its appeal for all ages.



Image: A child dribbling a mini basketball before shooting at the wall-mounted hoop, illustrating its use for younger players.

6. MAINTENANCE

To ensure the longevity and optimal performance of your GYMAX Mini Basketball Hoop, follow these maintenance guidelines:

- **Regular Cleaning:** Wipe down the backboard and rim with a damp cloth to remove dust and dirt. Avoid abrasive cleaners that could scratch the surface.
- **Net Inspection:** Periodically check the nylon net for tears or fraying. Replace the net if it shows significant wear (a spare net is included).
- **Hardware Check:** Regularly inspect all mounting screws and connections to ensure they remain tight. Tighten any loose hardware to maintain stability.
- **Outdoor Care:** While designed for all-weather use, prolonged exposure to extreme weather conditions may accelerate wear. Consider bringing the hoop indoors during severe weather if possible.

7. TROUBLESHOOTING

If you encounter any issues with your GYMAX Mini Basketball Hoop, refer to the following common solutions:

- **Hoop is Wobbly:** Check all mounting screws and ensure they are securely tightened. If wall-mounted, verify that the anchors are properly installed in a solid surface.
- **Net is Damaged:** Replace the damaged net with the spare net provided in the package.
- **Difficulty with Assembly:** Review the assembly instructions carefully. Ensure all parts are correctly oriented and connected. Do not force components together.
- **Product Damage:** If the backboard or rim is damaged, discontinue use and contact customer support for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	GYMAX
Model Name	29" x 20" Wall Mounted Hoop with Spare Net, Portable Shatterproof Basketball Backboard, All Weather Basketball Hoop for Kids Teens Adults, Indoor/Outdoor Play Set Bedroom
Model Number	GO-GM0185
Material	Metal, Polypropylene (PP)
Color	Black
Product Dimensions	17"D x 29"W x 40"H
Item Weight	5 Pounds
Indoor/Outdoor Usage	Indoor, Outdoor
Special Features	2 Net, Breakaway Rim, Easy assembly, Portable, Shatterproof
Mounting Type	Wall Mount
Target Audience	Adults, Kids, Students, Teens, Youth
Included Components	1 x Backboard, 2 x Net
Rim Size	16.5 Inches
Assembly Required	Yes
UPC	615200296681




Image: Detailed dimensions of the GYMAX Mini Basketball Hoop, showing the backboard size (29" x 20") and rim diameter (16.5").

9. WARRANTY & SUPPORT

For warranty information or customer support regarding your GYMAX Mini Basketball Hoop, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt for any warranty claims.