

[manuals.plus](#) /› [LIVINGTON](#) /› [Livington Prime Steam Mop User Manual](#)

LIVINGTON M16625

Livington Prime Steam Mop User Manual

Model: M16625



1. INTRODUCTION

Thank you for choosing the Livingston Prime Steam Mop. This versatile cleaning device utilizes the power of steam to provide hygienic cleanliness without the need for harsh chemicals. It is designed for efficient cleaning of various surfaces, including floors, carpets, windows, upholstery, and more. Please read this manual thoroughly before first use to ensure safe and optimal operation of your device.

2. SAFETY INSTRUCTIONS

- Always read all instructions before using the appliance.
- This appliance is intended for household use only.
- Do not leave the steam mop unattended while it is plugged in or operating.
- Keep the appliance out of reach of children and pets.
- Use only clean tap water in the water tank. Do not add cleaning solutions, perfumes, or other chemicals, as this may damage the appliance or create hazardous fumes.
- Steam is very hot. Avoid direct contact with steam. Do not direct steam at people, animals, or electrical appliances.
- Always unplug the appliance from the power outlet before filling or emptying the water tank, attaching or removing accessories, or when not in use.
- Do not immerse the appliance in water or any other liquid.
- Do not operate the appliance with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Ensure the power cord is not pinched or damaged during use.

3. PRODUCT OVERVIEW AND COMPONENTS

The Livingston Prime Steam Mop is designed for versatility, easily converting from a floor mop to a handheld steamer. Below are the main components and included accessories:



Main Steam Mop Unit: The primary device for steam cleaning floors and converting to handheld use.



Microfiber Pad: Attaches to the mop head for effective floor cleaning.



Glass Cleaner Attachment: For streak-free cleaning of windows and mirrors.



Key Features: Illustrates 90° articulation, 120°C steam, 10-second heat-up, and 1.5 kg weight.

Additional accessories include a Carpet Glider, Metal Round Brush, Large Plastic Round Brush, and Upholstery Cleaning Pad, designed for specialized cleaning tasks.

4. SETUP

1. Assembly:

- Attach the handle to the main body of the steam mop until it clicks securely into place.
- Connect the mop head to the main body. Ensure all connections are firm before use.

2. Attaching the Microfiber Pad:

- Place the microfiber pad on the floor with the loops facing upwards.
- Align the mop head over the pad and press down firmly to secure the pad using the hook-and-loop fasteners.

3. Filling the Water Tank:

- Ensure the appliance is unplugged.

- Locate the water tank cap, usually on the front or side of the main unit. Open the cap.
- Fill the tank with clean tap water using the provided measuring cup, if applicable. Do not overfill. The tank capacity is 200 ml.
- Close the water tank cap securely.

5. OPERATING INSTRUCTIONS

5.1 General Operation

1. Plug the power cord into a grounded electrical outlet (220 Volts).
2. The indicator light will illuminate, and the device will begin to heat up. The Livingston Prime Steam Mop heats up in approximately 10 seconds.
3. Once the steam is ready, you can begin cleaning.

5.2 Using as a Steam Mop

The steam mop is ideal for sealed hard floors such as tile, laminate, and sealed hardwood. It cleans hygienically with steam at 120°C, eliminating 99.9% of bacteria and mites.



Hard Floor Cleaning: Glide the mop slowly over the surface to allow the steam to penetrate and clean effectively.



Carpet Cleaning: Attach the carpet glider over the microfiber pad. Move the mop back and forth over carpets to refresh and sanitize them. Note: This is for refreshing and sanitizing, not deep cleaning heavily soiled carpets.



Flexible Cleaning: The articulated joint allows for easy cleaning under furniture and in hard-to-reach areas.


5.3 Converting to Handheld Steamer and Using Attachments

With two clicks, the mop transforms into a handheld steam cleaner for versatile use around the home.

- Conversion:** Detach the mop head and handle from the main unit to use it as a handheld steamer.
- Attaching Accessories:** Securely attach the desired accessory to the nozzle of the handheld unit.
- Usage Examples:**



- Upholstery Cleaning Pad:** Ideal for refreshing and sanitizing upholstered furniture, mattresses, and clothing.



- **Mattress Sanitization:** Use the upholstery pad to sanitize mattresses and remove odors.



- **Metal/Plastic Round Brushes:** Excellent for cleaning stubborn dirt in tight spaces like grout lines, oven interiors, or barbecue grates.



- **Glass Cleaner Attachment:** For cleaning windows, mirrors, and other glass surfaces.

6. MAINTENANCE AND CLEANING

- **Emptying the Water Tank:** After each use, unplug the appliance and allow it to cool. Open the water tank cap and carefully empty any remaining water.
- **Cleaning Microfiber Pads:** The microfiber pads can be machine washed with similar colors. Do not use bleach or fabric softener. Air dry or tumble dry on low.
- **Cleaning Accessories:** Rinse brushes and other attachments with water after use. Allow them to air dry completely before storing.
- **Descaling:** Over time, mineral deposits may build up in the water tank and internal components, especially in areas with hard water. To descale, mix a solution of equal parts white vinegar and water. Fill the tank with this solution and let it sit for a few hours (or overnight). Then, run the appliance until the tank is empty. Repeat with clean water to rinse. Perform this process monthly or as needed based on water hardness.
- **Storage:** Store the steam mop and its accessories in a cool, dry place, away from direct sunlight and out of reach of children.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No steam or low steam output.	Water tank is empty or low. Appliance not heated sufficiently. Mineral buildup.	Refill water tank. Wait for the indicator light to show readiness (approx. 10 seconds). Perform descaling procedure.
Water leaking from the mop head.	Microfiber pad not attached correctly or saturated. Appliance not fully heated.	Ensure microfiber pad is securely attached. Allow the appliance to fully heat up before use. Replace worn-out pads.
Appliance not turning on.	Not plugged in. Power outlet malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Poor cleaning results.	Microfiber pad is dirty or worn. Moving too fast.	Clean or replace the microfiber pad. Move the mop slower over the surface to allow steam to work.

8. SPECIFICATIONS

Brand	LIVINGTON
Model Number	M16625
Color	White
Dimensions (L x W x H)	62.99 x 27 x 14 cm
Weight	2.8 Kilograms
Water Tank Capacity	200 Milliliters
Power	1300 Watts
Voltage	220 Volts
Material	ABS, Steel
Special Features	Articulated joint, handheld steam cleaner function

9. WARRANTY AND SUPPORT

Specific warranty information for the Livingston Prime Steam Mop (Model M16625) is not available in the provided product details. For warranty claims, technical support, or inquiries regarding spare parts, please contact the retailer or the manufacturer, Mediashop, directly.

Please retain your proof of purchase for any warranty-related inquiries.

For further assistance, you may visit the official Livingston or Mediashop website, or refer to the contact information provided with your product packaging.

Related Documents - M16625

	<p><u>Livington PRIME® Steam Mop Bedienungsanleitung</u> Entdecken Sie den Livingston PRIME® Steam Mop, ein vielseitiges Reinigungsgerät für Ihr Zuhause. Diese Anleitung bietet detaillierte Informationen zur Verwendung, Sicherheit und Wartung.</p>
	<p><u>Livington PRIME EVERYDAY Cordless Vacuum Cleaner Manual</u> This comprehensive manual provides detailed instructions for the Livingston PRIME EVERYDAY cordless vacuum cleaner, covering setup, operation, maintenance, troubleshooting, and safety guidelines.</p>
	<p><u>Livington Deeper Sweeper: User Manual & Instructions for Use</u> Comprehensive user manual for the Livingston Deeper Sweeper. Find detailed instructions on safety, assembly, operation, maintenance, and technical specifications for this cordless electric sweeper.</p>
	<p><u>Livington Mini Table Vacuum Cleaner Manual</u> User manual and safety instructions for the Livingston Mini Table Vacuum Cleaner. Learn how to operate, clean, and maintain your device.</p>
	<p><u>Livington ChillTower Turbo Replacement Filter & Cleaning Guide</u> Instructions for replacing and cleaning the filter for the Livingston ChillTower Turbo air cooler. Includes maintenance tips and importer contact information.</p>
	<p><u>Livington MultiScrubber User Manual</u> This manual provides instructions for the Livingston MultiScrubber, covering assembly, usage, cleaning, and troubleshooting. It details the product's features, technical specifications, and safety precautions for optimal performance and user safety.</p>

