Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DEWALT N025972

DEWALT OEM N025972 Spacer Instruction Manual

Genuine Replacement Part for DEWALT Power Tools

1. Product Overview

The DEWALT OEM N025972 Spacer is a genuine, original equipment manufacturer (OEM) replacement part designed for specific DEWALT power tools. This spacer plays a crucial role in maintaining the correct alignment and spacing of components within the tool, ensuring optimal performance and longevity. It is manufactured to DEWALT's precise specifications to guarantee a perfect fit and reliable operation.



Image 1.1: The DEWALT OEM N025972 Spacer. This image shows the small, black, cylindrical spacer component, which is essential for proper assembly and function within compatible DEWALT tools.

2. Compatibility

This N025972 spacer is compatible with the following DEWALT power tool models:

- DCF610S2 Type 1
- DCF610S2 Type 2
- DCF610S2 Type 3
- DCF610S2-AR Type 1
- DCF610S2-B2 Type 1
- DCF610S2-B2 Type 2
- DCF610S2-BR Type 1
- DCF610S2-BR Type 2
- DCF680N1 Type 1
- DCF680N2 Type 1

Always verify the part number required for your specific tool model before purchasing to ensure correct fitment.

3. Installation and Replacement

The N025972 spacer is a component part of a larger assembly within your DEWALT tool. Its installation typically involves disassembling a portion of the tool to replace a worn or damaged spacer.

1. **Safety First:** Before attempting any repair or replacement, ensure the power tool is disconnected from its power source (unplugged or battery removed).
2. **Consult Tool Manual:** Refer to the specific service manual or exploded parts diagram for your DEWALT tool model (e.g., DCF610S2, DCF680N1) to identify the exact location and orientation of the N025972 spacer.
3. **Disassembly:** Carefully disassemble the tool components as instructed in your tool's service manual to access the spacer.
4. **Replacement:** Remove the old or damaged spacer and insert the new DEWALT OEM N025972 Spacer in its correct position and orientation. Ensure it seats properly.
5. **Reassembly:** Reassemble the tool components, ensuring all screws and fasteners are tightened securely according to the manufacturer's specifications.
6. **Functionality Check:** After reassembly, perform a brief functional check of the tool (without load) to ensure all parts operate smoothly and correctly before putting it into full use.

Note: *If you are unsure about any step of the installation process, it is highly recommended to seek assistance from a qualified service technician or refer to official DEWALT service resources. Improper installation can lead to tool malfunction or damage.*

4. Specifications

Key specifications for the DEWALT OEM N025972 Spacer are as follows:

Attribute	Detail
Part Number	N025972
Manufacturer	DEWALT
Item Weight	Approximately 1.06 ounces (30 grams)
Product Dimensions (L x W x H)	Approximately 0.55 x 0.55 x 0.3 inches (1.4 x 1.4 x 0.76 cm)
Item Package Quantity	1

Batteries Required	No

5. Maintenance and Care

As a static component, the N025972 spacer itself requires no specific maintenance. However, ensuring the overall cleanliness and proper lubrication (if applicable to surrounding components) of your DEWALT tool will contribute to the longevity of all its parts, including this spacer. Regularly inspect your tools for any signs of wear or damage to components, and replace them with genuine OEM parts as needed.

6. Troubleshooting

If your DEWALT tool is experiencing issues related to component alignment, excessive play, or unusual noises after a repair, it is possible that a spacer is worn, incorrectly installed, or the wrong part was used.

- **Incorrect Part:** Double-check that the N025972 spacer is the correct part number for your specific tool model.
- **Improper Installation:** Review the installation steps and ensure the spacer is seated correctly and not misaligned or damaged during assembly.
- **Worn Components:** Inspect surrounding components for wear that might affect the spacer's function.

For persistent issues, consult a professional DEWALT service center.

This manual provides general information for the DEWALT OEM N025972 Spacer. For detailed tool-specific instructions, always refer to your DEWALT power tool's original user manual or service guide.
© 2023 DEWALT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07KGH6P3P

More documents and user manuals: **https://manuals.plus/**