

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bergström](#) /

› [Bergström Black Elegance 90 cm Wall-Mounted Glass LED Range Hood User Manual](#)

Bergström Auswahl

Bergström Black Elegance 90 cm Wall-Mounted Glass LED Range Hood User Manual

Model: Auswahl

1. INTRODUCTION

Thank you for choosing the Bergström Black Elegance 90 cm Wall-Mounted Glass LED Range Hood. This manual provides essential information for the safe installation, operation, and maintenance of your new appliance. Please read it thoroughly before use and keep it for future reference.

2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury, observe the following:

- Ensure the electrical installation complies with local regulations.
- Do not operate the range hood if the power cord is damaged.
- Always disconnect the appliance from the power supply before cleaning or maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not flambé under the range hood.
- Ensure adequate ventilation in the room when the range hood is used simultaneously with appliances burning gas or other fuels.
- The air must not be discharged into a flue that is used for exhausting fumes from appliances burning gas or other fuels.
- Regularly clean grease filters to prevent fire hazards.
- The minimum distance between the supporting surface for the cooking vessels on the hob and the lowest part of the range hood must be at least 65 cm.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged:

- Bergström Black Elegance Range Hood unit
- Adjustable chimney sections
- Remote control
- Mounting hardware (screws, wall plugs)
- User Manual (this document)
- Grease filters (pre-installed)



Figure 3.1: Included components: The range hood unit, remote control, and energy efficiency label are shown. The remote control allows for convenient operation of the hood's functions.

4. SETUP AND INSTALLATION

Installation should be performed by a qualified technician. Ensure the power supply is disconnected before beginning

installation.

4.1 Wall Mounting

The range hood is designed for wall mounting. Mark the drilling points on the wall according to the provided template (not included in this manual, refer to packaging). Ensure the mounting height is appropriate for your cooking surface, maintaining a minimum distance of 65 cm.



Figure 4.1: Product dimensions. The image displays the overall width of 90 cm, a height of 60 cm for the main hood body, and an adjustable chimney height ranging from 52.5 cm to 105 cm. These measurements are crucial for proper installation planning.

4.2 Chimney Adjustment

The chimney sections are adjustable to accommodate various ceiling heights. During assembly, the chimney can be progressively adjusted to the desired working height. Secure the chimney sections as per the installation instructions provided with the product packaging.

4.3 Electrical Connection

Connect the range hood to a 230 Volt power supply. Ensure all electrical connections are secure and comply with local electrical codes.

5. OPERATING INSTRUCTIONS

Your Bergström Black Elegance range hood features a sensor touch control panel and a remote control for convenient operation.

5.1 Control Panel



Figure 5.1: Close-up of the sensor touch control panel. The panel features illuminated icons for power, fan speed adjustment, lighting, and timer functions, providing intuitive control over the range hood.

The sensor touch control unit with LED display ensures comfortable operation. The main functions include:

- **Power On/Off:** Touch the power icon to turn the hood on or off.
- **Fan Speed Selection:** Use the 3-level selector to adjust the extraction intensity. Choose a lower speed for light cooking and a higher speed for intense cooking fumes.
- **Lighting:** Activate the integrated LED lighting to illuminate your cooking area.

- **Timer Function:** The timer control allows you to set a specific operating duration after which the hood will automatically switch off. This is useful for clearing residual odors after cooking.

5.2 Remote Control

The included remote control provides an alternative way to operate the range hood from a distance. Its functions mirror those on the main control panel.



Figure 5.2: The remote control unit. It features buttons for power, fan speed adjustment, light control, and timer settings, offering convenient wireless operation of the range hood.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your range hood. Always disconnect power before cleaning.

6.1 Cleaning Grease Filters

The range hood is equipped with mesh grease filters. These filters should be cleaned regularly (e.g., monthly, depending on usage) to prevent grease buildup and maintain extraction efficiency. They can typically be washed by hand with warm soapy water or in a dishwasher.

6.2 Cleaning Surfaces

Clean the glass and other exterior surfaces with a soft cloth and a mild, non-abrasive cleaning agent. Avoid using harsh chemicals or abrasive pads that could scratch the finish.

7. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

- **Hood does not turn on:**

- Check if the power cord is securely plugged in.
- Verify the circuit breaker or fuse.
- Ensure the power button on the control panel or remote is pressed.

- **Poor extraction performance:**

- Clean or replace the grease filters.
- Check for obstructions in the ducting.
- Ensure the fan speed is set appropriately for the cooking intensity.

- **Lights not working:**

- Check if the light function is activated.
- If individual LEDs are replaceable, consult a qualified technician.

- **Unusual noise:**

- Ensure all mounting screws are tight.
- Check for loose components or obstructions in the fan.

If the problem persists, contact customer support or a qualified service technician.

8. SPECIFICATIONS

Brand	Bergström
Model	Auswahl
Type	Wall-Mounted Range Hood
Material	Glass
Color	Black
Dimensions (Product)	90 cm (Width) x 60 cm (Height of main body)
Chimney Height (Adjustable)	52.5 - 105 cm
Package Dimensions	100 x 67 x 49 cm

Weight	15.6 Kilograms
Power	198 Watts
Voltage	230 Volts
Control Type	Touch, Remote Control
Filter Type	Mesh
Noise Level	65 Decibels
Energy Efficiency Class	C (A++ to E scale)
Special Features	Automatic, Timer




Figure 8.1: Energy efficiency label for the Bergström Black Elegance 90. It indicates an energy class C, annual energy consumption of 85




9. WARRANTY AND SUPPORT

Information regarding specific warranty terms and conditions is not provided in this manual. Please refer to the documentation included with your purchase or contact your retailer for warranty details.

For technical support or spare parts inquiries, please contact Bergström customer service through their official website or the contact information provided at the point of purchase. Spare parts availability information is not available in this document.

© 2023 Bergström. All rights reserved.

Related Documents - Auswahl

	<p>BERGSTRÖM Deluxe Plug-in Wireless Doorbell H020 - Instructions and Features</p> <p>User manual and features for the BERGSTRÖM Deluxe Plug-in Wireless Doorbell (Model H020). Includes setup, operating instructions, specifications, care, and disposal information for this 52-ringtone doorbell.</p>
	<p>BERGSTROM J017 Radio Controlled Wall Clock Instructions and Setup</p> <p>Detailed instructions for setting up and operating the BERGSTROM J017 radio-controlled wall clock, including battery installation, time setting, signal reception, and disposal information.</p>
	<p>Checkliste: PV-Module für Balkonkraftwerke – Auswahl, Technik & Montage</p> <p>Eine schnelle Qualitätskontrolle zur Auswahl, Installation und zum Betrieb von PV-Modulen für Balkonkraftwerke. Behandelt Kriterien für Qualität, Technik, Kompatibilität und rechtliche Aspekte.</p>
	<p>Kenworth T700/T2000 NITE Phoenix Installation Manual</p> <p>Comprehensive installation manual for the NITE Phoenix no-idle climate control system for Kenworth T700/T2000 trucks. Covers general, electrical, and optional heater installation procedures, parts lists, and tools required.</p>