

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bose](#) /
- › [Bose Soundlink Mini II Bluetooth Speaker Instruction Manual](#)

Bose SoundLink Mini II-cr

Bose Soundlink Mini II Bluetooth Speaker Instruction Manual

INTRODUCTION

The Bose Soundlink Mini II Bluetooth speaker is engineered to deliver rich, deep sound in a compact, portable design. Crafted with anodized aluminum, this durable speaker is ideal for enjoying high-quality audio at home, in the office, or on the go. It features simple Bluetooth pairing with voice prompts, a built-in speakerphone for calls, and versatile charging options.



Front view of the Bose Soundlink Mini II Bluetooth Speaker, showcasing its compact design and the Bose logo on the speaker grille.

SETUP

Powering On/Off

- To power on, press the **Power button** () on the top panel.
- To power off, press and hold the **Power button** until the indicator light turns off.

Bluetooth Pairing

1. Ensure the speaker is powered on.
2. Press the **Bluetooth button** () on the top panel. The Bluetooth indicator light will blink blue.
3. On your mobile device, enable Bluetooth and select "Bose Soundlink Mini II" from the list of available

devices.

4. Once connected, the speaker will provide a voice prompt, and the Bluetooth indicator light will glow solid white.

Connecting via Auxiliary Input

For devices without Bluetooth, connect an audio cable (not included) from your device's headphone jack to the **AUX input** on the side of the speaker.



Close-up top view of the Bose Soundlink Mini II, highlighting the control panel with power, volume, Bluetooth pairing, and auxiliary input buttons.

OPERATING INSTRUCTIONS

Volume Control

- Adjust volume using the **Volume Up (+)** and **Volume Down (-)** buttons on the top panel of the speaker.
- Alternatively, control the volume directly from your connected Bluetooth device.

Voice Prompts

The speaker provides helpful voice prompts for Bluetooth pairing, battery status, and connected devices. These prompts simplify the user experience.

Speakerphone Functionality

When connected to a smartphone, the built-in speakerphone allows you to take calls directly through the speaker. Press the **Multi-function button** (center button with three dots) to answer or end calls.

CHARGING

The Soundlink Mini II can be charged using the included charging cradle or directly via the Micro-B USB port on the side of the speaker. A full charge provides up to 10 hours of listening time.

- Place the speaker on the charging cradle to begin charging.
- Connect a Micro-B USB cable to the speaker's USB port for direct charging.

SPECIFICATIONS

Feature	Detail
Brand	Bose
Model Number	SoundLink Mini II-cr
Connectivity Technology	Bluetooth
Audio Output Mode	Stereo
Speaker Maximum Output Power	5 Watts
Frequency Response	50 Hz
Battery Average Life	10 Hours
Battery Charge Time	10 Hours
Item Dimensions (D x W x H)	2.3"D x 7.1"W x 2.1"H
Color	Triple Black
Control Method	Voice



Diagram illustrating the dimensions of the Bose Soundlink Mini II speaker: 7.1 inches wide, 2.1 inches high, and 2.3 inches deep.

MAINTENANCE

- Clean the speaker's surface with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive cleaners.
- Keep the speaker away from water and excessive moisture, as it is not waterproof.
- Store the speaker in a cool, dry place when not in use.

TROUBLESHOOTING

No Power

- Ensure the speaker is fully charged. Connect it to the charging cradle or directly via USB.
- Verify that the power adapter is securely plugged into a working outlet.

Bluetooth Pairing Issues

- Make sure the speaker is in Bluetooth pairing mode (blinking blue light).
- Disable and re-enable Bluetooth on your device.
- Clear the speaker's pairing list by pressing and holding the Bluetooth button for 10 seconds until you hear a tone. Then, try pairing again.
- Ensure your device is within 10 meters (33 feet) of the speaker.

No Sound

- Increase the volume on both the speaker and your connected device.
- Check if the speaker is correctly paired via Bluetooth or connected via the auxiliary input.
- If using auxiliary input, ensure the cable is fully inserted and functional.

WARRANTY AND SUPPORT

This Bose Soundlink Mini II speaker comes with a 90-day limited warranty. For detailed warranty information or technical support, please refer to the official Bose support channels or contact your retailer.