Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- GYMAX /
- > GYMAX 54-inch Foosball Table Instruction Manual (Model CA-GM0282)

GYMAX CA-GM0282

GYMAX 54-inch Foosball Table Instruction Manual

Model: CA-GM0282

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your GYMAX 54-inch Foosball Table, Model CA-GM0282. Please read this manual thoroughly before assembly and use to ensure proper setup and safe operation.



Image: The GYMAX 54-inch Foosball Table, showcasing its full size and design with a brown wood-grain finish and black legs.

SAFETY INFORMATION

- Keep small parts away from children during assembly to prevent choking hazards.
- Ensure all screws and fasteners are securely tightened before use. Periodically check for loose connections.
- Do not climb on or stand on the table.
- Use the table on a level surface to prevent tipping and ensure optimal gameplay.
- Adult supervision is recommended for young children during play.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 1 x Foosball Table (unassembled components)
- 2 x Soccer Balls
- 1 x User's Manual (this document)
- All necessary hardware for assembly

ASSEMBLY INSTRUCTIONS

Assembly typically requires approximately 3 hours. It is recommended to have two adults for easier and safer assembly. Follow the step-by-step diagrams provided in the included user's manual for detailed instructions.

- 1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Identify all components against the parts list.
- 2. **Assemble the Base:** Attach the legs to the main table body. Ensure all screws are tightened firmly but do not overtighten to avoid damaging the engineered wood. The oversized leg levelers should be installed at this stage to allow for height adjustment.
- 3. **Install Playing Rods:** Insert the alloy steel rods through the designated holes. Attach the foosball players (13 black, 13 ivory) and comfortable rubber hand grips to the rods. Ensure the players are oriented correctly.
- 4. **Secure Scoring Devices and Ball Returns:** Attach the bead-style scoring devices to each end of the table. Verify that the internal goal and ball collector mechanisms are correctly positioned for easy retrieval.
- 5. **Final Checks:** Once assembled, check all connections for stability. Adjust the leg levelers to ensure the playing surface is perfectly flat.




Image: A close-up view of the foosball table's sturdy construction, highlighting the iron rods and comfortable, wear-resistant rubber handles.

OPERATING INSTRUCTIONS

Playing the Game

- Starting Play: Place one of the two included soccer balls into the designated ball entry point at the center of the table
- Controlling Players: Use the rubber hand grips to rotate and slide the rods, moving your foosball players to strike the ball. The rods are designed for smooth rotation and control.
- **Scoring:** When a ball enters the opponent's goal, use the bead-style scoring device located at the side of the table to keep track of the score. The internal goal and ball collector allow for easy retrieval of scored balls.
- Fair Play: Avoid spinning the rods excessively, as this can damage the table and is generally considered unsportsmanlike.



Comfortable Rubber Hand Grips



Ball Return Cover



Bead Style Scoring Device



Rubber Ring for Floor Protection

Image: Detailed view of the foosball table's features, including comfortable rubber hand grips, a ball return cover, a beadstyle scoring device, and a rubber ring for floor protection on the leg levelers.



Image: A family of four, including two children and two adults, enjoying a game of foosball on the table, demonstrating its use for various age groups.

MAINTENANCE

- **Cleaning:** Wipe the playing surface and exterior with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Rod Lubrication:** Periodically apply a small amount of silicone-based lubricant to the steel rods to ensure smooth operation. Avoid oil-based lubricants as they can attract dust.
- Hardware Check: Regularly inspect all screws and fasteners for tightness. Re-tighten any loose connections to maintain table stability.
- **Storage:** Store the foosball table in a dry environment, away from direct sunlight and extreme temperature fluctuations, to preserve its materials.

TROUBLESHOOTING

- Loose Screws: If screws become loose or fall out over time, re-insert and tighten them. For persistent issues, consider using slightly larger screws or a small amount of wood glue in the screw holes for added security.
- **Uneven Playing Surface:** Adjust the oversized leg levelers at the bottom of each leg until the playing surface is perfectly horizontal.
- Sticking Rods: Apply silicone lubricant to the rods as described in the Maintenance section. Ensure rods are clean and free of debris.

SPECIFICATIONS

Model Number	CA-GM0282
Product Dimensions	136 cm (L) x 77.5 cm (W) x 89 cm (H) / 54 inches (L) x 30.5 inches (W) x 35 inches (H)
Item Weight	34.02 kg (75 lbs)
Material	Engineered Wood, Alloy Steel
Color	Brown (table body), Ivory (players)
Number of Players	2-4
Included Components	1 x Foosball Table, 2 x Soccer Balls, 1 x User's Manual

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official GYMAX website. Keep your proof of purchase for any warranty claims.

© 2025 GYMAX. All rights reserved.

Related Documents - CA-GM0282



GYMAX 10-in-1 Multi-Game Table UY10001 User Manual and Assembly Guide

Official user manual and assembly instructions for the GYMAX 10-in-1 Multi-Game Table, model UY10001. Includes detailed parts list, safety warnings, and step-by-step assembly guidance for Foosball, Air Hockey, Pool, Ping Pong, Shuffleboard, Bowling, and board games.



Gymax 8 ft. Beer Pong Table - Portable Party Drinking Game

Discover the Gymax 8 ft. Beer Pong Table, a portable and foldable party essential. Featuring a durable design with unique graphics, it's perfect for tailgating and social events.

USEKT MANUAL SIGN TIME	Gymax Side Table Assembly Instructions - Model GYM07109 Official assembly instructions for the Gymax Side Table (Model GYM07109). Includes a detailed parts list, step-by-step assembly guide, and important safety information for your nightstand or end table.
And have refused and the control of	Gymax Kids Table and Chair Set - Assembly Instructions Comprehensive assembly guide for the Gymax Kids 3 Piece Play or Activity Table and Chair Set. Includes safety warnings, parts list, step-by-step instructions, and return policy.
	GYMAX Basketball Arcade Machine Assembly and User Manual Comprehensive guide for assembling and operating the GYMAX Basketball Arcade Machine, including a detailed parts list, step-by-step assembly instructions, electronic scorer operation, and game modes. Features safety warnings and return/damage claim procedures.
	Gymax Glass Dining Table Assembly and Safety Instructions Assembly and safety instructions for the Gymax Glass Dining Table (Model GYM11872), including parts list, assembly steps, and return/damage claim procedures.