

[Manuals.plus](#) /

› [Joseph Joseph](#) /

› Joseph Joseph Flip-Up Drain Board with Foldable Dish Rack (Model 85139) Instruction Manual

Joseph Joseph 85139

Joseph Joseph Flip-Up Drain Board with Foldable Dish Rack (Model 85139) Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the Joseph Joseph Flip-Up Drain Board with Foldable Dish Rack. This product is designed to efficiently drain washed dishes, offering a convenient pop-up plate rack and a compact storage solution. Its thoughtful design includes a ribbed surface to prevent water trapping, a sloping base for effective water channeling, and an integrated spout for direct drainage into the sink. Non-slip feet ensure stability during use.

SETUP

To set up your Joseph Joseph Flip-Up Drain Board, simply place it on a flat countertop surface adjacent to your kitchen sink. Ensure the integrated draining spout is positioned over the sink opening to allow water to flow directly into the sink. The non-slip feet on the base will help keep the unit securely in place.



Image: The Joseph Joseph Flip-Up Drain Board ready for use on a kitchen counter.

OPERATING INSTRUCTIONS

Using the Flip-Up Plate Rack

The drain board features a unique pop-up plate rack. To use, gently lift the rack from its flat position until it locks into an upright position. This rack can hold up to 6 dinner plates, allowing them to air dry efficiently. For other items like cups, glasses, and bowls, place them on the ribbed surface of the drain board.



Image: A hand flipping up the integrated plate rack for use.



Image: The drain board in use, holding various dishes for drying.

Efficient Water Drainage

The drain board is designed with a sloping base and an integrated spout to channel excess water directly into your sink. Ensure the spout is positioned correctly over the sink opening for optimal drainage. The ribbed surface helps prevent water from pooling under items.



Image: Close-up view of water draining from the spout into the sink.

Compact Storage

After use, the plate rack can be folded neatly back into the flat position, allowing for compact storage in a cupboard or drawer.

MAINTENANCE

To clean your drain board, wash it by hand with warm, soapy water. Rinse thoroughly and allow it to air dry. Avoid using abrasive cleaners or scourers, as these may damage the surface. Regular cleaning will prevent the buildup of limescale or residue.

TROUBLESHOOTING

Water Not Draining Completely

If water appears to sit on the drain board and does not drain completely, ensure the drain board is placed on a perfectly level surface. If your countertop has a slight incline away from the sink, or if you prefer faster drainage, you may slightly elevate the side of the drain board opposite the spout using a thin, stable support. This will increase the slope towards the integrated spout, facilitating more complete water runoff.

SPECIFICATIONS

Material	Plastic
----------	---------

Product Dimensions (D x W x H)	0.94" x 15.75" x 12.56"
Item Weight	0.5 kg
Special Feature	Foldable
Dish Drying Rack Location	On the Counter
Model Number	85139
Included Components	1 x draining board

WARRANTY INFORMATION

This Joseph Joseph product comes with a 1-year guarantee against manufacturing defects. Please retain your proof of purchase for any warranty claims.

SUPPORT

For further assistance or inquiries regarding your Joseph Joseph Flip-Up Drain Board, please refer to the official Joseph Joseph website or contact their customer service department. Contact details can typically be found on the product packaging or the manufacturer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

