

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SoBuy](#) /

› [SoBuy FKW68-WN Kitchen Cart with Drawers and Shelves - Assembly and User Manual](#)

## SoBuy FKW68-WN

# SoBuy FKW68-WN Kitchen Cart User Manual

Model: FKW68-WN

## 1. PRODUCT OVERVIEW

---

The SoBuy FKW68-WN Kitchen Cart is a versatile and modern storage solution designed for your kitchen or dining area. It features a durable work surface, two convenient drawers for utensils, two spacious shelves for dishes and other items, a practical towel rail, and four robust wheels, two of which are lockable for stability. Its compact design and mobility make it an ideal addition to any home.



Image 1: The SoBuy FKW68-WN Kitchen Cart, showcasing its design and storage capabilities in a kitchen environment.

## 2. SAFETY INFORMATION

---

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the cart. The maximum load capacity is 50 kg.
- Always lock the wheels when the cart is stationary to prevent accidental movement.
- Avoid placing hot items directly on the wooden surface without protection.
- Use on a flat, stable surface to prevent tipping.

## 3. PACKAGE CONTENTS

---

Before beginning assembly, verify that all parts are present and undamaged. Refer to the included parts list and diagrams in your physical instruction manual for specific component identification. Typical components include:

- Top panel (work surface)

- Side frames (4 pieces)
- Drawer components (front, back, sides, bottom)
- Shelf panels (2 pieces)
- Towel rail
- Wheels (4 pieces, 2 with locks)
- Hardware pack (screws, dowels, cam locks, etc.)
- Assembly tools (e.g., Allen key, if required)

## 4. ASSEMBLY INSTRUCTIONS

---

Assembly typically requires two people. Follow the step-by-step illustrated instructions provided in your product packaging. A general assembly sequence is outlined below:

1. **Prepare the Area:** Clear a spacious, clean, and soft surface to prevent scratching the furniture during assembly.
2. **Attach Wheels:** Secure the four wheels to the bottom of the side frames. Ensure the two lockable wheels are positioned on the same side for easier access.
3. **Assemble Frame:** Connect the side frames using the provided crossbars and hardware to form the basic structure.
4. **Install Shelves:** Slide or secure the two shelf panels into their designated slots or supports within the frame.
5. **Assemble Drawers:** Construct the two drawers by attaching the sides, back, and bottom to the drawer front. Install drawer slides if applicable.
6. **Install Drawers:** Insert the assembled drawers into the top section of the cart.
7. **Attach Top Panel:** Place the wooden top panel onto the assembled frame and secure it with the appropriate hardware.
8. **Attach Towel Rail:** Mount the towel rail to the side of the cart as shown in the diagrams.
9. **Final Check:** Verify that all connections are tight and the cart is stable.



Image 2: Detailed dimensions of the kitchen cart, useful for planning placement and assembly.



*Image 3: View of the durable rubber wheels, highlighting the locking mechanism for stability.*

## 5. OPERATING INSTRUCTIONS

---

- **Moving the Cart:** To move the cart, unlock the two lockable wheels by flipping their levers upwards. Gently push the cart to your desired location.
- **Securing the Cart:** Once the cart is in position, engage the locks on the two wheels by flipping their levers downwards. This will prevent the cart from rolling.
- **Using Drawers:** The two drawers provide convenient storage for cutlery, small utensils, or other kitchen essentials. Pull them gently to open and push to close.
- **Utilizing Shelves:** The two slatted shelves offer ample space for storing plates, bowls, glasses, or pantry items. Distribute weight evenly across the shelves.
- **Towel Rail:** Use the integrated towel rail to keep kitchen towels or cloths easily accessible.



*Image 4: An open drawer revealing its capacity for storing cutlery or small items.*



*Image 5: The integrated towel rail, demonstrating its function for hanging kitchen towels.*

## 6. MAINTENANCE AND CARE

---

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Clean up spills immediately to prevent staining, especially on the wooden top.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Protection:** Use placemats or coasters on the work surface to protect it from heat, moisture, and scratches.
- **Environment:** Avoid prolonged exposure to direct sunlight or extreme humidity, which can affect the wood and finish.

## 7. TROUBLESHOOTING

---

- **Cart is Wobbly:**
  - Check all screws and bolts. Tighten any loose connections.
  - Ensure the cart is on a flat, even surface.

- **Drawers Stick or Don't Close Smoothly:**
  - Verify that the drawer slides are correctly installed and aligned.
  - Check for any obstructions inside the drawer or along the slides.
- **Wheels Not Locking:**
  - Ensure the locking levers are fully engaged (flipped downwards).
  - Check for any debris obstructing the wheel lock mechanism.
- **Missing Parts:**
  - Review the package contents list. If parts are missing, contact SoBuy customer support.

## 8. SPECIFICATIONS

---

<b>Brand</b>	SoBuy
<b>Model Number</b>	FKW68-WN
<b>Color</b>	White
<b>Product Dimensions (L x W x H)</b>	85 x 90 x 39 cm
<b>Item Weight</b>	17 kg
<b>Maximum Weight Recommendation</b>	50 kg
<b>Material</b>	Hevea Wood, Engineered Wood, Pine Wood
<b>Frame Material</b>	Engineered Wood
<b>Finish Type</b>	Acrylic Lacquer
<b>Style</b>	Modern
<b>Number of Drawers</b>	2
<b>Number of Shelves</b>	2

## 9. WARRANTY AND SUPPORT

---

SoBuy is committed to providing high-quality products. If you encounter any issues with your FKW68-WN Kitchen Cart, or if you are not satisfied with your purchase, please contact SoBuy customer support. We offer a return policy for products that do not meet your expectations or have manufacturing defects.

- **Contact Support:** For assistance, please refer to the contact information provided in your purchase documentation or visit the official SoBuy website.
- **Returns:** If you wish to return the product due to dissatisfaction or a problem, please contact us for a free return voucher.
- **Missing Parts:** If any parts are missing or damaged upon arrival, please contact customer service for replacements.

