

BANDAI DX BeyonDriver

Bandai Kamen Rider Zi-O Henshin Belt DX BeyonDriver Instruction Manual

Brand: BANDAI | Model: DX BeyonDriver

1. SETUP

1.1 Unpacking Contents

Carefully remove all components from the packaging. Ensure the following items are present:

- DX BeyonDriver Belt Unit
- Woz Miridewatch

1.2 Battery Installation

The DX BeyonDriver requires two types of batteries for full functionality:

- **DX BeyonDriver Belt:** Requires 3 x AAA batteries (sold separately).
- **Woz Miridewatch:** Requires 3 x LR44 batteries (included).

To install batteries in the DX BeyonDriver Belt:

1. Locate the battery compartment on the left side of the BeyonDriver belt.
2. Using a small Phillips head screwdriver, open the battery compartment cover.
3. Insert 3 new AAA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.



Image: DX BeyonDriver belt with the battery compartment open.

To install batteries in the Woz Miridewatch:

1. The Woz Miridewatch comes with LR44 batteries pre-installed. If replacement is needed, locate the battery compartment on the back of the Miridewatch.
2. Using a small Phillips head screwdriver, open the battery compartment cover.
3. Insert 3 new LR44 batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.



Image: DX BeyonDriver belt and Woz Miridewatch components.

2. OPERATING INSTRUCTIONS

2.1 Woz Miridewatch Functions

The Woz Miridewatch is an interactive device that produces sounds and lights when activated.

- Press the button located on the top of the Woz Miridewatch to activate its unique sounds and light effects.



Image: Woz Miridewatch with button press indicated.

2.2 BeyonDriver Transformation Sequence

To perform a transformation using the DX BeyonDriver and Woz Miridewatch:

1. Open the left side of the BeyonDriver belt.
2. Insert the Woz Miridewatch into the designated slot on the open side of the BeyonDriver. Ensure it clicks securely into place.
3. Press the button on the inserted Woz Miridewatch to initiate the transformation sound.
4. Close the lever on the BeyonDriver belt to complete the transformation. The belt will light up and play transformation sounds.



Image: Woz Miridewatch inserted into the BeyonDriver.

レバーを戻すと
必殺技待機状態に!

ビヨンドザタイム!



再びレバーを閉じると必殺技が発動!



タイムイクスプロージョン!

Image: Transformation sequence with Miridewatch insertion and lever action.

2.3 Activating Special Attacks

After transformation, the BeyonDriver can activate special attack sounds:

- 1. While in transformed state, open the lever on the BeyonDriver belt. This will set the belt to a special attack standby mode.
- 2. Close the lever again to activate a special attack sound and light effect.



Image: Special attack activation sequence by manipulating the BeyonDriver lever.

3. MAINTENANCE

3.1 Cleaning

To maintain the appearance and functionality of your DX BeyonDriver:

- Wipe the surface with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the plastic.
- Avoid exposing the product to excessive dust or moisture.

3.2 Battery Care

- Remove batteries from the unit if it will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

4. TROUBLESHOOTING

If you encounter issues with your DX BeyonDriver, refer to the following common solutions:

Problem	Solution
---------	----------

Problem	Solution
No sound or light from the BeyonDriver.	Check if the AAA batteries are correctly installed and not depleted. Replace if necessary.
No sound or light from the Woz Miridewatch.	Check if the LR44 batteries are correctly installed and not depleted. Replace if necessary.
Miridewatch does not securely fit into the BeyonDriver.	Ensure the Miridewatch is oriented correctly and inserted firmly until it clicks. Do not force it.

5. SPECIFICATIONS

Feature	Detail
Brand Name	BANDAI
Model	DX BeyonDriver
ASIN	B07KM1359B
Material Type	Plastic
Colour	Green
Belt Style	Transformation Belt
BeyonDriver Battery Type	3 x AAA Batteries (sold separately)
Miridewatch Battery Type	3 x LR44 Batteries (included)
Item Weight	880 g (1.94 Pounds)
Package Dimensions	38.29 x 28.5 x 13.5 cm
Manufacturer	Banbai Hobby
Date First Available	23 December 2021

6. WARRANTY INFORMATION

Specific warranty details for the Bandai Kamen Rider Zi-O Henshin Belt DX BeyonDriver are typically provided with the product packaging or on the manufacturer's official website. Please refer to these sources for comprehensive warranty terms and conditions.

7. CUSTOMER SUPPORT

For further assistance, inquiries, or to report any issues not covered in this manual, please contact Bandai customer support through their official website or the contact information provided on the product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question