

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BRIO](#) /

› **BRIO 30388 Remote Control Race Car Instruction Manual**

## BRIO 30388

# BRIO 30388 Remote Control Race Car Instruction Manual

Model: 30388 | Brand: BRIO

## INTRODUCTION

---

The BRIO 30388 Remote Control Race Car is designed to provide an interactive and engaging play experience for toddlers aged 2 and up. This durable toy features a bright red chassis and an easy-to-use remote control, helping to develop dexterity and control. This manual provides essential information for the safe and proper use, setup, and maintenance of your BRIO Remote Control Race Car.



Figure 1: The BRIO 30388 Remote Control Race Car and its retail packaging. The car is red with white stripes and a number '1', accompanied by a yellow and red remote control.

## SAFETY INFORMATION

### WARNING: Not for children under 2 years of age.

- Always supervise children during play.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the toy is not used for a long period.
- Dispose of batteries responsibly.

## WHAT'S IN THE BOX

Upon opening the package, ensure all components are present and undamaged. The BRIO 30388 Remote Control Race Car package includes:

- 1 x R/C Race Car

- 1 x Remote Control



Figure 2: The two main components included in the box: the red race car and its corresponding remote control.

## SETUP

---

Before operating your BRIO Remote Control Race Car, you will need to install batteries in both the car and the remote control.

### Battery Installation

1. Locate the battery compartment on the underside of the R/C Race Car.
2. Using a small screwdriver (not included), open the battery compartment cover.
3. Insert the required AA batteries into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.
5. Locate the battery compartment on the underside of the Remote Control.
6. Open the battery compartment cover.
7. Insert the required AA batteries into the compartment, ensuring correct polarity (+/-).
8. Replace the battery compartment cover.

**Note:** A total of 7 AA batteries are required for full operation. Batteries are not included.

## OPERATING INSTRUCTIONS

The BRIO Remote Control Race Car is designed for simple and intuitive operation, making it ideal for young children.

### Remote Control Functions

- **Forward Button:** Press the large arrow button pointing upwards on the remote control to make the race car move forward.
- **Backward Button:** Press the large arrow button pointing downwards on the remote control to make the race car move backward.
- **Turn Left Button:** Press the arrow button pointing left to make the race car turn left.
- **Turn Right Button:** Press the arrow button pointing right to make the race car turn right.



Figure 3: Illustrates how to press the forward button on the remote control to propel the race car forward.



Figure 4: Illustrates how to press the backward button on the remote control to move the race car in reverse.

The remote control operates on a 2.4 GHz frequency, providing a stable connection. The car can reach speeds of approximately 0.5 meters per second and has an operating range of up to 15 meters.



Figure 5: Key operational specifications including range, frequency, and speed.

## MAINTENANCE

To ensure the longevity and optimal performance of your BRIO Remote Control Race Car, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the car and remote control with a soft, damp cloth. Do not immerse in water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Always remove batteries if the toy will not be used for an extended period to prevent leakage and damage.

## TROUBLESHOOTING

If you encounter any issues with your BRIO Remote Control Race Car, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Car does not move or responds intermittently.	Low or dead batteries in car or remote. Incorrect battery polarity. Interference.	Replace all batteries in both the car and remote control with fresh ones. Ensure batteries are inserted with correct +/- orientation. Move to an area with less electronic interference.
Car moves slowly or range is reduced.	Weak batteries. Obstructions between remote and car.	Replace batteries in both units. Ensure a clear line of sight between the remote and the car. Operate within the specified 15m range.
Remote control buttons are unresponsive.	Remote batteries are low or dead. Remote is out of range.	Replace batteries in the remote control. Bring the remote closer to the car.

## SPECIFICATIONS

Detailed technical specifications for the BRIO 30388 Remote Control Race Car:

**Product Model Number:** 63038800

**Product Dimensions:** 10.24 x 5.71 x 4.13 inches (26 x 14.5 x 10.5 cm)

**Item Weight:** 1.34 pounds (0.61 kg)

**Manufacturer Recommended Age:** 24 months - 5 years

**Batteries Required:** 7 AA batteries - Not included

**Radio Frequency:** 2.4 GHz

**Max Speed:** Approximately 0.5 m/sec

**Operating Range:** Up to 15 meters

**Material:** High Impact-Resistant Plastic

**Manufacturer:** BRIO

**Release Date:** November 4, 2020

## WARRANTY AND SUPPORT

BRIO products are manufactured to high-quality standards. For information regarding warranty coverage or to seek technical support, please contact BRIO customer service directly.

You can find more information and contact details by visiting the official BRIO website or their Amazon store page:[BRIO Amazon Store](#)

© 2024 BRIO. All rights reserved.

## Related Documents - 30388

	<p><a href="#">BRIO Builder Flashlight - Interactive Toy Accessory Guide</a></p> <p>Learn how to use and care for the BRIO Builder Flashlight, a colorful LED accessory compatible with BRIO Builder tools. Includes battery installation, safety guidelines, and product features.</p>
---	---

	<p><a href="#"><b>BRIO Builder Light Set - Enhance Your Construction Play</b></a></p> <p>Enhance your BRIO Builder construction play with the Builder Light Set. This set adds dynamic light effects with multiple modes. Learn about product features, care instructions, and safe battery replacement.</p>
	<p><a href="#"><b>BRIO Remote-Control Race Car - User Manual and Instructions</b></a></p> <p>Comprehensive guide for the BRIO Remote-Control Race Car, detailing setup, operation, controls, troubleshooting, and safety information for toddlers and parents.</p>
	<p><a href="#"><b>BRIO Battery-Operated Steaming Train - User Manual and Instructions</b></a></p> <p>Comprehensive guide for the BRIO Battery-Operated Steaming Train (model 33884). Learn how to install batteries, operate the train, generate steam, and understand safety precautions. Includes tips for optimal play and maintenance.</p>
	<p><a href="#"><b>BRIO Code &amp; Go Bumblebee User Manual and Instructions</b></a></p> <p>Comprehensive guide for the BRIO Code &amp; Go Bumblebee toy, covering setup, operation, battery replacement, and safety guidelines. Learn how to program movement patterns and explore the different modes of this educational toy.</p>
	<p><a href="#"><b>BRIO Light Up Construction Crane 33835 - Assembly and Safety Instructions</b></a></p> <p>Detailed instructions for assembling, operating, and maintaining the BRIO Light Up Construction Crane (model 33835), including battery replacement and safety guidelines.</p>