NETGEAR AC2100-100NAS

NETGEAR Nighthawk AC2100 Smart WiFi Router

Model: AC2100-100NAS

Introduction

This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your NETGEAR Nighthawk AC2100 Smart WiFi Router. The AC2100 router delivers extreme WiFi speed for HD streaming, up to 2100Mbps. It features a dual-core processor, external antennas, and Beamforming+ technology for extended range and optimal connectivity. Downstream and upstream QoS automatically prioritizes applications for smooth streaming. This product is compatible with 100-240V voltage.

Safety Information

- Ensure the router is placed in a well-ventilated area to prevent overheating.
- Use only the power adapter supplied with the device.
- Keep the device away from water, fire, and high temperatures.
- Do not attempt to open or repair the device yourself. Refer all servicing to qualified personnel.
- Keep out of reach of children.

Package Contents

Verify that your package contains the following items:

- NETGEAR Nighthawk AC2100 Smart WiFi Router
- Ethernet Cable
- Power Adapter
- Quick Start Guide

Hardware Overview

Front Panel

The front panel of your Nighthawk AC2100 router features LED indicators for various functions and a USB 3.0 port.



Figure 1: Front View of the Nighthawk AC2100 Router. Shows the router's top surface with three external antennas, a row of LED indicators, and a USB 3.0 port on the front edge.

- **Power LED:** Indicates power status.
- **Internet LED:** Indicates internet connection status.
- **WiFi LEDs (2.4GHz & 5GHz):** Indicate wireless network activity.
- **Ethernet Port LEDs:** Indicate activity on the wired LAN ports.
- **USB 3.0 Port:** For connecting USB storage devices.

Rear Panel

The rear panel contains all the essential ports for connecting your router to the internet and your local network devices.



Figure 2: Rear View of the Nighthawk AC2100 Router. Displays the back of the router with three external antennas, four yellow LAN ports, one yellow WAN port, a power on/off button, a power input, and a reset button.

- **Reset Button:** Used to restore factory default settings.
- **LAN Ports (1-4):** Gigabit Ethernet ports for wired devices.
- **WAN Port (Internet):** Connects to your modem.
- **Power On/Off Button:** Turns the router on or off.
- **Power Input:** Connects to the power adapter.

Setup Guide

1. **Position Your Router:** Place the router in a central location to maximize WiFi coverage. Avoid placing it near large metal objects, concrete walls, or other electronic devices that might cause interference.
2. **Connect to Modem:** Power off your modem. Connect one end of the provided Ethernet cable to the yellow WAN port on your Nighthawk router and the other end to the Ethernet port on your modem.
3. **Power On:** Connect the power adapter to the router's power input and plug it into a power outlet. Press the Power On/Off button. Wait for the Power LED to turn solid white.
4. **Connect Devices:**
    - **Wired Connection:** Connect your computer or other wired devices to any of the yellow LAN ports (1-4) on the router using an Ethernet cable.
    - **Wireless Connection:** On your WiFi-enabled device (laptop, smartphone, tablet), search for available WiFi networks. Select the NETGEAR network name (SSID) found on the router's label. Enter the default password (Network Key) also found on the label.
5. **Initial Setup via Browser or App:**

- **Browser Setup:** Open a web browser (e.g., Chrome, Firefox, Edge) and typewww.routerlogin.net or www.routerlogin.com into the address bar. Follow the on-screen instructions to complete the setup, including changing the default admin password and WiFi network name/password.
- **Nighthawk App Setup:** Download the NETGEAR Nighthawk app from your device's app store. Launch the app and follow the prompts to set up your router. This method is often quicker and more intuitive.

6. **Firmware Update:** After initial setup, check for and install any available firmware updates through the router's web interface or the Nighthawk app to ensure optimal performance and security.




Figure 3: Nighthawk App Interface. Shows a smartphone screen with the Nighthawk app open, displaying options like WiFi Settings, Device List, Guest WiFi, and Parental Controls, with the router status as "Internet: Online".

Operating Instructions

Managing Your WiFi Network

- **Change WiFi Name (SSID) and Password:** Access the router's web interface or Nighthawk app. Navigate to the WiFi settings to customize your network name and password for both 2.4GHz and 5GHz bands.
- **Guest WiFi:** Enable a separate guest network for visitors, keeping your main network secure. You can set a different password and limit access to your local network resources.
- **Parental Controls:** Use the Nighthawk app or web interface to set up parental controls, allowing you to filter content and manage internet access times for specific devices.

Advanced Features

- **Quality of Service (QoS):** The router automatically prioritizes internet traffic for smooth streaming and gaming. You can also manually configure QoS settings to prioritize specific applications or devices.
- **ReadySHARE USB Access:** Connect a USB storage device to the USB 3.0 port to share files across your network or access them remotely using NETGEAR ReadySHARE.
- **Beamforming+:** This technology improves WiFi range and performance by focusing WiFi signals directly to connected devices.

Maintenance

- **Regular Reboots:** Periodically reboot your router (unplug from power for 10 seconds, then plug back in) to clear its memory and improve performance.
- **Keep Firmware Updated:** Regularly check for and install the latest firmware updates. These updates often include performance improvements, security patches, and new features.
- **Cleanliness:** Keep the router clean and free of dust. Use a soft, dry cloth to wipe the exterior. Ensure ventilation holes are not blocked.
- **Secure Your Network:** Use strong, unique passwords for your WiFi network and router administration. Enable WPA2/WPA3 encryption.

Troubleshooting

No Internet Connection

- **Check Cables:** Ensure all Ethernet cables are securely connected to the router and modem.
- **Reboot Devices:** Power cycle your modem first, wait 1-2 minutes, then power cycle your router. Wait for all indicator lights to stabilize.
- **Modem Status:** Check the indicator lights on your modem to ensure it has an active internet connection.
- **ISP Issue:** Contact your Internet Service Provider (ISP) if the modem lights indicate a problem.

Slow WiFi Speed or Poor Coverage

- **Router Placement:** Move the router to a more central location, away from obstructions and interference sources.
- **Interference:** Other electronic devices (cordless phones, microwaves) can interfere with WiFi signals. Try changing your WiFi channel in the router settings.
- **Band Selection:** Ensure your devices are connecting to the appropriate WiFi band (5GHz for faster speeds at shorter distances, 2.4GHz for better range).
- **Too Many Devices:** Disconnect unused devices from the network.

Cannot Access Router Settings

- **Correct Address:** Ensure you are typing www.routerlogin.net or www.routerlogin.com correctly into your browser.
- **IP Address:** Try accessing the router using its default IP address, usually192.168.1.1 or 192.168.0.1.
- **Reset Router:** If you forgot your password, perform a factory reset by pressing and holding the reset button on the back of the router for 7-10 seconds. This will revert all settings to default, including the password.

Specifications

Feature	Detail
Model Name	AC2100-100NAS
Wireless Type	802.11ac
Frequency Band Class	Dual-Band (2.4GHz & 5GHz)
Wireless Speed	Up to 2100Mbps

Feature	Detail
Ethernet Ports	4 x Gigabit LAN, 1 x Gigabit WAN
USB Ports	1 x USB 3.0
Antenna Type	External
Operating System	NETGEAR Smart WiFi OS
Dimensions (LxWxH)	12 x 9 x 3 inches
Item Weight	2.93 pounds
Voltage	100-240 Volts
Special Features	QoS, WPS, Beamforming+

Warranty and Support

NETGEAR provides a limited hardware warranty for this product. The exact duration and terms of the warranty may vary by region and purchase date. Please refer to the warranty card included in your product packaging or visit the official NETGEAR website for detailed warranty information.

Technical Support

For technical assistance, product registration, or to access the latest software and user manuals, please visit the NETGEAR support website:

Visit NETGEAR Support

You can also download the NETGEAR Nighthawk app for easy management and support access directly from your smartphone.

© 2024 NETGEAR. All rights reserved.