

Formuler Z Nano

Formuler Z Nano HD Android Box User Manual

Model: Z Nano (ZnanoSG)

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Formuler Z Nano HD Android Box. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience. The Formuler Z Nano is a compact Android-based media receiver designed for Full-HD entertainment.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your product packaging:

- Formuler Z Nano HD Android Box
- Remote Control
- Power Adapter
- HDMI Cable
- 2 x AAA Batteries (for remote control)
- Quick Setup Guide

3. PRODUCT OVERVIEW

The Formuler Z Nano is a compact and efficient Android media receiver. It features various ports for connectivity and is designed for easy integration into your home entertainment system.



Figure 3.1: The Formuler Z Nano HD Android Box shown with its retail packaging. The device itself is a small, dark grey rectangular unit with the 'FORMULER' logo on the front. The packaging is also dark grey, featuring the 'Z nano' logo and 'android Media Receiver' text.

3.1 Device Dimensions

Dimensions: 9.6 x 9.6 x 2.5 cm

Weight: 450 g

3.2 Ports and Connections

The device includes essential ports for power, video output, and network connectivity. Specific port locations can be found on the device itself.

- **HDMI Output:** For connecting to your television or display.
- **Power Input:** For connecting the power adapter.
- **Ethernet Port:** For wired network connection.
- **USB Ports:** For connecting external storage or peripherals.
- **Micro USB Port:** For specific connectivity needs.

4. SETUP

Follow these steps to set up your Formuler Z Nano HD Android Box:

1. **Connect to TV:** Connect one end of an HDMI cable to the HDMI output port on the Formuler Z Nano and the other end to an available HDMI input port on your television.
2. **Connect to Power:** Plug the power adapter into the power input port on the Formuler Z Nano, then plug the

adapter into a wall outlet. The device should power on automatically or indicate power status.

3. **Insert Batteries into Remote:** Open the battery compartment on the back of the remote control and insert the two AAA batteries, ensuring correct polarity.
4. **Network Connection:**
 - **Wired (Ethernet):** Connect an Ethernet cable from your router or modem to the Ethernet port on the Formuler Z Nano.
 - **Wireless (Wi-Fi):** During the initial setup wizard, you will be prompted to select your Wi-Fi network and enter the password. The device supports 2.4G WiFi.
5. **Initial Boot-up:** Turn on your television and select the correct HDMI input source. The Formuler Z Nano will boot up, and you will be guided through an on-screen setup wizard to configure language, time zone, and network settings.

5. OPERATING INSTRUCTIONS

5.1 Navigation and User Interface

Use the provided remote control to navigate the Android interface. The directional buttons allow you to move between icons and menus, while the 'OK' button confirms selections. The 'Back' button returns to the previous screen, and the 'Home' button takes you to the main Android home screen.

5.2 Accessing Applications

The Formuler Z Nano comes with pre-installed applications and allows for installation of additional apps from the Google Play Store (internet connection required). Supported internet services include Netflix, Hulu, and Amazon Prime Video.

- **MyTvOnline 1:** This application is a key feature for accessing various media content. Refer to the in-app guide or Formuler's official support for detailed usage instructions.
- **Other Apps:** Navigate to the 'Apps' section on the home screen to view and launch installed applications.

5.3 Special Features

- **Chromecast:** Cast content from compatible mobile devices or web browsers directly to your Formuler Z Nano. Ensure both devices are on the same Wi-Fi network.
- **Miracast:** Mirror the screen of your Android smartphone or tablet to your television via the Formuler Z Nano.

6. MAINTENANCE

6.1 Cleaning the Device

To clean the Formuler Z Nano, ensure it is powered off and unplugged from the power outlet. Use a soft, dry, lint-free cloth to wipe the exterior surfaces. Avoid using liquid cleaners, aerosols, or abrasive materials, as these can damage the device.

6.2 Software and Firmware Updates

The Formuler Z Nano supports Over-The-Air (OTA) software and firmware updates. It is recommended to keep your device's software up-to-date to ensure optimal performance, security, and access to new features. You can usually check for updates in the device's settings menu under "About" or "System Updates."

7. TROUBLESHOOTING

If you encounter issues with your Formuler Z Nano, refer to the following common problems and solutions:

Problem	Possible Solution
No Power	Ensure the power adapter is securely connected to both the device and a working power outlet. Try a different outlet.
No Signal on TV	Verify the HDMI cable is properly connected to both the Formuler Z Nano and the TV. Ensure your TV is set to the correct HDMI input source. Try a different HDMI cable or port.
No Internet Connection	For Wi-Fi, check your network settings and ensure the correct password is entered. For Ethernet, ensure the cable is connected and your router is functioning. Restart your router and the Formuler Z Nano.
Remote Control Not Responding	Check if the AAA batteries are inserted correctly and have sufficient charge. Replace batteries if necessary. Ensure there are no obstructions between the remote and the device.
Application Issues	Close and restart the application. Clear the app's cache and data in the Android settings. Ensure the device has a stable internet connection.

If the problem persists after attempting these solutions, please contact Formuler customer support.

8. SPECIFICATIONS

Key technical specifications for the Formuler Z Nano HD Android Box:

Model Name: Z Nano (ZnanoSG)

Manufacturer: Formuler Sales

Resolution: 1080p (Full HD)

Connectivity: Ethernet, Wi-Fi (2.4G), Micro USB

Special Features: Chromecast, Miracast, MyTvOnline 1, OTA Software/Firmware Updates

Supported Internet Services: Netflix, Hulu, Amazon Prime Video

Controller Type: App Control (and included remote)

Dimensions: 9.6 x 9.6 x 2.5 cm

Weight: 0.45 Kilograms (450 g)

Batteries: 2 x AAA (included)

9. WARRANTY AND SUPPORT

Your Formuler Z Nano HD Android Box comes with a **2 Year Warranty** from FORMULER SALES USA. For warranty claims, technical assistance, or further inquiries, please contact Formuler Sales customer support directly. Keep your proof of purchase for warranty validation.

For the most up-to-date support information and resources, please visit the official Formuler website.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07KMXHZK1>

More documents and user manuals: **<https://manuals.plus/>**