

SONGMICS HSR62BK

SONGMICS HSR62BK Garment Rack Instruction Manual

Model: HSR62BK

1. INTRODUCTION

Thank you for choosing the SONGMICS HSR62BK Garment Rack. This manual provides essential information for the safe assembly, proper operation, and effective maintenance of your new garment rack. Please read these instructions thoroughly before beginning assembly or use, and retain this manual for future reference.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum load capacity of 110 kg (242 lbs). Overloading can cause instability and damage.
- **Movement:** When the garment rack is fully loaded, move it slowly and carefully. If possible, seek assistance from another person to prevent tipping or damage.
- **Height Clearance:** The total height of the assembled rack is 198 cm (78 inches). Verify door frame heights or other clearances before attempting to move the rack through narrow passages.
- **Assembly:** Ensure all parts are securely fastened according to the assembly instructions. Loose connections can lead to instability.
- **Children and Pets:** Keep children and pets away from the product during assembly.
- **Placement:** Place the garment rack on a flat, stable surface to prevent wobbling or tipping.

3. PACKAGE CONTENTS

Before assembly, please verify that all components are present and undamaged. If any parts are missing or defective, contact customer service.

- 1 x Garment Rack (disassembled components)
- 1 x Instruction Manual

- 1 x Assembly Kit (tools and fasteners)

4. SPECIFICATIONS

Feature	Detail
Model Number	HSR62BK
Dimensions (L x W x H)	130 x 49 x 198 cm (51.2 x 19.3 x 78 inches)
Weight	7.2 kg (15.9 lbs)
Maximum Load Capacity (Total)	110 kg (242 lbs)
Material	Steel
Color	Black
Number of Shelves	2
Special Features	Adjustable middle rail, 4 universal wheels (2 with brakes)

Note: All dimensions are approximate and may vary slightly.




Image: Garment rack dimensions and load capacity overview.

5. SETUP (ASSEMBLY INSTRUCTIONS)

Assembly of the SONGMICS HSR62BK Garment Rack is designed to be straightforward. Please follow the numbered steps and refer to the included diagrams for visual guidance.

5.1 Unpacking and Part Identification

Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided parts list in your assembly kit.

SONGMICS
by SONGMICS HOME



Portant à vêtements robuste de style industriel

Image: Exploded view of garment rack components.

5.2 Assembly Steps

1. **Attach Wheels:** Secure the four universal wheels to the base frame. Ensure that the two wheels with brakes are positioned on the same side for easy locking.
2. **Assemble Base Frame:** Connect the horizontal bars to the vertical supports of the base frame.
3. **Install Lower Shelf:** Place the lower shelf bars onto the designated slots on the base frame.
4. **Attach Vertical Poles:** Insert the main vertical poles into the base frame.
5. **Install Adjustable Middle Rail:** Attach the adjustable middle rail to the vertical poles. This rail can be set at one of four heights. Refer to the diagram below for adjustment points.

6. **Attach Top Rail:** Secure the top hanging rail to the upper section of the vertical poles.
7. **Tighten All Connections:** Once all parts are in place, carefully tighten all screws and fasteners to ensure stability.



Image: Detail of adjustable middle rail height settings (1-4).

Taille de la figurante: 165 cm

Facile à déplacer et à immobiliser



Verrouillable



Pivotant à 360°



Silencieux



×2 **×2**

Image: Universal wheels with locking mechanism.

6. OPERATING INSTRUCTIONS

6.1 Adjusting the Middle Rail

The middle rail can be adjusted to four different heights to accommodate various clothing lengths. To adjust, loosen the fasteners on the vertical poles, slide the rail to the desired height (indicated by numbered holes), and re-tighten the fasteners securely. The top rail's height remains fixed, making it suitable for longer garments like coats and dresses.

La barre inférieure est réglable en hauteur sur 4 positions

Convient pour des vêtements de différentes longueurs



Image: Adjustable middle rail for different garment lengths.

6.2 Utilizing Storage Space

- **Top Rail:** Ideal for hanging longer items such as coats, dresses, and suits.
- **Middle Rail:** Suitable for shirts, blouses, skirts, and trousers. Adjust its height as needed.
- **Bottom Shelf:** Provides space for shoes, bags, storage boxes, or other accessories.

6.3 Moving and Locking the Rack

The garment rack is equipped with four universal wheels for easy mobility. Two of these wheels have brakes. To move the rack, ensure the brakes are disengaged. To secure the rack in place, press down on the brake levers on the two braked wheels until they lock.

7. MAINTENANCE

- **Cleaning:** Wipe the metal surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Load Distribution:** Distribute weight evenly across the rails to prevent stress on any single point and maintain balance.

8. TROUBLESHOOTING

- **Rack is Unstable/Wobbly:**
 - a. Ensure all screws and fasteners are fully tightened.
 - b. Verify that the rack is placed on a flat, level surface.
 - c. Check if the weight is evenly distributed.
- **Wheels Not Rolling Smoothly:**
 - a. Check for any debris or obstructions in the wheels.
 - b. Ensure the wheel brakes are fully disengaged.
- **Middle Rail Not Adjusting:**
 - a. Ensure the fasteners holding the middle rail are sufficiently loosened before attempting to adjust.
 - b. Confirm that the rail is aligned with the numbered adjustment holes.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For further assistance, product support, or to report missing/damaged parts, please contact SONGMICS customer service through their official website or the contact information provided with your purchase.