

[Manuals.plus](#) /

› [Rfiver](#) /

› Rfiver Universal Table Top TV Stand Instruction Manual

Rfiver Universal Tabletop TV Base for 32"-55"

Rfiver Universal Table Top TV Stand Instruction Manual

Model: Universal Tabletop TV Base for 32"-55"

PRODUCT OVERVIEW

The Rfiver Universal Table Top TV Stand is designed to provide a stable and adjustable base for most LCD, LED, Plasma, OLED, and QLED 4K Smart flat panel/curved screen TVs and monitors. It offers a reliable alternative to wall mounting or original TV feet, allowing for height adjustment and ensuring stability on various surfaces.



Figure 1: Rfiver Universal Table Top TV Stand supporting a television.

KEY FEATURES

- **Universal Compatibility:** Fits most 32-55 inch LCD, LED, Plasma, OLED, and QLED 4K Smart flat panel/curved screen TVs/monitors/PCs with VESA mounting hole patterns between 200x100mm and 800x400mm. *Note: Not compatible with Samsung 55 inch TVs. For TVs larger than 42 inches, VESA is recommended to be above 200x200mm to prevent legs from being too close.*
- **Robust Structure:** Constructed from heavy-duty steel, capable of supporting TVs up to 88 lbs (40 kg). Designed to prevent tilting and shaking, enhancing safety.
- **Adjustable Height:** Features 3 height adjustments, allowing the TV to be mounted between 20.2 inches and 22.5 inches for optimal viewing angles.
- **Non-Scratch & Anti-Slip Protection:** Equipped with soft bottom foot pads to prevent the TV from slipping and to protect furniture surfaces from scratches.

- **Easy Assembly:** Designed for quick and straightforward installation with an included manual and all necessary hardware.



Figure 2: Compatibility and load capacity of the TV stand.



Figure 3: Three height adjustment options for the TV stand.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- TV Stand Legs (2 pieces)
- Vertical Mounting Brackets (2 pieces)
- Mounting Hardware Kit (various screws, nuts, washers, spacers)
- Instruction Manual

3 HEIGHT ADJUSTABLE ENJOY EYE LEVEL COMFORT




Figure 4: Unboxed components of the Rfiver TV Stand.



Figure 5: All necessary parts for installation are included in the package.

SETUP AND ASSEMBLY

The Rfiver Universal Table Top TV Stand is designed for quick and easy assembly, typically taking around 15 minutes. No drilling into walls is required.

1. **Step 1: Assemble the Base.** Attach the vertical mounting brackets to the stand legs using the provided screws. Ensure they are securely fastened.
2. **Step 2: Install on TV.** Carefully place your TV face down on a soft, clean surface. Attach the assembled stand to the VESA mounting holes on the back of your TV using the appropriate screws from the hardware kit. Ensure the stand is centered and aligned with the TV's VESA pattern.
3. **Step 3: Position the TV.** Once the stand is securely attached, carefully lift the TV and place it steadily on your desired table or cabinet.



Figure 6: Quick and easy assembly process.

Your browser does not support the video tag.

Video 1: Official introduction and assembly guide for the Rfiver Table Top TV Stand.

OPERATING INSTRUCTIONS

Height Adjustment

The TV stand allows for three different height settings to optimize your viewing experience. To adjust the height:

1. Carefully remove the TV from the stand. It is recommended to have assistance when handling larger TVs.
2. Locate the multiple mounting holes on the vertical brackets of the stand.
3. Re-attach the TV to the desired set of holes to achieve the preferred height (20.2", 21.3", or 22.5" from the table surface to the bottom of the TV).
4. Ensure all screws are tightened securely before placing the TV back on the table.

3 LEVELS HEIGHT ADJUSTMENT

MULTI HEIGHT FOR EYE LEVEL COMFORT



Figure 7: Adjusting the TV height for optimal viewing comfort.

MAINTENANCE

To ensure the longevity and continued stability of your Rfiver TV stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the stand with a soft, dry cloth to remove dust. For stubborn marks, use a slightly damp cloth and mild detergent, then dry thoroughly. Avoid abrasive cleaners or solvents.
- **Check Connections:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Foot Pads:** Ensure the soft bottom foot pads are intact and clean to prevent slipping and protect furniture surfaces.

TROUBLESHOOTING

If you encounter any issues with your Rfiver Universal Table Top TV Stand, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
TV feels unstable or wobbly.	Loose screws or incorrect assembly. TV size/weight exceeds specifications. Uneven surface.	Ensure all screws connecting the stand to the TV and the stand components themselves are securely tightened. Verify your TV's weight and VESA pattern are within the stand's specifications (max 88 lbs, VESA 200x100mm to 800x400mm). Place the TV stand on a flat, level surface.
TV legs appear crooked or not straight.	Incorrect VESA alignment during installation. TV VESA pattern is too narrow for the stand's design (especially for TVs > 42 inches).	Re-check the VESA mounting points on your TV and ensure the stand's vertical brackets are aligned correctly and parallel. For TVs larger than 42 inches, confirm your TV's VESA is above 200x200mm. If the VESA is too narrow, the legs may appear closer or angled. Ensure the TV is centered on the stand.

Problem	Possible Cause	Solution
Scratches on furniture surface.	Missing or damaged non-slip foot pads.	Verify that the soft bottom foot pads are properly attached to the base of the stand legs. If pads are damaged or missing, contact customer support for replacements.

SPECIFICATIONS

Attribute	Detail
Brand	Rfiver
Model Number	Universal Tabletop TV Base for 32"-55"
Compatible TV Sizes	32-55 inches (LCD, LED, Plasma, OLED, QLED 4K Smart flat panel/curved screen TVs/Monitors/PCs)
Max Load Capacity	88 lbs (40 kg)
VESA Compatibility	200x100mm to 800x400mm
Height Adjustment	3 levels (20.2", 21.3", 22.5" from table to TV bottom)
Material	Heavy-duty Steel
Color	Black
Product Dimensions	1.2 x 14 x 22.5 inches (approximate, as per max height)
Item Weight	3.3 pounds

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Rfiver Universal Table Top TV Stand, please do not hesitate to contact our friendly customer support team. We are committed to providing you with the best possible experience. Please refer to the contact information provided on the product packaging or the official Rfiver website for the most up-to-date support details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question