

[Manuals.plus](#) /

› [VOUNOT](#) /

› VOUNOT 3x3M Folding Garden Gazebo Instruction Manual

VOUNOT 2440966635620

VOUNOT 3x3M Folding Garden Gazebo Instruction Manual

Model: 2440966635620

1. SAFETY INFORMATION

Please read all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- This gazebo is designed for temporary use and is not intended to be left unattended or used during adverse weather conditions such as strong winds, heavy rain, or snow.
- Ensure the gazebo is securely anchored to the ground using the provided pegs, ropes, and sandbags to prevent it from being lifted by wind.
- Be careful to prevent rainwater accumulation on the roof, as excessive weight can damage the frame. Regularly clear any standing water.
- Keep children and pets away from the assembly area to avoid accidents.
- Do not use open flames or heating appliances inside or near the gazebo.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- 1x Folding Gazebo Frame
- 1x Gazebo Roof Canopy (Green)
- 4x Sandbags (for weight)
- 8x Pegs
- 4x Tension Ropes
- 1x Carry Bag
- 1x Instruction Manual



ACCESSOIRES INCLUS ACCESSORIES INCLUDED / ZUBEHÖR INKLUSIVE



Figure 2.1: Included accessories for the VOUNOT Gazebo. This image displays the folding steel frame, the green waterproof roof canopy, a green carry bag, four white tension ropes, eight silver pegs, and four black sandbags.

3. SETUP INSTRUCTIONS

The gazebo features a pop-up design for quick assembly and disassembly. For optimal stability and to prevent damage, two people are recommended for setup.

3.1 Unfolding the Frame

1. Place the folded frame in the desired location.
2. With one person on each side, gently pull the outer legs of the frame outwards. Apply even pressure to ensure the frame expands uniformly.
3. Avoid applying strong pressure to one side or allowing the frame to expand unevenly, as this can damage the connectors.



DIMENSIONI PRODOTTO DIMENSIONI PRODOTTO / DIMENSIONI PRODOTTO



Figure 3.1: Illustration demonstrating the correct method for unfolding the gazebo frame with two people, applying even pressure, versus the incorrect method by one person, which can cause damage.

3.2 Attaching the Roof Canopy

1. Once the frame is partially expanded, place the roof canopy over the top.
2. Align the corners of the canopy with the corners of the frame.
3. Secure the canopy to the frame using the integrated straps or ties.

3.3 Extending the Legs and Securing

1. Fully extend the legs of the gazebo to the desired height, ensuring all locking mechanisms are engaged.
2. Fill the four sandbags with sand and attach them to the gazebo legs for additional weight and stability.
3. Use the provided pegs to anchor the gazebo legs to the ground, especially on soft surfaces like grass.
4. Attach the tension ropes to the corners of the canopy and stake them into the ground at an angle to provide extra wind resistance.



Figure 3.2: Detailed views showing how the roof is secured to the frame, the leg height adjustment mechanism, and a sandbag attached to a gazebo leg for stability.

4. OPERATION

The VOUNOT Folding Garden Gazebo provides a shaded area for various outdoor activities.

- **Sun Protection:** The polyester roof with PA coating offers effective protection from the sun.
- **Versatile Use:** Ideal for family gatherings, picnics, parties, outdoor events, camping, and commercial use.

PIQUE NIQUE PICNIC / PICNICH



JARDIN GARDEN / GARTEN



MARCHÉ MARKET / MARKT



FESTIVAL FESTIVAL / FEST



Figure 4.1: Examples of the gazebo's versatile applications, including picnics, garden relaxation, market stalls, and festivals.

5. MAINTENANCE

Proper maintenance will extend the lifespan of your gazebo.

- **Cleaning:** Clean the canopy and frame with mild soap and water. Avoid harsh chemicals that could damage the fabric or paint.
- **Drying:** Ensure the canopy is completely dry before folding and storing to prevent mold and mildew.
- **Storage:** Store the gazebo in its carry bag in a dry, cool place when not in use.
- **Inspection:** Regularly inspect the frame for any signs of damage or wear. Check all connections and locking mechanisms.
- **Rainwater:** Do not allow rainwater to accumulate on the roof. This can cause the frame to bend or break.

6. TROUBLESHOOTING

Common issues and solutions for your gazebo.

- **Gazebo is unstable:** Ensure all legs are fully extended and locked. Verify that sandbags are filled and attached, and pegs and tension ropes are properly secured.
- **Frame difficult to unfold/fold:** Ensure two people are assisting with the process, applying even pressure. Do not force the frame. Check for any obstructions or bent parts.
- **Water pooling on roof:** This indicates insufficient tension or improper setup. Ensure the canopy is taut and properly secured to the frame. Regularly clear any accumulated water.
- **Damage to frame/connectors:** This often occurs from uneven pressure during setup or use in high winds without proper anchoring. Always assemble with care and secure the gazebo adequately for weather conditions.

7. SPECIFICATIONS

Feature	Specification
Brand	VOUNOT
Model Number	2440966635620
Product Dimensions	3L x 3l x 2.5H meters
Item Weight	10 Kilograms
Frame Material	Alloy Steel (powder-coated)
Canopy Material	Polyester with PA coating
Water Resistance Level	Not water resistant (Note: Canopy is waterproof, but product is not designed for heavy rain/unattended use)
Shape	Square
UV Protection	Sun protection
Assembly Required	Yes
Occupancy	4-6 people
Color	Green

STRUCTURE RÉSISTANTE

RESISTANT FRAME / WIDERSTANDSFÄHIGER RAHMEN



TAILLE PRATIQUE

PRACTICAL FRAME / PRAKTISCHER RAHMEN



TOIT IMPERMÉABLE

WATERPROOF ROOF / WASSERDICHTES DACH



ACCESSOIRES INCLUS

ACCESSORIES INCLUDED / ZUBEHÖR INKLUSIVE



Figure 7.1: Product specifications including dimensions (300cm x 300cm x 220cm height, 30cm roof peak) and folded size (120cm x 20cm x 18cm).

8. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the purchase documentation or contact VOUNOT customer service through the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question