Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > PPLEE /
- Alarm Clock for Bedroom, 7.5" Large Display LED Digital Clock with 7 Color Night Light, USB Phone Charger, Dimmer, Battery Backup, Easy to Set Loud Bedside Clock for Heavy Sleepers Adult Teen Kid Boy Girl Green Digits

PPLEE CR1008

PPLEE Digital Alarm Clock User Manual

Model: CR1008

NTRODUCTION

Thank you for purchasing the PPLEE Digital Alarm Clock. This alarm clock is designed for ease of use and features a large LED display, 7-color night light, dual USB charging ports, adjustable alarm volume, and battery backup. Please read this manual carefully to ensure proper operation and to fully utilize all features of your new alarm clock.

WHAT'S IN THE BOX

- 1 x PPLEE Night Light Alarm Clock
- 1 x Power Adapter
- 1 x USB Cable
- 1 x User Manual
- 1 x Product Box

PRODUCT FEATURES

- Easy to Operate: Simple interface with conspicuous buttons for time and alarm setting.
- Power Options: Plug-in outlet powered with battery backup for settings memory.
- Large Clear Display: 7.5-inch LED display with green digits for easy readability.
- Brightness Dimmer: 0%-100% full range brightness adjustment for comfortable viewing.
- 7-Color Night Light: Integrated night light with 7 color options, easily changed or turned off.
- Adjustable Alarm Volume: 3-level (Low-Medium-High) adjustable alarm volume.
- Snooze Function: 9-minute snooze activated by pressing the SNOOZE button.
- Dual USB Charging Ports: Charge two smart devices simultaneously.
- Time Format & DST: Switch between 12/24-hour format and control Daylight Saving Time.

SETUP

1. Power Connection

Connect the provided power adapter to the DC IN port on the back of the alarm clock and plug it into a wall outlet. The display will light up.





Image: Front view of the PPLEE Digital Alarm Clock displaying green digits and the top light bar showing various colors.

2. Battery Backup Installation (Optional but Recommended)

For memory backup of time and alarm settings during a power outage, install 2 AAA batteries (not included) into the battery compartment on the back of the clock. The batteries will also trigger the alarm if power fails.



Image: Rear view of the alarm clock with the battery compartment open, showing where to insert AAA batteries. USB charging ports are also visible.

OPERATING INSTRUCTIONS

Setting Time

- 1. Press the "SET TIME" button on the back of the clock.
- 2. Use the "HOUR" and "MIN" buttons on the top of the clock to adjust the time.
- 3. Wait for 3-5 seconds for the setting to be confirmed automatically, or press "SET TIME" again to save.

Your browser does not support the video tag.

Video: Demonstrates how to set the time on the PPLEE Digital Alarm Clock using the "SET TIME", "HOUR", and "MIN" buttons.

Setting Alarm

- 1. Slide the "ALARM" switch on the back to the "ON" position.
- 2. Press the "SET ALARM" button on the back.
- 3. Use the "HOUR" and "MIN" buttons on the top to set your desired alarm time.
- 4. Wait for 3-5 seconds for the setting to be confirmed automatically, or press "SET ALARM" again to save.

Your browser does not support the video tag.

Video: Illustrates the process of setting an alarm on the PPLEE Digital Alarm Clock, including activating the alarm and adjusting the time.

Adjusting Display Brightness (Dimmer)

Use the "DIMMER" slider on the back of the clock to adjust the display brightness from 0% (off) to 100% (brightest). This allows you to find the most comfortable viewing level for any environment.



<u>0%-100%</u> BRIGHTNESS DIMMER

Easily adjust to the most comfortable brightness





Image: The alarm clock display is shown with varying brightness levels, from completely off to fully illuminated, demonstrating the dimmer function.

Using the Night Light

Press the large "LIGHT" button on the top of the clock to cycle through 7 different night light colors. Hold the "LIGHT" button to turn the night light off.




Image: The alarm clock's night light feature is displayed, cycling through various colors suitable for different moods or preferences.

Your browser does not support the video tag.

Video: A demonstration of the 7-color changing night light feature of the alarm clock, showing how to cycle through colors and turn it off.

Use the "ALARM VOLUME" slider on the back of the clock to select between Low, Medium, or High alarm volume levels.



Image: A graphic illustrating the three adjustable alarm volume levels (Low, Medium, High) for the alarm clock.

Snooze Function

When the alarm rings, press the large "SNOOZE" button on the top to temporarily turn off the alarm for 9 minutes. The alarm will ring again after 9 minutes unless you press the "ALARM PAUSE" button on the back.

Image: A hand pressing the large snooze button on top of the alarm clock, indicating the snooze function.

Using USB Charging Ports

The two USB ports on the back of the clock allow you to charge your smartphone or other smart devices while the clock is powered on.

DUAL USB CHARGING PORT

Meet different charging needs, fully charged when you wake up in the morning



Image: The alarm clock is shown with two devices (a smartphone and wireless earbuds) connected and charging via its dual USB ports.

12/24 Hour Time Format & DST

Slide the "12H/24H" switch button on the back to choose your preferred time format. To control Daylight Saving Time (DST), hold down the "SET TIME" button.



Image: The alarm clock displays both 12-hour and 24-hour time formats, illustrating the time format selection feature.

MAINTENANCE

- Clean the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the clock away from direct sunlight, extreme temperatures, and high humidity.
- Ensure proper ventilation around the clock, especially when using the USB charging ports.

TROUBLESHOOTING

Problem	Solution
Display is dim or off.	Check power connection. Adjust the "DIMMER" slider on the back.
Alarm does not sound.	Ensure the "ALARM" switch is set to "ON". Check alarm time setting. Adjust "ALARM VOLUME".
USB ports not charging.	Ensure the clock is powered via the AC adapter. USB charging is not supported by battery backup alone.
Time is incorrect after power outage.	Ensure AAA backup batteries are installed and not depleted. Reset time if necessary.

SPECIFICATIONS

Feature	Detail
Brand	PPLEE
Model Number	CR1008
Display Type	Digital LED
Display Size	7.5 inches
Power Source	Corded Electric with Battery Backup (2 AAA batteries, not included)

Feature	Detail
USB Charging Output	Dual USB Ports
Night Light Colors	7 Colors
Alarm Volume Levels	3 (Low, Medium, High)
Snooze Duration	9 minutes
Product Dimensions	6.29"W x 3.22"H
Item Weight	0.7 Pounds (11.2 ounces)

WARRANTY AND SUPPORT

PPLEE offers excellent after-sale service, including a 365-day product warranty, 30-day free return, and 24-hour response for any questions or concerns. Please contact us via Amazon or our support email for assistance.

For additional support, you may refer to the official User Manual (PDF) available at:

https://manuals.plus/m/3785bbedfdf18e213fceea66c8ebdc032d83528bd01befdde23ae815cf421832

Related Documents - CR1008

