

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Smoby](#) /
- › [Smoby 840204 Climbing Tower with Slide and Ladder Instruction Manual](#)

## Smoby 840204

# Smoby 840204 Climbing Tower with Slide and Ladder

Instruction Manual

## 1. IMPORTANT SAFETY INFORMATION

---

Read all instructions before assembly and use of the Smoby 840204 Climbing Tower. Failure to follow these instructions may result in serious injury.

- **Age Recommendation:** This product is intended for children aged 24 months (2 years) and older.
- **Weight Limit:** The maximum weight capacity for this climbing tower is 50 kg (110 lbs). Do not exceed this limit.
- **Supervision:** Adult supervision is required at all times when children are using the climbing tower.
- **Installation:** Ensure the climbing tower is assembled on a level, soft surface such as grass or wood chips, away from fences, trees, or other obstacles.
- **Stability:** Regularly check all connections and fasteners to ensure they are tight and secure. Loose parts can cause instability and injury.
- **Weather Conditions:** Do not use the climbing tower during strong winds, rain, or other adverse weather conditions.
- **Maintenance:** Regularly inspect the product for wear and tear, especially plastic parts and connections. Replace any damaged parts immediately.
- **Outdoor Use:** This product is designed for outdoor use. The plastic components are treated with anti-UV to ensure durability and color retention over time.

## 2. PARTS LIST

---

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- Climbing Tower Structure (various plastic panels)
- Slide (1.5 meters in length)
- Ladder
- Platform components
- Climbing walls with integrated sockets (3 sections)
- Fasteners and connectors (screws, caps, etc.)
- Assembly Tool (if included)



Figure 2.1: Fully assembled Smoby 840204 Climbing Tower. This image shows the complete structure including the slide, climbing walls, and platform.

### 3. SETUP AND ASSEMBLY INSTRUCTIONS

---

Assembly of the Smoby 840204 Climbing Tower requires adult supervision and may take approximately 1-2 hours. It is recommended to have two adults for easier assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Compare with the parts list to ensure everything is present.
2. **Assemble Base Structure:** Begin by connecting the main base panels of the tower. Ensure all connections are firm and secure.
3. **Attach Climbing Walls:** Secure the three climbing wall sections to the main tower structure. These walls feature integrated hand and foot holds.
4. **Install Platform:** Mount the platform components at the top of the climbing tower. This platform serves as an access point to the slide.
5. **Connect Slide:** Attach the 1.5-meter slide to the platform. Ensure the slide is securely fastened and stable.
6. **Attach Ladder:** Secure the ladder to the designated access point on the tower, providing an alternative route to the platform.
7. **Final Inspection:** Once assembled, thoroughly check all screws, bolts, and connections to ensure they are tightened correctly. Shake the structure gently to confirm stability.



*Figure 3.1: Detail of a child utilizing one of the climbing wall sections. The climbing walls are designed with integrated sockets for hand and foot placement.*

## 4. OPERATING INSTRUCTIONS

---

The Smoby 840204 Climbing Tower offers multiple activities for children. Always ensure children are supervised during play.

- **Climbing:** Children can ascend the tower using the three climbing walls, which feature various hand and foot holds.
- **Sliding:** Once on the platform, children can use the 1.5-meter slide to descend. Ensure the landing area is clear.
- **Ladder Access:** An alternative to the climbing walls, the ladder provides another way to reach the platform.
- **Hideaway/Play Area:** The base of the tower and areas under the slide can be used as hideaways or imaginative play spaces.
- **Water Feature (Optional):** On warm days, a garden hose can be connected to the slide to create a water cascade, enhancing the sliding experience. Ensure the water flow is gentle and the landing area remains safe.



*Figure 4.1: A child inside the tower structure, demonstrating the hideaway or play area feature. The tower provides enclosed spaces for imaginative play.*



Figure 4.2: A child sitting comfortably under the slide, illustrating another potential hideaway or shaded play spot within the structure.

## 5. MAINTENANCE

---

Regular maintenance ensures the longevity and safety of your Smoby 840204 Climbing Tower.

- **Cleaning:** Clean the plastic surfaces regularly with mild soap and water. Avoid abrasive cleaners or solvents that could damage the material.
- **Fastener Check:** Periodically check all screws, bolts, and connections. Tighten any loose fasteners to maintain structural integrity.
- **UV Protection:** The plastic components are treated with anti-UV to resist fading and degradation from sun exposure. However, prolonged exposure to extreme weather may still affect the material over many years.
- **Inspection for Damage:** Inspect the entire structure for cracks, sharp edges, or other damage, especially after severe weather. Replace any damaged parts immediately.
- **Winter Storage:** While designed for outdoor use, consider covering the climbing tower or storing it indoors during harsh winter months to extend its lifespan.

## 6. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your climbing tower.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Tower feels wobbly or unstable.	Loose fasteners or uneven ground.	Check and tighten all screws and connections. Ensure the tower is placed on a firm, level surface.
Plastic parts appear faded.	Prolonged exposure to direct sunlight.	While UV-treated, extreme sun exposure over many years can cause some fading. This typically does not affect structural integrity.
Difficulty connecting parts during assembly.	Misalignment or incorrect orientation.	Refer to the assembly diagrams (if provided in a physical manual). Ensure parts are oriented correctly before applying force. Do not force connections.

## 7. SPECIFICATIONS

<b>Brand:</b>	Smoby
<b>Model Number:</b>	840204
<b>Material:</b>	Plastic (Anti-UV treated)
<b>Item Weight:</b>	14 Kilograms
<b>Maximum Weight Recommendation:</b>	50 Kilograms
<b>Minimum Age Recommendation:</b>	24 Months (2 Years)
<b>Slide Length:</b>	1.5 meters
<b>Included Components:</b>	1 tower with 1 slide, 3 climbing walls, 1 platform, 1 ladder
<b>Assembly Required:</b>	Yes

## 8. WARRANTY AND CUSTOMER SUPPORT

For warranty information, missing parts, or technical assistance, please contact Smoby customer support directly. Refer to the product packaging or the official Smoby website for contact details.

**Manufacturer:** SMOBY

**Manufacturer Part Number:** 7600840204

