Picket House DGD100SV

Picket House Furnishings Jasper Buffet Table & Sideboard User Manual

Model: DGD100SV

1. Introduction

Thank you for choosing the Picket House Furnishings Jasper Buffet Table & Sideboard. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions thoroughly before beginning assembly and retain them for future reference.



Figure 1: Front view of the Jasper Buffet Table & Sideboard, showcasing its dark walnut finish, multiple drawers, cabinet doors, and central wine rack.

2. Important Safety Information

WARNING: This product can expose you to chemicals including Formaldehyde, which is known to the State of California to cause cancer. For more information, go to www.P65Warnings.ca.gov.

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload drawers or shelves. Distribute weight evenly.
- For safety, this unit includes anti-tipping hardware. It is crucial to install this hardware to prevent serious injury from tipping furniture.
- Keep small parts and packaging materials away from children.

3. Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Main Buffet Table/Sideboard Unit
- Four (4) Drawers
- Two (2) Adjustable/Removable Shelves
- Hardware Pack (screws, bolts, anti-tipping kit, etc.)

- Assembly Instructions (this document)

4. Assembly Instructions

Assembly is required for this product. It is recommended that two adults assemble this unit. Please follow these steps carefully.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent damage. Identify all parts against the provided parts list (if included separately) and the hardware pack.
2. **Attach Legs/Base:** Secure the base or legs to the main body of the buffet table using the provided hardware. Ensure they are firmly attached and stable.
3. **Install Drawer Glides:** If not pre-installed, attach the drawer glides to the interior of the buffet table and to the sides of the drawers according to the hardware instructions.
4. **Assemble Drawers:** Construct the four drawers. Insert the drawer bottoms and secure the front, back, and side panels. Attach the drawer pulls to the front of each drawer.
5. **Insert Drawers:** Carefully slide the assembled drawers into their respective compartments, ensuring they operate smoothly.
6. **Install Cabinet Doors:** Attach the cabinet doors to the main unit using the provided hinges. Adjust hinges as needed for proper alignment. Attach the cabinet pulls.
7. **Place Shelves:** Insert the adjustable shelves into the cabinet sections at your desired height.
8. **Install Anti-Tipping Hardware:** This is a critical safety step. Securely attach the anti-tipping device to the back of the buffet table and to a wall stud using the provided hardware. Follow the specific instructions included with the anti-tipping kit.



Figure 2: Product dimensions, illustrating the overall width, height, and depth of the unit.

5. Product Features and Operation

The Jasper Buffet Table & Sideboard is designed for versatile storage and display.

5.1 Drawers

The unit features four spacious drawers, including brown, felt-lined top drawers. To open, gently pull the dark metal hardware handle. To close, push the drawer back until it is fully seated. Avoid slamming drawers to ensure longevity of the glides.



Figure 3: An open drawer, highlighting the felt-lined interior of the top drawers.

5.2 Cabinets

Two cabinets are located on either side of the central section. Each cabinet contains an adjustable and removable shelf. To open, pull the dark metal hardware handle. To adjust or remove a shelf, carefully lift the shelf and reposition it on the desired shelf pins, or remove it entirely for larger items.



Figure 4: An open cabinet door, showing the interior with an adjustable shelf.

5.3 Open Cubby Space / Wine Rack

The central open cubby space features an X-shaped divider, ideal for storing wine bottles or other decorative items. This section is fixed and not adjustable.



Figure 5: Detail of the central wine rack cubby.

6. Maintenance and Care

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat and Moisture:** Protect the surface from extreme heat and moisture. Use coasters under beverages and

hot pads under hot dishes.

- **Hardware:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten as needed.

7. Troubleshooting

- **Drawers stick or do not close smoothly:** Check that the drawer glides are properly aligned and free of obstructions. Ensure all screws on the glides are tight.
- **Cabinet doors are misaligned:** Adjust the hinges on the cabinet doors. Most hinges allow for minor adjustments to align the door properly.
- **Unit wobbles:** Ensure the unit is placed on a level surface. Check that all leg attachments and frame connections are securely tightened. Verify anti-tipping hardware is correctly installed.
- **Scratches or minor damage:** For minor scratches, touch-up pens or furniture repair kits matching the dark walnut finish may be used. Consult a professional for significant damage.

8. Specifications

Feature	Detail
Brand	Picket House
Model Name	Jasper Server
Model Number	DGD100SV
Color	Dark Walnut
Product Dimensions	18"D x 60"W x 42"H
Item Weight	166 Pounds
Frame Material	Wood
Finish Type	Wood
Mounting Type	Floor Mount
Assembly Required	Yes
Number of Drawers	4
Number of Cabinets	2
Number of Shelves	2 (adjustable/removable)

9. Warranty and Customer Support

Picket House Furnishings stands behind the quality of its products. For specific warranty information, please refer to the documentation included with your purchase or visit the official Picket House Furnishings website. If you have any questions, require replacement parts, or need assistance with assembly or operation, please contact Picket House Furnishings customer support directly.
Contact information can typically be found on the manufacturer's website or on your purchase receipt.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question