

[Manuals.plus](#) /

› [Wildgame Innovations](#) /

› Wildgame Innovations Terra 12 MP HD Infrared Digital Game Camera User Manual

Wildgame Innovations SG_B07KT917G4_US

Wildgame Innovations Terra 12 MP HD Infrared Digital Game Camera User Manual

Model: SG_B07KT917G4_US

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Wildgame Innovations Terra 12 MP HD Infrared Digital Game Camera. Please read this manual thoroughly before using the camera to ensure optimal performance and longevity.



Image: The Wildgame Innovations Terra 12 MP HD Infrared Digital Game Camera, shown with a SanDisk 8GB SD card and a pack of Duracell AA batteries. The camera is black, featuring an array of infrared LEDs at the top, a central lens, and a small display screen at the bottom. It has a rugged design suitable for outdoor use.

SETUP

1. Battery Installation

The Terra 12 MP camera requires 8 AA batteries for operation. Ensure batteries are inserted with correct polarity as indicated inside the battery compartment.

- Open the battery compartment latch.
- Insert 8 new AA batteries, observing the positive (+) and negative (-) markings.
- Close the battery compartment securely to ensure a watertight seal.

2. SD Card Installation

A compatible SD card (up to 32GB, Class 4 or higher recommended) is required to store images and videos. An 8GB SD

card is typically included.

- Locate the SD card slot, usually near the battery compartment or on the side of the camera.
- Insert the SD card with the metal contacts facing down until it clicks into place.
- To remove, press the card in until it springs out.

3. Initial Power On and Basic Settings

After installing batteries and SD card, power on the camera to configure basic settings.

- Switch the camera to the "SETUP" or "ON" position.
- The display screen will activate.
- Use the navigation buttons (usually UP, DOWN, LEFT, RIGHT, OK/ENTER) to set the current date, time, and year.
- Format the SD card through the camera's menu system to ensure compatibility and optimal performance. This will erase all data on the card.

OPERATING INSTRUCTIONS

1. Mounting the Camera

Proper placement is crucial for effective scouting.

- Mount the camera to a sturdy tree or post using the included strap or a compatible mounting accessory.
- Position the camera approximately 3-6 feet (1-2 meters) off the ground, aiming towards the area of interest.
- Avoid pointing the camera directly at the rising or setting sun to prevent overexposure.
- Clear any brush or obstacles from the camera's field of view to prevent false triggers.

2. Menu Navigation and Settings

The camera's menu allows customization of various parameters.

- **Mode:** Select between Photo, Video, or Photo+Video mode.
- **Resolution:** Adjust image (e.g., 12 MP) and video (e.g., HD) resolution. Higher resolution consumes more storage.
- **Trigger Speed:** Set the delay before the camera takes a picture or video after detecting motion (e.g., 1 second).
- **Detection Delay:** Configure the time interval between consecutive captures after an initial trigger.
- **Flash Mode:** Infrared LEDs provide discreet night vision up to 60 feet.
- **Time Stamp:** Enable or disable date and time overlay on images/videos.

3. Activating Surveillance Mode

Once settings are configured, switch the camera to "ON" mode to begin monitoring.

- After setting up, switch the camera from "SETUP" to "ON".
- The camera will typically enter a brief countdown before activating its motion sensor.
- The indicator light (if present) will flash during the countdown and then turn off, indicating the camera is actively monitoring.

MAINTENANCE

1. Battery Replacement

Regularly check battery levels, especially before extended deployment.

- Replace all batteries simultaneously with new, high-quality alkaline or lithium batteries.
- Do not mix old and new batteries, or different battery types.

2. SD Card Management

Periodically retrieve and review captured media.

- Remove the SD card safely by switching the camera to "OFF" mode first.
- Transfer media to a computer or other storage device.
- Format the SD card in the camera after transferring files to ensure optimal performance and prevent data corruption.

3. Cleaning and Storage

Keep the camera clean for clear images and reliable operation.

- Wipe the lens and infrared LEDs with a soft, lint-free cloth.
- Ensure the camera housing and seals are free of dirt and debris.
- When storing for extended periods, remove batteries to prevent leakage. Store in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera not powering on	Incorrect battery installation; Dead batteries; Corroded battery terminals	Check battery polarity; Replace all batteries; Clean terminals with a pencil eraser.
No images/videos captured	SD card full or corrupted; Incorrect settings; PIR sensor blocked; Camera in OFF mode	Format or replace SD card; Verify settings (mode, sensitivity); Clear obstructions; Ensure camera is in ON mode.
Poor image quality (blurry, dark)	Dirty lens; Low light conditions; Subject too far; Incorrect resolution setting	Clean lens; Ensure adequate lighting or use flash; Adjust camera placement; Increase resolution setting.
Excessive blank images	PIR sensor detecting moving branches/grass; Camera pointed at sun	Clear vegetation from detection zone; Reposition camera away from direct sunlight.

SPECIFICATIONS

Model: Wildgame Innovations Terra 12 MP HD Infrared Digital Game Camera

Part Number: SG_B07KT917G4_US

Image Resolution: 12 Megapixels

Video Resolution: HD (15-second clips)

Trigger Speed: 1 second

Flash Type: High-intensity LED Infrared

Flash Range: Up to 60 feet

Power Source: 8 AA Batteries (included)

Storage: SD Card (up to 32GB, 8GB included)

Color: Black

Dimensions: Approximately 14.8 x 10.39 x 2.6 inches (Package Dimensions)

Weight: Approximately 0.7 Kilograms (Package Weight)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Wildgame Innovations website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

Wildgame Innovations Customer Service: [Visit Wildgame Innovations Support Page](#)

© 2024 Wildgame Innovations. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question