Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BCXY CS-ECH311BL

Replacement Battery User Manual

Model: CS-ECH311BL

Product Overview

This manual provides essential information for the safe and effective use of the BCXY Replacement Battery, model CS-ECH311BL. This battery is designed as a replacement for specific ELCA devices.



Image: The BCXY Replacement Battery, showing its label with model and part numbers.

Compatible Models:

- ELCA EVO
- ELCA MAGO-EVO
- ELCA MITO-VETTA
- ELCA VETTA

Compatible Battery Part Number: ELCA 0401BA000311

Safety Information and Warnings

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in fire, electric shock, injury, or damage to the battery or device.

- **DO NOT ATTEMPT TO DISASSEMBLE, OPEN OR SERVICE THE BATTERY PACK.**
- **REPLACE ONLY WITH THE BATTERY PACK DESIGNATED FOR THIS PRODUCT.**
- **DO NOT CRUSH, PUNCTURE, SHORT EXTERNAL CONTACTS OR DISPOSE OF IN FIRE OR WATER.**
- **DO NOT STORE ABOVE 60°C (140°F).**
- **NEW BATTERY PACK MUST BE FULLY CHARGED BEFORE USE.**
- **TO REDUCE RISK OF FIRE OR BURNS, READ INSTRUCTIONS IN OPERATING GUIDE BEFORE USING THE BATTERY.**

This battery is certified with ISO9001, RoHS, and CE standards, ensuring quality and safety compliance.

Setup and Installation

Before installation, ensure your device is powered off and disconnected from any power source. Refer to your device's original instruction manual for specific battery replacement procedures.

1. **Power Off Device:** Ensure the ELCA device is completely turned off and unplugged.
2. **Locate Battery Compartment:** Identify the battery compartment on your ELCA device. This typically involves opening a cover or panel.
3. **Remove Old Battery:** Carefully disconnect and remove the old battery. Note the orientation of the connector.
4. **Insert New Battery:** Align the connector of the new BCXY replacement battery (Model: CS-ECH311BL) with the port in your device. Gently push the connector until it clicks into place.



Image: Close-up view of the battery's 3-pin connector, showing its design for proper insertion.

5. **Secure Battery:** Place the new battery securely within the compartment.
6. **Close Compartment:** Reattach the battery compartment cover or panel.
7. **Initial Charge:** It is recommended to fully charge the new battery before its first use.

Operating Instructions

Once the battery is installed and fully charged, your ELCA device should operate as normal. The battery provides reliable power for your compatible device.

- **Charging:** Use only the original or manufacturer-approved charger for your ELCA device. The battery's limited charge voltage is 4.2V±0.05V.
- **Usage:** Operate your device within its specified temperature ranges. Avoid extreme hot or cold environments.
- **Discharge:** Avoid completely draining the battery frequently, as this can reduce its lifespan.

Maintenance and Storage

Proper maintenance and storage will extend the life of your battery.

- **Regular Charging:** For optimal performance, charge the battery regularly, even if the device is not in frequent use.
- **Storage:** If storing the battery for an extended period, store it in a cool, dry place at approximately 50% charge. Do not store above 60°C (140°F).
- **Cleaning:** Keep battery contacts clean and free of dust or debris. Use a dry cloth to wipe them if necessary.
- **Disposal:** Dispose of old batteries responsibly according to local regulations. Do not dispose of batteries in household waste or fire.

Troubleshooting

If you experience issues with your replacement battery, consider the following common solutions:

Problem	Possible Cause	Solution
Device not powering on after battery installation.	Battery not fully charged, or not properly connected.	Ensure the battery is fully charged. Re-check the battery connection to ensure it is securely seated.
Battery not holding a charge.	Incorrect charging method, or battery lifespan reached.	Ensure you are using the correct charger. If the battery is old, it may need replacement.
Battery overheating during use or charging.	Faulty battery or charger, or improper ventilation.	Immediately discontinue use and charging. Contact support if the issue persists. Ensure device ventilation is not blocked.

If troubleshooting steps do not resolve the issue, please contact customer support.

Specifications

Detailed technical specifications for the BCXY Replacement Battery (Model: CS-ECH311BL).

Model Number: CS-ECH311BL

Part Number: 0401BA000311

Battery Type: Li-Polymer

Capacity: 1250mAh

Voltage: 3.7V

Limited Charge Voltage: 4.2V ± 0.05V

Dimensions: 59.70 x 37.10 x 6.30 mm (2.35 x 1.46 x 0.25 inches)

Item Weight: 2.12 ounces

Reusability: Rechargeable

Certifications: ISO9001, RoHS, CE

Standard: GB 31241-2014

Manufacturer: Cameron Sino

Barcode/UPC: 4894128126966



Image: Detailed view of the battery label, displaying model number, part number, voltage, capacity, and warning information.

Warranty and Support

For warranty information or technical support regarding your BCXY Replacement Battery, please refer to the seller's policy or contact the manufacturer directly.

Tips Before Purchase: Please confirm the compatible model and battery part number carefully before you purchase it. If you are not sure, please send email to us with your battery details or pictures, we will give you professional suggestions.

For further assistance, you may visit the BCXY Store on Amazon.

© 2024 BCXY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07KVJCTS9

More documents and user manuals: **https://manuals.plus/**