# **Fatboy ETPSNG-WHT-UL**

# **Fatboy Edison The Petit Lamp - Instruction Manual**

Model: ETPSNG-WHT-UL | Brand: Fatboy

#### 1. Introduction

Welcome to the world of Fatboy Edison The Petit Lamp. This rechargeable, portable LED light is designed to provide a gentle yet powerful light source wherever you need it. Its sleek, minimalist design and durable





Figure 1: Front view of the Fatboy Edison The Petit Lamp.

#### 2. SETUP

- 1. **Unpacking:** Carefully remove the lamp and all accessories from the packaging. Ensure all components are present: the Edison The Petit Lamp, and the USB charging cable.
- Initial Charge: Before first use, fully charge the lamp. Connect the USB charging cable to the charging
  port located at the bottom of the lamp. Plug the other end into a compatible USB power adapter (not
  included). A flashing red light on the bottom indicates that the lamp is charging. A full charge typically
  takes 3 hours.
- 3. **Placement:** The lamp is designed for portability and can be placed on any flat, stable surface. Its splash-resistant design makes it suitable for outdoor use, but avoid submerging it in water.



Figure 2: Angled view of the lamp, highlighting its compact design.

The Fatboy Edison The Petit Lamp features a simple pull-chain mechanism for operation and brightness adjustment.

- 1. **Power On/Off:** Gently pull the red Fatboy tag located beneath the lamp shade. The lamp will turn on at its lowest brightness setting. Pull the tag again to cycle through the brightness levels. A final pull will turn the lamp off.
- 2. **Adjusting Brightness:** The lamp has three distinct brightness levels: low, medium, and high. Each pull of the tag will advance to the next brightness level.
- 3. **Battery Life:** On a full charge, the lamp can glow for up to 8 hours on the highest power setting. Battery life may vary based on usage and selected brightness level.



Figure 3: The lamp's compact size allows for easy portability.

#### 4. MAINTENANCE

To ensure the longevity and optimal performance of your Fatboy Edison The Petit Lamp, follow these simple maintenance guidelines:

- **Cleaning:** The lamp's outer part is made of robust polyethylene, making it easy to clean. Use lukewarm water and a neutral soap with a soft cloth. Avoid abrasive cleaners or harsh chemicals.
- **Storage:** When not in use for extended periods, store the lamp in a cool, dry place. Ensure it is fully charged before storage to maintain battery health.
- **Battery Care:** To maximize battery lifespan, avoid completely draining the battery frequently. Recharge the lamp when the red indicator light begins to flash.

## 5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted.	Charge the lamp for at least 3 hours. Check if the red indicator light flashes during charging.
Lamp does not hold a charge for long.	Continuous use on highest setting; battery degradation over time.	Reduce brightness setting for longer use. Ensure full charge before use. If issues persist after prolonged use, battery may need replacement (contact support).
Light flickers or is dim.	Low battery.	Recharge the lamp fully.

## 6. SPECIFICATIONS

Feature	Detail
Model Name	Edison the Petit
Model Number	ETPSNG-WHT-UL
Dimensions (H x D)	10 inches x 6.5 inches
Weight	1 Pound
Light Source Type	LED
Brightness	58.76 Lumen
Wattage	1 watts
Voltage	3.7 Volts
Power Source	Battery Powered (1 Lithium Ion battery required)

Feature	Detail
Charging Time	Approx. 3 hours for full charge
Run Time (Highest Setting)	Up to 8 hours
Material	Polyethylene (outer part)
Water Resistance Level	Water Resistant (splash resistant)
Switch Type	Pull Chain

# 7. WARRANTY AND SUPPORT

For specific warranty information regarding your Fatboy Edison The Petit Lamp, please refer to the documentation included with your purchase or visit the official Fatboy website. For technical support, replacement parts, or any other inquiries, please contact Fatboy customer service through their official channels.

© 2024 Fatboy. All rights reserved.