

Cellularline MUSICCAP18K

Cellularline Music Cap Bluetooth Beanie Instruction Manual

Model: MUSICCAP18K

1. INTRODUCTION

Thank you for choosing the Cellularline Music Cap. This Bluetooth beanie integrates stereo earphones and a microphone, allowing you to enjoy music and manage calls wirelessly while staying warm. This manual provides essential information for the proper use and maintenance of your Music Cap.

2. SAFETY INFORMATION

- Do not expose the device to extreme temperatures, moisture, or corrosive substances.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or modify the device. This may void the warranty and cause damage.
- Keep the device away from children.
- Do not use the device at excessively high volumes for extended periods, as this may cause hearing damage.
- This product is not water resistant. Avoid exposure to rain or submersion in water.

3. PACKAGE CONTENTS

Please check that all items are present in the package:

- 1 x Cellularline Music Cap (Grey)
- 1 x Charging Cable
- 1 x Instruction Manual (this document)

4. PRODUCT OVERVIEW

The Cellularline Music Cap features integrated stereo earphones and a control panel for easy operation. The control panel is typically located on the side of the beanie.



This image displays the Cellularline Music Cap, a grey knitted beanie with a small control panel on the side. The control panel features a Bluetooth logo and buttons for playback control. Blue sound wave graphics illustrate the wireless connection between the beanie's integrated earphones and a smartphone displaying a music player interface.

Key Components:

- **Integrated Earphones:** Stereo audio output.
- **Control Panel:** Buttons for power, volume, track control, and call management.
- **Microphone:** For hands-free calling.
- **Charging Port:** For recharging the internal battery.

5. SETUP

5.1. Charging the Music Cap

1. Locate the charging port on the Music Cap (usually near the control panel).
2. Connect the provided charging cable to the Music Cap's charging port.
3. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
4. An indicator light will typically show the charging status. Refer to the indicator light behavior for full charge status (e.g., solid red while charging, off or blue when fully charged).

5. Allow sufficient time for a full charge before first use.

5.2. Bluetooth Pairing

To connect your Music Cap to a Bluetooth-enabled device (e.g., smartphone, tablet):

1. Ensure the Music Cap is fully charged.
2. Press and hold the Power/Multi-function button on the control panel until the indicator light flashes (often blue and red alternately), indicating pairing mode.
3. On your device, enable Bluetooth and search for available devices.
4. Select "Cellularline Music Cap" or a similar name from the list of found devices.
5. Once paired, the indicator light on the Music Cap will usually turn solid blue or flash slowly, and you will hear an audible confirmation.
6. If prompted for a password, enter "0000" (four zeros).

The Music Cap will usually automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.

6. OPERATING THE MUSIC CAP

6.1. Power On/Off

- **Power On:** Press and hold the Power/Multi-function button for approximately 3 seconds until the indicator light turns on and you hear an audible prompt.
- **Power Off:** Press and hold the Power/Multi-function button for approximately 3-5 seconds until the indicator light turns off and you hear an audible prompt.

6.2. Music Playback

- **Play/Pause:** Press the Power/Multi-function button once.
- **Next Track:** Press the "+" button once.
- **Previous Track:** Press the "-" button once.
- **Volume Up:** Press and hold the "+" button.
- **Volume Down:** Press and hold the "-" button.

6.3. Call Management

- **Answer Call:** Press the Power/Multi-function button once when a call comes in.
- **End Call:** Press the Power/Multi-function button once during a call.
- **Reject Call:** Press and hold the Power/Multi-function button for approximately 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the Power/Multi-function button.

7. CARE AND MAINTENANCE

- **Cleaning:** The electronic components are removable. Gently remove the integrated earphones and control panel before hand washing the beanie with mild soap and cold water. Allow the beanie to air dry completely before reinserting the electronics.
- **Storage:** Store the Music Cap in a cool, dry place when not in use.

- **Battery:** To prolong battery life, charge the device regularly, even if not used frequently.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the Music Cap fully.
Cannot pair with device.	Bluetooth is off on your device; Music Cap is not in pairing mode; device is out of range.	Ensure Bluetooth is enabled on your device. Put Music Cap into pairing mode (flashing blue/red). Move devices closer.
No sound.	Volume too low; device not connected; media not playing.	Increase volume on both Music Cap and connected device. Verify successful Bluetooth connection. Ensure media is playing on your device.
Poor sound quality.	Interference; device too far from Music Cap.	Move closer to the connected device. Avoid obstacles between devices.

9. SPECIFICATIONS

- **Model:** MUSICCAP18K
- **Brand:** Cellularline
- **Color:** Grey
- **Connectivity Technology:** Wireless (Bluetooth)
- **Ear Placement:** On-ear (integrated)
- **Form Factor:** Supraaural (integrated)
- **Control Type:** Media control
- **Compatible Devices:** Mobile phones, Tablets
- **Specific Product Uses:** Music, Communication
- **Recommended Product Uses:** Music listening, Calling, Cycling, Running, Exercise
- **Water Resistance Level:** Not water resistant
- **Item Weight:** 200 g
- **Package Dimensions:** 26.01 x 23.01 x 2.01 cm
- **Model Year:** 2018

10. WARRANTY INFORMATION

Specific warranty details for the Cellularline Music Cap are typically provided at the point of purchase or within separate warranty documentation included with the product. Please retain your proof of purchase for warranty claims.

For detailed warranty terms and conditions, please refer to the official Cellularline website or contact their customer support.

11. CUSTOMER SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact Cellularline customer support.

You can usually find contact information on the official Cellularline website:


www.cellularline.com

Please have your product model (MUSICCAP18K) and proof of purchase ready when contacting support.

© 2023 Cellularline. All rights reserved.

Related Documents - MUSICCAP18K

	<p>Music Sound MAXI 2 Bluetooth Headphones - User Manual & Specifications</p> <p>Comprehensive guide to the Music Sound MAXI 2 Bluetooth headphones by Cellularline, detailing features, specifications, usage instructions for pairing and multi-device connection, safety warnings, and disposal information. Includes Bluetooth v5, 16-hour battery life, and quick charging.</p>
	<p>Cellularline MUSIC SOUND Wireless Stereo Bluetooth Headphones User Manual</p> <p>This document provides instructions for setting up, using, and maintaining the Cellularline MUSIC SOUND Wireless Stereo Bluetooth Headphones with Charging Case. It includes details on pairing, call handling, audio controls, charging, reset procedures, and technical specifications.</p>
	<p>Music Sound SHOWY Wireless Earbuds - User Manual & Specifications</p> <p>Comprehensive user manual and technical specifications for the Music Sound SHOWY wireless earbuds, including setup, operation, and safety information.</p>
	<p>Cellularline MUSIC SOUND DRIP Wireless Earbuds: User Manual, Specs & How-To Guide</p> <p>User manual and technical specifications for the Cellularline MUSIC SOUND DRIP wireless earbuds. Learn how to charge, pair, control music, and reset your earbuds. Includes safety warnings and warranty information.</p>
	<p>Cellularline Music Sound Vertical Portable Bluetooth Speaker - User Manual and Specifications</p> <p>User manual and technical specifications for the Cellularline Music Sound Vertical portable Bluetooth speaker. Learn about its features, operation, connectivity, safety guidelines, and compliance.</p>



[Cellularline KEEN Bluetooth Earbuds - User Manual & Specifications](#)

Comprehensive guide to Cellularline KEEN Bluetooth earbuds, including setup, usage, touch controls, technical specifications, safety information, and compliance details.