

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [JAKKS Pacific](#) /
- › [JAKKS Pacific Sonic Articulated Figure User Manual](#)

JAKKS Pacific S7195316

JAKKS Pacific Sonic Articulated Figure User Manual

Model: S7195316

1. INTRODUCTION

This manual provides essential information for the proper use and care of your JAKKS Pacific Sonic Articulated Figure set. This product is designed for recreational play and features articulated joints for posing.

The set includes three articulated figures: Sonic the Hedgehog, Dr. Eggman, and Metal Sonic. Each figure is designed with multiple points of articulation, allowing for various poses and dynamic display.

2. PACKAGE CONTENTS

Please verify that all items listed below are present in your package:

- 1 x Sonic the Hedgehog Articulated Figure
- 1 x Dr. Eggman Articulated Figure
- 1 x Metal Sonic Articulated Figure



Figure 1: The Jakks Pacific Sonic 30th Anniversary Articulated Figure Multi-Pack, featuring Sonic, Dr. Eggman, and Metal Sonic figures.

The figures are displayed within their clear plastic packaging, highlighting their articulated design.

3. SETUP

1. **Unboxing:** Carefully remove the figures from their packaging. Be mindful of any ties or plastic restraints.
2. **Inspection:** Inspect each figure for any visible damage or manufacturing defects. If any issues are found, refer to the Warranty & Support section.
3. **Initial Posing:** Gently manipulate the articulated joints to understand their range of motion. Avoid excessive force to prevent damage.

4. OPERATING

The Jakks Pacific Sonic Articulated Figures are designed for interactive play and display. Their articulation allows for a variety of poses.

- **Posing:** Gently bend and rotate the joints at the neck, shoulders, elbows, hips, and knees (where applicable) to achieve desired poses.
- **Display:** The figures can be displayed on flat surfaces. Some poses may require careful balancing.
- **Intended Use:** These figures are suitable for indoor and outdoor play, but prolonged exposure to harsh weather conditions should be avoided.

5. MAINTENANCE

Proper care will help maintain the condition and longevity of your figures.

- **Cleaning:** To clean the figures, wipe them gently with a soft, damp cloth. Do not use harsh chemicals, abrasive cleaners, or solvents, as these may damage the paint or plastic.
- **Storage:** Store figures in a cool, dry place away from direct sunlight and extreme temperatures to prevent discoloration or material degradation.
- **Handling:** Avoid dropping the figures or applying excessive force to the joints, which could lead to breakage.

6. TROUBLESHOOTING

This section addresses common minor issues you might encounter.

Issue	Possible Cause	Solution
Joints are stiff or difficult to move.	New figures may have tight joints.	Gently work the joint back and forth to loosen it. Do not force it. Applying a very small amount of silicone lubricant (not oil-based) can help, but is generally not recommended for toys.
Figure does not stand upright.	Improper balance or pose.	Adjust the figure's stance and limb positions to find a stable center of gravity. Ensure feet are flat on the surface.
Paint appears faded or chipped.	Normal wear and tear, or exposure to harsh conditions.	This is typically cosmetic and not repairable. Avoid prolonged exposure to direct sunlight or abrasive surfaces.

7. SPECIFICATIONS

Attribute	Detail
Product Dimensions	5.83 x 11.18 x 3.31 inches (packaging)
Item Weight	13.7 ounces
Manufacturer	Jakks Pacific
Model Number	S7195316
ASIN	B07KXHLGC4
Number of Pieces	3 (figures)
Batteries Required	No
Recommended Use	Indoor, Outdoor
Finish Type	Glossy

8. SAFETY INFORMATION

Please read and adhere to the following safety guidelines:

- **Age Recommendation:** This product is recommended for ages 3 and up.
- **Choking Hazard:** The figures contain small parts which may pose a choking hazard to young children. Keep away from children under 3 years of age.
- **Supervision:** Adult supervision is recommended during play, especially with younger children.
- **Avoid Misuse:** Do not throw, hit, or step on the figures, as this may cause damage to the product or injury.

9. WARRANTY & SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the retailer's policy where the product was purchased or visit the official JAKKS Pacific website for customer service contact details.

Please retain your proof of purchase for any warranty claims.

