

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Peg-Pérego](#) /

› [Peg-Pérego Chassis ICBT0000NL31 Instruction Manual](#)

Peg-Pérego ICBT0000NL31

Peg-Pérego Chassis ICBT0000NL31 Instruction Manual

Model: ICBT0000NL31

1. INTRODUCTION

This instruction manual provides essential information for the correct assembly, operation, maintenance, and troubleshooting of your Peg-Pérego Chassis, model ICBT0000NL31. Please read this manual thoroughly before using the product to ensure safe and efficient operation. Keep this manual for future reference.

2. SAFETY INFORMATION

Always prioritize safety when using the chassis. Failure to follow these instructions could result in serious injury.

- Ensure all locking mechanisms are engaged before placing a child in the stroller or using the chassis.
- Never leave a child unattended in the stroller.
- Do not overload the storage basket. Refer to the specifications for maximum weight capacity.
- Always use the parking brake when the stroller is stationary.
- Keep children clear of moving parts during folding and unfolding operations.
- Regularly inspect the chassis for loose parts, damage, or wear. Do not use if damaged.
- This chassis is designed for use with compatible Peg-Pérego components. Using non-approved accessories may be unsafe.

3. SETUP AND ASSEMBLY

Follow these steps to set up your Peg-Pérego Chassis.

3.1 Unfolding the Chassis

1. Place the folded chassis on a flat, stable surface.
2. Locate the folding release mechanism.
3. Release the lock and lift the handle upwards until the chassis fully extends and locks into place. You should hear an audible click.
4. Verify that all locking mechanisms are securely engaged before use.



Figure 1: Peg-Pérego Chassis in unfolded configuration. This image shows the chassis fully extended with the handle raised and the wheels ready for use. The storage basket is visible underneath the seat area.

3.2 Attaching Compatible Components

This chassis is designed to accept various Peg-Pérego compatible components such as car seats or stroller seats. Refer to the specific component's manual for attachment instructions. Ensure components are securely fastened to the chassis before use.

4. OPERATING INSTRUCTIONS

4.1 Folding the Chassis

1. Ensure any attached components (seat, car seat) are removed or folded according to their respective manuals.
2. Engage the parking brake.

3. Locate the folding release mechanisms (usually on the handle or side frame).
4. Simultaneously activate the release mechanisms and push the handle downwards, allowing the chassis to collapse.
5. Secure the chassis in its folded position using the integrated locking clip.



Figure 2: Peg-Pérego Chassis in folded configuration. This image displays the chassis collapsed into a compact form, suitable for storage or transportation.

4.2 Using the Parking Brake

The parking brake is located on the rear axle. To engage, press the brake pedal down firmly until it clicks into place. To release, lift the pedal upwards. Always ensure the brake is fully engaged when the chassis is stationary.

4.3 Handle Adjustment

The handle height can be adjusted for user comfort. Locate the adjustment buttons on either side of the handle. Press these buttons and simultaneously move the handle to the desired height. Release the buttons to lock the handle in position.

5. MAINTENANCE AND CARE

- **Cleaning the Frame:** Wipe the chassis frame with a damp cloth and mild soap. Dry thoroughly. Do not use abrasive cleaners or solvents.
- **Wheel Maintenance:** Regularly check wheels for debris and ensure they rotate freely. Lubricate axles with a silicone-based spray if necessary.
- **Storage:** Store the chassis in a dry, well-ventilated area, away from direct sunlight and extreme temperatures.
- **Inspections:** Periodically check all screws, rivets, and plastic parts for tightness and damage. Replace worn or damaged parts immediately.

6. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--|--|---|
| Chassis does not unfold/fold smoothly. | Locking mechanisms are stiff or obstructed. | Ensure all release levers are fully engaged. Check for debris in the folding mechanism. Apply a silicone lubricant if necessary. |
| Wheels squeak or do not turn freely. | Dirt or debris in the axle, lack of lubrication. | Clean wheels and axles. Apply a silicone-based lubricant to moving parts. |
| Parking brake is not engaging/disengaging. | Mechanism obstructed or damaged. | Check for debris around the brake pedal and mechanism. Ensure the pedal is fully pressed/lifted. If problem persists, contact customer support. |

7. SPECIFICATIONS

- **Model Number:** ICBT0000NL31
- **Package Dimensions:** 89 x 56.4 x 23.2 cm
- **Item Weight:** 1.5 kg
- **Manufacturer:** Peg-Pérego
- **Batteries Required:** No
- **First Available Date:** March 8, 2019

8. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your purchase or visit the official Peg-Pérego website. For technical support, spare parts, or service inquiries, please contact Peg-Pérego customer service through their official channels.

Manufacturer: Peg-Pérego

Website: www.pegperego.com (Note: This is a placeholder URL, please refer to your product documentation for the correct support website.)

